



**AFFINITY
AERONAUTICAL
SOLUTIONS**

LEADERS IN QUALITY REPAIRS AND SERVICE

FAA CRS# NC4R383M EASA.145.6578

WWW.AFFINITY.AERO

OFFICE: (954) 399-7876 • FAX: (954) 278-9980



PART NUMBER	DESCRIPTION	OEM
ACR/EM-1A	PORTABLE SAFETY MEGAPHONE	ACR ELECTRONICS
ACR/EM-1D	PORTABLE SAFETY MEGAPHONE	ACR ELECTRONICS
AC30-0004	STARTER SWITCH ASSEMBLY	ESTERLINE
AC30-0004-1	STARTER SWITCH ASSEMBLY	ESTERLINE
AC30-0004-2	STARTER SWITCH ASSEMBLY	ESTERLINE
AE0607AA1	ARINC FAN	TECHNOFAN/SAFRAN
AE0607AA2	ARINC FAN	TECHNOFAN/SAFRAN
AE0607F00	ARINC FAN	TECHNOFAN/SAFRAN
AE0607F01	ARINC FAN	TECHNOFAN/SAFRAN
AE0804AA1	COCKPIT DISPLAY FAN	TECHNOFAN/SAFRAN
AE0804AA2	COCKPIT DISPLAY FAN	TECHNOFAN/SAFRAN
AE0804C00	COCKPIT DISPLAY FAN	TECHNOFAN/SAFRAN
AE0804C01	COCKPIT DISPLAY FAN	TECHNOFAN/SAFRAN
AE1502U00	UNIVERSAL BRAKE COOLING FAN	TECHNOFAC/SAFRAN
AE1502U01	UNIVERSAL BRAKE COOLING FAN	TECHNOFAC/SAFRAN
AE1502U02	UNIVERSAL BRAKE COOLING FAN	TECHNOFAC/SAFRAN
AE1502U02AMDTA	UNIVERSAL BRAKE COOLING FAN	TECHNOFAC/SAFRAN
AE1502U02AMDTB	UNIVERSAL BRAKE COOLING FAN	TECHNOFAC/SAFRAN
AHV5-221	HEIGHT INDICATOR FOR RADIO ALTIMETERS	THALES
APE 5100	ELECTRONIC CLOCK	AIR PRECISION
APE 5100-1	ELECTRONIC CLOCK	AIR PRECISION
AW2835AB01	CABIN ALTITUDE & DIFFERENTIAL PRESSURE INDICATOR	AMETEK AEROSPACE
AW2835AB02	CABIN ALTITUDE & DIFFERENTIAL PRESSURE INDICATOR	AMETEK AEROSPACE
AW2835AB04	CABIN ALTITUDE & DIFFERENTIAL PRESSURE INDICATOR	AMETEK AEROSPACE
AW2835AB05	CABIN ALTITUDE & DIFFERENTIAL PRESSURE INDICATOR	AMETEK AEROSPACE
AW2835AB06	CABIN ALTITUDE & DIFFERENTIAL PRESSURE INDICATOR	AMETEK AEROSPACE
AW2835AB07	CABIN ALTITUDE & DIFFERENTIAL PRESSURE INDICATOR	AMETEK AEROSPACE
A05000	ACTUATOR ASSEMBLY	SITEC AEROSPACE
A05B00	ACTUATOR ASSEMBLY	SITEC AEROSPACE
A06000	ACTUATOR ASSEMBLY	SITEC AEROSPACE
A06A00	ACTUATOR ASSEMBLY	SITEC AEROSPACE
A06C00	ACTUATOR ASSEMBLY	SITEC AEROSPACE
A06D00	ACTUATOR ASSEMBLY	SITEC AEROSPACE
A06L00	ACTUATOR ASSEMBLY	SITEC AEROSPACE
A-1077DD	CONTACTOR	TE CONNECTIVITY
A3-06-1402	PORTABLE SAFETY MEGAPHONE	ACR ELECTRONICS
A8985-1	FLOODLIGHT	MIDLANDROSS/GRIMES
A8985-2	FLOODLIGHT	MIDLANDROSS/GRIMES
A8985-3	FLOODLIGHT	MIDLANDROSS/GRIMES
A8985-4	FLOODLIGHT	MIDLANDROSS/GRIMES
A8985-5	FLOODLIGHT	MIDLANDROSS/GRIMES
A8985-6	FLOODLIGHT	MIDLANDROSS/GRIMES
A8985-7	FLOODLIGHT	MIDLANDROSS/GRIMES
A8985-8	FLOODLIGHT	MIDLANDROSS/GRIMES
A8985-9	FLOODLIGHT	MIDLANDROSS/GRIMES
A8985-10	FLOODLIGHT	MIDLANDROSS/GRIMES
A8985-11	FLOODLIGHT	MIDLANDROSS/GRIMES
A8985-12	FLOODLIGHT	MIDLANDROSS/GRIMES
A8985-13	FLOODLIGHT	MIDLANDROSS/GRIMES
A8985-14	FLOODLIGHT	MIDLANDROSS/GRIMES
A8985-15	FLOODLIGHT	MIDLANDROSS/GRIMES
A8985-16	FLOODLIGHT	MIDLANDROSS/GRIMES
A8985-17	FLOODLIGHT	MIDLANDROSS/GRIMES
A8985-103	FLOODLIGHT	MIDLANDROSS/GRIMES
BAO8032-230	BALLAST	BRUCE INDUSTRIES
BA5-0933-901	BATTERY POWER SUPPLY	BRUCE INDUSTRIES
BC-1301	BATTERY CHARGER MODEL BC-1301	SECURAPLANE
BFS24	BATTERY AND CHARGER SYSTEM	RADIANT POWER CORP
BP-493-3	3PST CONTACTOR	TYCO ELECTRONICS

PART NUMBER	DESCRIPTION	OEM
BPS7-2	BATTERY POWER SUPPLY	RADIANT POWER CORP
BPS7-3	BATTERY POWER SUPPLY	RADIANT POWER CORP
BP-353A	3PST NC SIDESTABLE CONTACTOR	HARTMAN ELECTRICAL
BP-493-1 MOD.06	3PST CONTACTOR	TYCO ELECTRONICS
BP-493-1 MOD.07	3PST CONTACTOR	TYCO ELECTRONICS
BP-493-1 MOD.08	3PST CONTACTOR	TYCO ELECTRONICS
BR7203-701	CARGO LIGHT	BRUCE INDUSTRIES
BR9500-5	BALLAST	BRUCE INDUSTRIES
B0247-81101	MACH AIRSPEED INDICATOR	GE AVIATION
B0247-81105	MACH AIRSPEED INDICATOR	GE AVIATION
B0247-81106	MACH AIRSPEED INDICATOR	GE AVIATION
B0247-81107	MACH AIRSPEED INDICATOR	GE AVIATION
B13-944.22.00.0.A	MECHANICAL AIRCRAFT CHRONOGRAPH	REVUE THOMMEN
B13-944.22.28.2.A	MECHANICAL AIRCRAFT CHRONOGRAPH	REVUE THOMMEN
B13-944.32.05.1.CH	MECHANICAL AIRCRAFT CHRONOGRAPH	REVUE THOMMEN
B15-945.32.05.4.CD	MECHANICAL AIRCRAFT CHRONOGRAPH	REVUE THOMMEN
B17-941.22.05.1.A	MECHANICAL AIRCRAFT CHRONOGRAPH	REVUE THOMMEN
B17-941.27.00.0.A	MECHANICAL AIRCRAFT CHRONOGRAPH	REVUE THOMMEN
B17-951.22.05.1.DG	MECHANICAL AIRCRAFT CHRONOGRAPH	REVUE THOMMEN
B17-951.22.05.4.AA	MECHANICAL AIRCRAFT CHRONOGRAPH	REVUE THOMMEN
B17-952.22.05.3.A	MECHANICAL AIRCRAFT CHRONOGRAPH	REVUE THOMMEN
B18-945.22.00.0.A	MECHANICAL AIRCRAFT CHRONOGRAPH	REVUE THOMMEN
B18-945.22.05.1.A	MECHANICAL AIRCRAFT CHRONOGRAPH	REVUE THOMMEN
B18-945.22.05.1.K	MECHANICAL AIRCRAFT CHRONOGRAPH	REVUE THOMMEN
B18-945.22.05.4.CR	MECHANICAL AIRCRAFT CHRONOGRAPH	REVUE THOMMEN
B18-945.22.28.1.A	MECHANICAL AIRCRAFT CHRONOGRAPH	REVUE THOMMEN
B18-945.22.28.1.K	MECHANICAL AIRCRAFT CHRONOGRAPH	REVUE THOMMEN
B18-945.22.28.2.A	MECHANICAL AIRCRAFT CHRONOGRAPH	REVUE THOMMEN
B18-945.22.28.4.CR	MECHANICAL AIRCRAFT CHRONOGRAPH	REVUE THOMMEN
B18-945.22.28.4.DN	MECHANICAL AIRCRAFT CHRONOGRAPH	REVUE THOMMEN
B18-945.32.28.1.AG	MECHANICAL AIRCRAFT CHRONOGRAPH	REVUE THOMMEN
B18-945.32.28.1.AJ	MECHANICAL AIRCRAFT CHRONOGRAPH	REVUE THOMMEN
B18-945.32.28.3.AG	MECHANICAL AIRCRAFT CHRONOGRAPH	REVUE THOMMEN
B18-955.22.00.0.CL	MECHANICAL AIRCRAFT CHRONOGRAPH	REVUE THOMMEN
B18-955.22.00.0.CS	MECHANICAL AIRCRAFT CHRONOGRAPH	REVUE THOMMEN
B18-955.22.05.4.CG	MECHANICAL AIRCRAFT CHRONOGRAPH	REVUE THOMMEN
B18-955.22.28.4.DC	MECHANICAL AIRCRAFT CHRONOGRAPH	REVUE THOMMEN
CG7P0	SMOKE DETECTOR	CERBERUS SA
CG7GT	SMOKE DETECTOR	CERBERUS SA
CG7GT-10	SMOKE DETECTOR	CERBERUS SA
CG7G0	SMOKE DETECTOR	CERBERUS SA
CG7G0-S	SMOKE DETECTOR	CERBERUS SA
CG7G0-10	SMOKE DETECTOR	CERBERUS SA
CG7G0-11	SMOKE DETECTOR	CERBERUS SA
CG7PT	SMOKE DETECTOR	CERBERUS SA
CG7PT-2	SMOKE DETECTOR	CERBERUS SA
CG7PT-10	SMOKE DETECTOR	CERBERUS SA
C16195AA	TOTAL PRESSURE PROBE	THALES
C16195BA	TOTAL PRESSURE PROBE	THALES
C12404AA01	ATC/TCAS CONTROL PANEL	THALES
C12404AB02	ATC/TCAS CONTROL PANEL	THALES
C12404BA02	ATC/TCAS CONTROL PANEL	THALES
C12404BB03	ATC/TCAS CONTROL PANEL	THALES
C12404EA01	ATC/TCAS CONTROL PANEL	THALES
C12404EA02	ATC/TCAS CONTROL PANEL	THALES
C406-1	EMERGENCY LOCATOR TRANSMITTER	ARTEX
C406-1HM	EMERGENCY LOCATOR TRANSMITTER	ARTEX
DLH 549-017	HOT CUP	ZODIAC AEROSPACE
D05000	FILL & DRAIN / OVERFLOW SHUT-OFF VALVE	SITEC AEROSPACE
D05A00	FILL & DRAIN / OVERFLOW SHUT-OFF VALVE	SITEC AEROSPACE
D05B00	FILL & DRAIN / OVERFLOW SHUT-OFF VALVE	SITEC AEROSPACE
D05C00	FILL & DRAIN / OVERFLOW SHUT-OFF VALVE	SITEC AEROSPACE
D23119750	ELECTRICAL BOX	SAFRAN
D23119750-1	ELECTRICAL BOX	SAFRAN
D23119751	ELECTRICAL BOX	SAFRAN
D23119751-1	ELECTRICAL BOX	SAFRAN
D23119760	ELECTRICAL BOX	SAFRAN

PART NUMBER	DESCRIPTION	OEM
D23119760-1	ELECTRICAL BOX	SAFRAN
D23119761	ELECTRICAL BOX	SAFRAN
D23119761-1	ELECTRICAL BOX	SAFRAN
D23119770	ELECTRICAL BOX	SAFRAN
D23119770-1	ELECTRICAL BOX	SAFRAN
D23119771	ELECTRICAL BOX	SAFRAN
D434-36-001	FLIGHT MODE ANNUNCIATOR	PAGE ENGINEERING
D434-56-001	AUTOFLIGHT STATUS ANNUNCIATOR	PAGE AEROSPACE
D717-01-001	EMERGENCY POWER SUPPLY	PAGE AEROSPACE
D717-02-001	EMERGENCY POWER SUPPLY	PAGE AEROSPACE
D717-01-100	BATTERY PACK	PAGE AEROSPACE
EA1065A-2406	WATER QUANTITY TANK UNIT	BF GOODRICH
EA1065A-2721	WATER QUANTITY TANK UNIT	BF GOODRICH
EA1065A-2745	WATER QUANTITY TANK UNIT	BF GOODRICH
EA1093A-3544	LIQUID QUANTITY TRANSMITTER	BF GOODRICH
EA1093A-3679	LIQUID QUANTITY TRANSMITTER	BF GOODRICH
EA1093AW3679	LIQUID QUANTITY TRANSMITTER	BF GOODRICH
ELM827-1	3PST CONTACTOR	TYCO ELECTRONICS
ELM827-3	3PST CONTACTOR	TYCO ELECTRONICS
ELM832-1	3PST NC SIDESTABLE CONTACTOR	HARTMAN ELECTRICAL
EP-410	VOLTAGE SENSITIVE RELAY	LEACH CORP
EVT3454G	AVIONICS FAN	SAFRAN TECHNOFAN
EVT3454H	AVIONICS FAN	SAFRAN TECHNOFAN
EVT3454HC	AVIONICS FAN	SAFRAN TECHNOFAN
E709-01-001	CEILING LIGHT	PAGE
E709-03-001	CEILING LIGHT	PAGE
E709-04-001	CEILING LIGHT	PAGE
FDS765A-1	SMOKE SENSOR ASSEMBLY	NOHMI BOSAI LTD
FDS765A-1A	SMOKE SENSOR ASSEMBLY	NOHMI BOSAI LTD
FDS765A-2	SMOKE SENSOR ASSEMBLY	NOHMI BOSAI LTD
FDS765A-2A	SMOKE SENSOR ASSEMBLY	NOHMI BOSAI LTD
FG243A1	OIL QUANTITY TANK UNIT AND COMPENSATOR	HONEYWELL
FG243A2	OIL QUANTITY TANK UNIT AND COMPENSATOR	HONEYWELL
FG243A3	OIL QUANTITY TANK UNIT AND COMPENSATOR	HONEYWELL
FG243A4	OIL QUANTITY TANK UNIT AND COMPENSATOR	HONEYWELL
F11QB3121	TRANSFORMER-RECTIFIER	AUXILEC
F11QY3121	TRANSFORMER-RECTIFIER	AUXILEC
F61A0048	SWING CHECK VALVE ASSEMBLY	PARKER HANNIFIN
GE16569-3	AUTO TRANSFORMER ASSEMBLY	BF GOODRICH
GE16569-4	AUTO TRANSFORMER ASSEMBLY	BF GOODRICH
GG436-4006-7	ICE DETECTOR	LIEBHERR
GG436-4006-9	ICE DETECTOR	LIEBHERR
GG670-80023-1	ICE DETECTOR	LIEBHERR
GMT 4190-011	ELECTRONIC CLOCK	AIR PRECISION
GMT 4190-012	ELECTRONIC CLOCK	AIR PRECISION
GMT 4190-020	ELECTRONIC CLOCK	AIR PRECISION
GMT 4200	ELECTRONIC CLOCK	AIR PRECISION
GMT 4200-1	ELECTRONIC CLOCK	AIR PRECISION
G-610-11	INTERCOM AMPLIFIER	GABLES
G0610-11	INTERCOM AMPLIFIER	GABLES
G1248B1	ANNUNCIATOR CONTROL	GABLES
G1340F	NAV WARNING AMPLIFIER	GABLES
G2141	DUAL COMM CONTROL PANEL	GABLES
G2141 MOD A	DUAL COMM CONTROL PANEL	GABLES
G2412	AUDIO CONTROL PANEL	GABLES
G2412 MOD A	AUDIO CONTROL PANEL	GABLES
G2412 MOD B	AUDIO CONTROL PANEL	GABLES
G2450B MOD A thru C	AUDIO CONTROL PANEL	GABLES
G2750A	AUDIO CONTROL PANEL	GABLES
G3122B MOD C	INTERPHONE AMPLIFIER	GABLES
G3454B	ADF CONTROL PANEL	GABLES
G37-1J	THERMAL SWITCH	HONEYWELL
G3737	AUDIO CONTROL PANEL	HONEYWELL
G3737-02 MOD B	AUDIO CONTROL PANEL	GABLES
G3737-05 MOD D	AUDIO CONTROL PANEL	GABLES
G4103	NAV/COMM CONTROL PANEL	GABLES
G5207A MOD F	AUDIO CONTROL PANEL	GABLES

PART NUMBER	DESCRIPTION	OEM
G5400-1	LANDING LIGHT	HONEYWELL
G5400-2	LANDING LIGHT	HONEYWELL
G5400-3	LANDING LIGHT	HONEYWELL
G5400-4	LANDING LIGHT	HONEYWELL
G5400-5	LANDING LIGHT	HONEYWELL
G5400-6	LANDING LIGHT	HONEYWELL
G5400-15	LANDING LIGHT	HONEYWELL
G5400-16	LANDING LIGHT	HONEYWELL
G5400-17	LANDING LIGHT	HONEYWELL
G5400-18	LANDING LIGHT	HONEYWELL
G5515 MOD C	COCKPIT SPEAKER	GABLES
G5584	VHF COMM CONTROL PANEL	GABLES
G5586	JACK BOX CONTROL PANEL	GABLES
G5730	INSTRUMENT SWITCHING PANELS	GABLES
G5730-03	INSTRUMENT SWITCHING PANELS	GABLES
G5730-04	INSTRUMENT SWITCHING PANELS	GABLES
G5780 MOD B	NAV CONTROL PANEL	GABLES
G5852	INSTRUMENT SWITCHING PANEL	GABLES
G5870 MOD E	AUDIO CONTROL PANEL	GABLES
G5870 MOD F	AUDIO CONTROL PANEL	GABLES
G6076 MOD A	COMM CONTROL PANEL	GABLES
G6076 MOD B	COMM CONTROL PANEL	GABLES
G6076 MOD C	COMM CONTROL PANEL	GABLES
G6076-05 MOD C	COMM CONTROL PANEL	GABLES
G6101	AUDIO CONTROL PANEL	GABLES
G6107A	PREAMPLIFIER ADJUSTMENT	BOEING
G6200	VHF COMM CONTROL PANEL	GABLES
G6200-02	VHF COMM CONTROL PANEL	GABLES
G6200-03	VHF COMM CONTROL PANEL	GABLES
G6200-04	VHF COMM CONTROL PANEL	GABLES
G6200-05	VHF COMM CONTROL PANEL	GABLES
G6200-06	VHF COMM CONTROL PANEL	GABLES
G6200-07	VHF COMM CONTROL PANEL	GABLES
G6200-12	VHF COMM CONTROL PANEL	GABLES
G6200-13	VHF COMM CONTROL PANEL	GABLES
G6200-15	VHF COMM CONTROL PANEL	GABLES
G6206	ATC CONTROL PANEL	GABLES
G6206-02	ATC CONTROL PANEL	GABLES
G6206-03	ATC CONTROL PANEL	GABLES
G6206-04	ATC CONTROL PANEL	GABLES
G6206-05	ATC CONTROL PANEL	GABLES
G6206-06	ATC CONTROL PANEL	GABLES
G6206-07	ATC CONTROL PANEL	GABLES
G6206-10	ATC CONTROL PANEL	GABLES
G6206-13	ATC CONTROL PANEL	GABLES
G6206-14	ATC CONTROL PANEL	GABLES
G6206-15	ATC CONTROL PANEL	GABLES
G6206-17	ATC CONTROL PANEL	GABLES
G6206-19	ATC CONTROL PANEL	GABLES
G6210-03 MOD D	AUDIO CONTROL PANEL	GABLES
G6560-03 MOD E	AUDIO CONTROL PANEL	GABLES
G6560-03 MOD F	AUDIO CONTROL PANEL	GABLES
G6773	VHF NAV/DME CONTROL PANEL	GABLES
G6773-02	VHF NAV/DME CONTROL PANEL	GABLES
G6773-03	VHF NAV/DME CONTROL PANEL	GABLES
G6773-04	VHF NAV/DME CONTROL PANEL	GABLES
G-6965-8	AIRCRAFT ROTATING WARNING NAVIGATIONAL LIGHT	T.O. 8D10-6-6-3
G-6965-22	AIRCRAFT ROTATING WARNING NAVIGATIONAL LIGHT	T.O. 8D10-6-6-3
G-6965-34	AIRCRAFT ROTATING WARNING NAVIGATIONAL LIGHT	T.O. 8D10-6-6-3
G6977-03	AUDIO CONTROL PANEL	GABLES
G6977-05	AUDIO CONTROL PANEL	GABLES
G6980-01	AUDIO MANAGEMENT UNIT	GABLES
G6980-02	AUDIO MANAGEMENT UNIT	GABLES
G6981	AUDIO CONTROL PANEL	GABLES
G6981-01	AUDIO CONTROL PANEL	GABLES
G6981-02	AUDIO CONTROL PANEL	GABLES
G6981-03	AUDIO CONTROL PANEL	GABLES

PART NUMBER	DESCRIPTION	OEM
G6981-04	AUDIO CONTROL PANEL	GABLES
G6990-02	MODE-S ATC/TCAS CONTROL PANEL	GABLES
G6990-05	MODE-S ATC/TCAS CONTROL PANEL	GABLES
G6990-08	MODE-S ATC/TCAS CONTROL PANEL	GABLES
G6990-09	MODE-S ATC/TCAS CONTROL PANEL	GABLES
G6990-12	MODE-S ATC/TCAS CONTROL PANEL	GABLES
G6990-13	MODE-S ATC/TCAS CONTROL PANEL	GABLES
G6990-15	MODE-S ATC/TCAS CONTROL PANEL	GABLES
G6990-17	MODE-S ATC/TCAS CONTROL PANEL	GABLES
G6990-19	MODE-S ATC/TCAS CONTROL PANEL	GABLES
G6990-20	MODE-S ATC/TCAS CONTROL PANEL	GABLES
G6990-21	MODE-S ATC/TCAS CONTROL PANEL	GABLES
G6990-24	MODE-S ATC/TCAS CONTROL PANEL	GABLES
G6990-25	MODE-S ATC/TCAS CONTROL PANEL	GABLES
G6990-27	MODE-S ATC/TCAS CONTROL PANEL	GABLES
G6990-28	MODE-S ATC/TCAS CONTROL PANEL	GABLES
G6990-34	MODE-S ATC/TCAS CONTROL PANEL	GABLES
G6990-35	MODE-S ATC/TCAS CONTROL PANEL	GABLES
G6990-40	ATC/TCAS CONTROL PANEL	GABLES
G6990-51	ATC/TCAS CONTROL PANEL	GABLES
G6990-53	ATC/TCAS CONTROL PANEL	GABLES
G6992-02	ATC/TCAS CONTROL PANEL	GABLES
G6992-40	ATC/TCAS CONTROL PANEL	GABLES
G7164	HF/SAT SELECT CONTROL PANEL	GABLES
G7164-01 MOD A	HF/SAT SELECT CONTROL PANEL	GABLES
G7164-01 MOD B	HF/SAT SELECT CONTROL PANEL	GABLES
G7164-03 MOD A	HF/SAT SELECT CONTROL PANEL	GABLES
G7164-05 MOD A	HF/SAT SELECT CONTROL PANEL	GABLES
G7164-05 MOD B	HF/SAT SELECT CONTROL PANEL	GABLES
G7185-05 MOD H	SMOKE DETECTION/SUPPRESSION PANEL	GABLES
G7189-02 MOD C	SMOKE DETECTION/SUPPRESSION PANEL	GABLES
G7189-04 MOD E	SMOKE DETECTION/SUPPRESSION PANEL	GABLES
G7189-09 MOD C	SMOKE DETECTION/SUPPRESSION PANEL	GABLES
G7400-04	VHF COMM CONTROL PANEL	GABLES
G7400-11 MOD D	VHF COMM CONTROL PANEL	GABLES
G7400-12	VHF COMM CONTROL PANEL	GABLES
G7400-12 MOD A	VHF COMM CONTROL PANEL	GABLES
G7400-12 MOD B	VHF COMM CONTROL PANEL	GABLES
G7400-12 MOD C	VHF COMM CONTROL PANEL	GABLES
G7400-12 MOD D	VHF COMM CONTROL PANEL	GABLES
G7400-12 MOD E	VHF COMM CONTROL PANEL	GABLES
G7400-12 MOD F	VHF COMM CONTROL PANEL	GABLES
G7400-13	VHF COMM CONTROL PANEL	GABLES
G7400-15 MOD H	VHF COMM CONTROL PANEL	GABLES
G7400-23	VHF COMM CONTROL PANEL	GABLES
G7400-27	VHF COMM CONTROL PANEL	GABLES
G7400-29	VHF COMM CONTROL PANEL	GABLES
G7400-29 MOD A	VHF COMM CONTROL PANEL	GABLES
G7400-29 MOD B	VHF COMM CONTROL PANEL	GABLES
G7400-29 MOD C	VHF COMM CONTROL PANEL	GABLES
G7400-31	VHF COMM CONTROL PANEL	GABLES
G7400-31 MOD A	VHF COMM CONTROL PANEL	GABLES
G7400-31 MOD B	VHF COMM CONTROL PANEL	GABLES
G7400-31 MOD C	VHF COMM CONTROL PANEL	GABLES
G7400-31 MOD D	VHF COMM CONTROL PANEL	GABLES
G7402-04	ADF CONTROL PANEL	GABLES
G7402-04 MOD A	ADF CONTROL PANEL	GABLES
G7402-04 MOD B	ADF CONTROL PANEL	GABLES
G7402-04 MOD C	ADF CONTROL PANEL	GABLES
G7402-04 MOD D	ADF CONTROL PANEL	GABLES
G7403-03	ADF CONTROL PANEL	GABLES
G7404-04	RADIO TUNING PANEL	GABLES
G7404-21	RADIO TUNING PANEL	GABLES
G7404-24	RADIO TUNING PANEL	GABLES
G7404-31 MOD L	RADIO TUNING PANEL	GABLES
G7404-121	RADIO TUNING PANEL	GABLES
G7404-123	RADIO TUNING PANEL	GABLES

PART NUMBER	DESCRIPTION	OEM
G7404-124	RADIO TUNING PANEL	GABLES
G7406-04	VHF COMM CONTROL PANEL	GABLES
G7406-04 MOD A	VHF COMM CONTROL PANEL	GABLES
G7406-04 MOD B	VHF COMM CONTROL PANEL	GABLES
G7406-04 MOD C	VHF COMM CONTROL PANEL	GABLES
G7406-04 MOD D	VHF COMM CONTROL PANEL	GABLES
G7406-04 MOD E	VHF COMM CONTROL PANEL	GABLES
G7406-04 MOD F	VHF COMM CONTROL PANEL	GABLES
G7406-04 MOD G	VHF COMM CONTROL PANEL	GABLES
G7406-04 MOD H	VHF COMM CONTROL PANEL	GABLES
G7406-04 MOD I	VHF COMM CONTROL PANEL	GABLES
G7406-05 MOD F	VHF COMM CONTROL PANEL	GABLES
G7406-20	VHF COMM CONTROL PANEL	GABLES
G7406-27	VHF COMM CONTROL PANEL	GABLES
G7406-27 MOD A	VHF COMM CONTROL PANEL	GABLES
G7406-27 MOD B	VHF COMM CONTROL PANEL	GABLES
G7406-204	VHF COMM CONTROL PANEL	GABLES
G7406-204 MOD A	VHF COMM CONTROL PANEL	GABLES
G7406-204 MOD B	VHF COMM CONTROL PANEL	GABLES
G7406-204 MOD C	VHF COMM CONTROL PANEL	GABLES
G7406-204 MOD D	VHF COMM CONTROL PANEL	GABLES
G7406-204 MOD E	VHF COMM CONTROL PANEL	GABLES
G7406-204 MOD F	VHF COMM CONTROL PANEL	GABLES
G7406-204 MOD G	VHF COMM CONTROL PANEL	GABLES
G7406-204 MOD H	VHF COMM CONTROL PANEL	GABLES
G7406-204 MOD I	VHF COMM CONTROL PANEL	GABLES
G7490-25 MOD F	DUAL MODE-S FLIGHT ID/ATC/TCAS CONTROL PANEL	GABLES
HAC19460	IMMERSION THERMOCOUPLE	HARCO LABORATORIES
HAD21339	EXHAUST GAS TEMPERATURE (EGT) / T3 HARNESS	HARCO LABORATORIES
HAD21988	EXHAUST GAS TEMPERATURE (EGT) / T3 HARNESS	HARCO LABORATORIES
HFA2000-10	COFFEE MAKER	IACOBUCCI HF
HFE95-20D	ESPRESSO MAKER	IACOBUCCI HF
HTE6303	6mm SWIVEL PIPE ASSEMBLY	EATON
HTE69000-1	PRESSURE SWITCH	EATON
H10-1015-3	ENCLOSED SWITCH	EATON
H10-1015-4	ENCLOSED SWITCH	EATON
H20-24B	SWITCH-ENCLOSED	EATON
JG1052AA01	ALTITUDE ALERT INDICATOR	HONEYWELL
JG1052AA02	ALTITUDE ALERT INDICATOR	HONEYWELL
JG1052AA03	ALTITUDE ALERT INDICATOR	HONEYWELL
JG1052AA04	ALTITUDE ALERT INDICATOR	HONEYWELL
JG1052AA05	ALTITUDE ALERT INDICATOR	HONEYWELL
JG1052AA06	ALTITUDE ALERT INDICATOR	HONEYWELL
JG1052AA07	ALTITUDE ALERT INDICATOR	HONEYWELL
JG1052AA08	ALTITUDE ALERT INDICATOR	HONEYWELL
JG1052AB01	ALTITUDE ALERT INDICATOR	HONEYWELL
JG1052AB02	ALTITUDE ALERT INDICATOR	HONEYWELL
JG1052AB03	ALTITUDE ALERT INDICATOR	HONEYWELL
JG1052AB04	ALTITUDE ALERT INDICATOR	HONEYWELL
JG1052AC01	ALTITUDE ALERT INDICATOR	HONEYWELL
JG1052AC02	ALTITUDE ALERT INDICATOR	HONEYWELL
JG1052AC03	ALTITUDE ALERT INDICATOR	HONEYWELL
JG1052AC04	ALTITUDE ALERT INDICATOR	HONEYWELL
JG1052AC09	ALTITUDE ALERT INDICATOR	HONEYWELL
JG1052AK01	ALTITUDE ALERT INDICATOR	HONEYWELL
JG1052AP01	ALTITUDE ALERT INDICATOR	HONEYWELL
JG1052BC01	ALTITUDE ALERT INDICATOR	HONEYWELL
JG1052BD01	ALTITUDE ALERT INDICATOR	HONEYWELL
LA11A2104	LINEAR ACTUATOR	ITT AEROSPACE
LG80E1	ENGINE PRESSURE RATIO COMPUTER	HONEYWELL
LK-35-1	STANDBY ALTIMETER	TOKYO AIRCRAFT INST
LK-35-2	STANDBY ALTIMETER	TOKYO AIRCRAFT INST
LK-35-3	STANDBY ALTIMETER	TOKYO AIRCRAFT INST
LK-35-4	STANDBY ALTIMETER	TOKYO AIRCRAFT INST
LK-35-7	STANDBY ALTIMETER	TOKYO AIRCRAFT INST
LK-35-8	STANDBY ALTIMETER	TOKYO AIRCRAFT INST
LK-35-9	STANDBY ALTIMETER	TOKYO AIRCRAFT INST

PART NUMBER	DESCRIPTION	OEM
L13471	RAPID WATER HEATER	DRIESSEN
L13471-03	RAPID WATER HEATER	ZODIAC
L13471-11	RAPID WATER HEATER	DRIESSEN
L13471-19	RAPID WATER HEATER	DRIESSEN
L13471-32	RAPID WATER HEATER	DRIESSEN
L13471-33	RAPID WATER HEATER	DRIESSEN
L13471-40	RAPID WATER HEATER	DRIESSEN
L18615	DOME LIGHT ASSEMBLY	GULTON INDUSTRIES
L18615-1	DOME LIGHT ASSEMBLY	GULTON INDUSTRIES
L18615-2	DOME LIGHT ASSEMBLY	GULTON INDUSTRIES
L18615-3	DOME LIGHT ASSEMBLY	GULTON INDUSTRIES
L18615-4	DOME LIGHT ASSEMBLY	GULTON INDUSTRIES
L18615-5	DOME LIGHT ASSEMBLY	GULTON INDUSTRIES
L18615-6	DOME LIGHT ASSEMBLY	GULTON INDUSTRIES
L18615-7	DOME LIGHT ASSEMBLY	GULTON INDUSTRIES
L18615-8	DOME LIGHT ASSEMBLY	GULTON INDUSTRIES
L18615-9	DOME LIGHT ASSEMBLY	GULTON INDUSTRIES
L18615-10	DOME LIGHT ASSEMBLY	GULTON INDUSTRIES
L18615-11	DOME LIGHT ASSEMBLY	GULTON INDUSTRIES
L18615-12	DOME LIGHT ASSEMBLY	GULTON INDUSTRIES
L18615-13	DOME LIGHT ASSEMBLY	GULTON INDUSTRIES
L18615-14	DOME LIGHT ASSEMBLY	GULTON INDUSTRIES
MA20A2027	OPTO ELECTRONIC MOTOR OPERATED ACTUATOR ASSY	ITT AEROSPACE
MA30A1001	OPTO ELECTRONIC MOTOR OPERATED ACTUATOR ASSY	ITT AEROSPACE
MODEL 1100	COFFEE MAKER ASSEMBLY	BE AEROSPACE
M83/P1801A	HAND HELD MICROPHONE	ELNO LEM
M83/P1801A PL68	HAND HELD MICROPHONE	ELNO LEM
MS28034-1	RESISTANCE TEMPERATURE DETECTOR	LEWIS ENGINEERING
MS28034-1	TEMPERATURE SENSOR	ESTERLINE NORWICH
MS28034-2	RESISTANCE TEMPERATURE DETECTOR	LEWIS ENGINEERING
MS28034-3	RESISTANCE TEMPERATURE DETECTOR	LEWIS ENGINEERING
PU90-401R1	SMOKE DETECTOR ASSY	JAMCO CORPORATION
PU90-401R2	SMOKE DETECTOR ASSY	JAMCO CORPORATION
PU90-401R3	SMOKE DETECTOR ASSY	JAMCO CORPORATION
PU90-401R4	SMOKE DETECTOR ASSY	JAMCO CORPORATION
PU90-401S	SMOKE DETECTOR ASSY	JAMCO CORPORATION
PU90-421R1	SMOKE DETECTOR ASSY	JAMCO CORPORATION
PU90-421R2	SMOKE DETECTOR ASSY	JAMCO CORPORATION
PU90-421R3	SMOKE DETECTOR ASSY	JAMCO CORPORATION
PU90-421R4	SMOKE DETECTOR ASSY	JAMCO CORPORATION
PU90-421S	SMOKE DETECTOR ASSY	JAMCO CORPORATION
PU90-431R1	SMOKE DETECTOR ASSY	JAMCO CORPORATION
PU90-431R2	SMOKE DETECTOR ASSY	JAMCO CORPORATION
PU90-431R3	SMOKE DETECTOR ASSY	JAMCO CORPORATION
PU90-431R4	SMOKE DETECTOR ASSY	JAMCO CORPORATION
PU90-431S	SMOKE DETECTOR ASSY	JAMCO CORPORATION
PU90-441R1	SMOKE DETECTOR ASSY	JAMCO CORPORATION
PU90-441R2	SMOKE DETECTOR ASSY	JAMCO CORPORATION
PU90-441R3	SMOKE DETECTOR ASSY	JAMCO CORPORATION
PU90-441R4	SMOKE DETECTOR ASSY	JAMCO CORPORATION
PU90-441S	SMOKE DETECTOR ASSY	JAMCO CORPORATION
PU90-451R1	SMOKE DETECTOR ASSY	JAMCO CORPORATION
PU90-451R2	SMOKE DETECTOR ASSY	JAMCO CORPORATION
PU90-451R3	SMOKE DETECTOR ASSY	JAMCO CORPORATION
PU90-451R4	SMOKE DETECTOR ASSY	JAMCO CORPORATION
PU90-451S	SMOKE DETECTOR ASSY	JAMCO CORPORATION
PU90-461R1	SMOKE DETECTOR ASSY	JAMCO CORPORATION
PU90-461R2	SMOKE DETECTOR ASSY	JAMCO CORPORATION
PU90-461R3	SMOKE DETECTOR ASSY	JAMCO CORPORATION
PU90-461R4	SMOKE DETECTOR ASSY	JAMCO CORPORATION
PU90-461S	SMOKE DETECTOR ASSY	JAMCO CORPORATION
PU90-499R1	SMOKE DETECTOR ASSY	JAMCO CORPORATION
PU90-499R2	SMOKE DETECTOR ASSY	JAMCO CORPORATION
PU90-499R3	SMOKE DETECTOR ASSY	JAMCO CORPORATION
PU90-499R4	SMOKE DETECTOR ASSY	JAMCO CORPORATION
PU90-499S	SMOKE DETECTOR ASSY	JAMCO CORPORATION
P10-009-0001	GLARESHIELD FLOODLIGHT	SPECTRALUX

PART NUMBER	DESCRIPTION	OEM
P141-395-1	POTABLE WATER TANK, SELECTOR VALVE ASSY	CIRCLE SEAL CONTROLS
P141-395-3	POTABLE WATER TANK, SELECTOR VALVE ASSY	CIRCLE SEAL CONTROLS
P141-395-5	POTABLE WATER TANK, SELECTOR VALVE ASSY	CIRCLE SEAL CONTROLS
Q0904	LINEAR TRANSDUCER RUDDER RATIO CHANGER	COLLINS
RD-AM8303	COCKPIT SPEAKER	PANASONIC
RD-AM8303-01	COCKPIT SPEAKER	PANASONIC
RD-AM8304	COCKPIT SPEAKER	PANASONIC
RL202EED5	TEMPERATURE INDICATOR	GE AVIATION
SEDLOC9B	DUAL DUCT PRESSURE INDICATOR	AMETEK
SEDLOC9C	DUAL DUCT PRESSURE INDICATOR	AMETEK
SEL-OC4AD	OIL PRESSURE INDICATOR	AMETEK
SM601BA10A22	CIRCUIT BREAKER	EATON
SM601BA15A22	CIRCUIT BREAKER	EATON
SM601BA20A22	CIRCUIT BREAKER	EATON
SM601BA25A22	CIRCUIT BREAKER	EATON
SM601BA35A22	CIRCUIT BREAKER	EATON
SM601BA40A22	CIRCUIT BREAKER	EATON
SM601BA50A22	CIRCUIT BREAKER	EATON
SM601BA60A22	CIRCUIT BREAKER	EATON
SM603BA10A	CIRCUIT BREAKER	EATON
SM603BA15A	CIRCUIT BREAKER	EATON
SM603BA20A	CIRCUIT BREAKER	EATON
SM603BA25A	CIRCUIT BREAKER	EATON
SM603BA35A	CIRCUIT BREAKER	EATON
SM603BA40A	CIRCUIT BREAKER	EATON
SM603BA50A	CIRCUIT BREAKER	EATON
SM603BA60	CIRCUIT BREAKER	EATON
SM603BA60A	CIRCUIT BREAKER	EATON
SRDL-6D	DUAL PRESSURE INDICATOR	AMETEK
SRL-C12F	HYDRAULIC FLUID QUANTITY INDICATOR	AMETEK
SRL-C12K	HYDRAULIC FLUID QUANTITY INDICATOR	AMETEK
SRL-C12P	HYDRAULIC FLUID QUANTITY INDICATOR	AMETEK
SRL-7F	HYDRAULIC PRESSURE INDICATOR	AMETEK
SRL-92E	SUPPLY AIR PRESSURE INDICATOR	AMETEK
SRL-92F	PNEUMATIC PRESSURE INDICATOR	AMETEK
SRL-92G	TEMP CONTROL VALVE POSITION INDICATOR	AMETEK
SRL-92H	PNEUMATIC PRESSURE INDICATOR	AMETEK
SRL-92P	PNEUMATIC PRESSURE INDICATOR	AMETEK
ST-104Y	SYNCHRO TRANSMITTER	AMETEK
ST-106AB	MULTIPURPOSE SYNCHRO TRANSMITTER	AMETEK
ST107Q	HYDRAULIC PRESSURE TRANSMITTER	AMETEK
ST12AE	POSITION TRANSMITTER	AMETEK
ST12S	POSITION TRANSMITTER	AMETEK
ST3100-20-01	HANDSET	BECKER AVIONIC
ST3100-20-02	HANDSET	BECKER AVIONIC
ST3100-21-10	HANDSET	BECKER AVIONIC
ST3100-21-11	HANDSET	BECKER AVIONIC
ST3100-21-12	HANDSET	BECKER AVIONIC
ST3100-21-13	HANDSET	BECKER AVIONIC
ST3100-21-14	HANDSET	BECKER AVIONIC
ST3100-21-15	HANDSET	BECKER AVIONIC
ST3100-21-16	HANDSET	BECKER AVIONIC
ST3100-21-17	HANDSET	BECKER AVIONIC
ST3100-21-18	HANDSET	BECKER AVIONIC
ST3100-21-21	HANDSET	BECKER AVIONIC
ST3100-21-22	HANDSET	BECKER AVIONIC
ST3100-21-25	HANDSET	BECKER AVIONIC
ST3100-21-28	HANDSET	BECKER AVIONIC
ST3100-21-30	HANDSET	BECKER AVIONIC
ST3100-21-31	HANDSET	BECKER AVIONIC
ST3100-21-32	HANDSET	BECKER AVIONIC
ST3100-22-10	HANDSET	BECKER AVIONIC
ST3100-22-12	HANDSET	BECKER AVIONIC
ST3100-22-14	HANDSET	BECKER AVIONIC
ST3100-22-18	HANDSET	BECKER AVIONIC
ST3100-22-21	HANDSET	BECKER AVIONIC
ST3100-22-22	HANDSET	BECKER AVIONIC

PART NUMBER	DESCRIPTION	OEM
ST3100-22-24	HANDSET	BECKER AVIONIC
ST3100-22-26	HANDSET	BECKER AVIONIC
ST3100-22-28	HANDSET	BECKER AVIONIC
ST3100-22-30	HANDSET	BECKER AVIONIC
ST3100-22-31	HANDSET	BECKER AVIONIC
ST3100-22-32	HANDSET	BECKER AVIONIC
ST3100-23-10	HANDSET	BECKER AVIONIC
ST3100-23-12	HANDSET	BECKER AVIONIC
ST3100-23-14	HANDSET	BECKER AVIONIC
ST3100-23-15	HANDSET	BECKER AVIONIC
ST3100-23-16	HANDSET	BECKER AVIONIC
ST3100-23-17	HANDSET	BECKER AVIONIC
ST3100-23-18	HANDSET	BECKER AVIONIC
ST3100-23-19	HANDSET	BECKER AVIONIC
ST3100-23-20	HANDSET	BECKER AVIONIC
ST3100-23-21	HANDSET	BECKER AVIONIC
ST3100-23-22	HANDSET	BECKER AVIONIC
ST3100-23-23	HANDSET	BECKER AVIONIC
ST3100-23-24	HANDSET	BECKER AVIONIC
ST3100-23-26	HANDSET	BECKER AVIONIC
ST3100-23-27	HANDSET	BECKER AVIONIC
ST3100-23-28	HANDSET	BECKER AVIONIC
ST3100-23-29	HANDSET	BECKER AVIONIC
ST3100-23-30	HANDSET	BECKER AVIONIC
ST3100-23-31	HANDSET	BECKER AVIONIC
ST3100-23-32	HANDSET	BECKER AVIONIC
ST3100-24-15	HANDSET	BECKER AVIONIC
ST3100-24-16	HANDSET	BECKER AVIONIC
ST3100-24-17	HANDSET	BECKER AVIONIC
ST3100-24-20	HANDSET	BECKER AVIONIC
ST3100-24-21	HANDSET	BECKER AVIONIC
ST3100-25-32	HANDSET	BECKER AVIONIC
ST3100-26-18	HANDSET	BECKER AVIONIC
ST3100-26-32	HANDSET	BECKER AVIONIC
ST3100-26-33	HANDSET	BECKER AVIONIC
ST3100-27-12	HANDSET	BECKER AVIONIC
ST3100-27-32	HANDSET	BECKER AVIONIC
ST3100-27-37	HANDSET	BECKER AVIONIC
ST3100-28-35	HANDSET	BECKER AVIONIC
ST3100-28-36	HANDSET	BECKER AVIONIC
ST3100-28-38	HANDSET	BECKER AVIONIC
ST3100-30-01	HANDSET	BECKER AVIONIC
ST3100-33-10	HANDSET	BECKER AVIONIC
ST506A	PNEUMATIC PRESSURE TRANSMITTER	AMETEK
ST509A	SUPPLY AIR PRESSURE TRANSMITTER	AMETEK
SLZ9885	ELECTRONIC THERMAL SWITCH CONTROL	SMITHS
S1653-1L	NAVIGATION LIGHT ASSEMBLIES / WING TIP	THE BOEING CO
S1653-1R	NAVIGATION LIGHT ASSEMBLIES / WING TIP	THE BOEING CO
S-168M	AUDIO HAILER	CABLEFORM
S-168MA	AUDIO HAILER	CABLEFORM
S1818502-02	ELT	KANNAD
S1819502-02	ELT	KANNAD
S1820502-01	ELT	KANNAD
S1820502-02	ELT	KANNAD
S1820502-04	ELT	KANNAD
S1821502-01	ELT	KANNAD
S1821502-02	ELT	KANNAD
S1821502-06	ELT	KANNAD
S1822502-01	ELT	KANNAD
S1822502-02	ELT	KANNAD
S1823502-01	ELT	KANNAD
S1823502-02	ELT	KANNAD
S1823502-03	ELT	KANNAD
S1823502-05	ELT	KANNAD
S1824502-01	ELT	KANNAD
S1824502-02	ELT	KANNAD
S1826502-02	ELT	KANNAD

PART NUMBER	DESCRIPTION	OEM
S1840501-01	ELT	KANNAD
S1840501-04	ELT	KANNAD
S1850501-01	ELT, INTEGRA FAMILY	KANNAD
S1850501-02	ELT, INTEGRA FAMILY	KANNAD
S1850501-03	ELT, INTEGRA FAMILY	KANNAD
S1851501-01	ELT, INTEGRA FAMILY	KANNAD
S1851501-02	ELT, INTEGRA FAMILY	KANNAD
S1851501-03	ELT, INTEGRA FAMILY	KANNAD
S1852501-01	ELT, INTEGRA FAMILY	KANNAD
S1852501-02	ELT, INTEGRA FAMILY	KANNAD
S1852501-03	ELT, INTEGRA FAMILY	KANNAD
S1854501-01	ELT, INTEGRA FAMILY	KANNAD
S1854501-02	ELT, INTEGRA FAMILY	KANNAD
S1854501-03	ELT, INTEGRA FAMILY	KANNAD
S210T120-15	FAN AIR MODULATING VALVE	UTC AEROSPACE
S210T120-105	FAN AIR MODULATING VALVE	UTC AEROSPACE
S210T120-115	FAN AIR MODULATING VALVE	UTC AEROSPACE
S210T120-125	FAN AIR MODULATING VALVE	UTC AEROSPACE
S210T120-132	PRESSURE CONTROLLER	UTC AEROSPACE
S210T120-135	FAN AIR MODULATING VALVE	UTC AEROSPACE
S210T120-142	PRESSURE CONTROLLER	UTC AEROSPACE
S210T120-152	PRESSURE CONTROLLER	UTC AEROSPACE
S210T120-162	PRESSURE CONTROLLER	UTC AEROSPACE
S210T120-172	PRESSURE CONTROLLER	UTC AEROSPACE
S210T120-182	PRESSURE CONTROLLER	UTC AEROSPACE
S210T120-222	PRESSURE CONTROLLER	UTC AEROSPACE
S210T120-232	PRESSURE CONTROLLER	UTC AEROSPACE
S210T120-242	PRESSURE CONTROLLER	UTC AEROSPACE
S210T130-19	DUCT AIR TEMPERATURE SENSOR	HONEYWELL
S210T130-75	DUCT AIR TEMPERATURE SENSOR	HONEYWELL
S210T160-42	CABIN PRESSURE SELECTOR	HONEYWELL
S210T160-52	CABIN PRESSURE SELECTOR	HONEYWELL
S210T160-62	CABIN PRESSURE SELECTOR	HONEYWELL
S210T160-72	CABIN PRESSURE SELECTOR	HONEYWELL
S210T170-12	NINE-INCH DIAMETER CHECK VALVE	HONEYWELL
S231A130-1	ELECTRONIC CLOCK	AVTECHTYEE
S231A130-2	ELECTRONIC CLOCK	AVTECHTYEE
S231T245-3	DUAL DUCT PRESSURE INDICATOR	AMETEK
S231T245-4	DUAL DUCT PRESSURE INDICATOR	AMETEK
S233T913-1	ANGLE OF ATTACK SENSOR	ROSEMOUNT
S233T913-2	ANGLE OF ATTACK SENSOR	CONRAC
S233T913-3	ANGLE OF ATTACK SENSOR	UTC AEROSPACE
S233T913-4	ANGLE OF ATTACK SENSOR	UTC AEROSPACE
S233T913-5	ANGLE OF ATTACK SENSOR	UTC AEROSPACE
S242T403-104	RDMI-743 RADIO DISTANCE MAGNETIC INDICATOR	ROCKWELL COLLINS
S242T403-106	RDMI-743 RADIO DISTANCE MAGNETIC INDICATOR	ROCKWELL COLLINS
S242T403-107	RDMI-743 RADIO DISTANCE MAGNETIC INDICATOR	ROCKWELL COLLINS
S242T403-108	RDMI-743 RADIO DISTANCE MAGNETIC INDICATOR	ROCKWELL COLLINS
S242T403-109	RDMI-743 RADIO DISTANCE MAGNETIC INDICATOR	ROCKWELL COLLINS
S242T403-110	RDMI-743 RADIO DISTANCE MAGNETIC INDICATOR	ROCKWELL COLLINS
S242T403-111	RDMI-743 RADIO DISTANCE MAGNETIC INDICATOR	ROCKWELL COLLINS
S242T403-112	RDMI-743 RADIO DISTANCE MAGNETIC INDICATOR	ROCKWELL COLLINS
S242T403-113	RDMI-743 RADIO DISTANCE MAGNETIC INDICATOR	ROCKWELL COLLINS
S242T403-114	RDMI-743 RADIO DISTANCE MAGNETIC INDICATOR	ROCKWELL COLLINS
S251N222-1 REV B	ROTARY VARIABLE DIFFERENTIAL TRANSFORMER	MPC PRODUCTS CORP
S251N222-2 REV C	ROTARY VARIABLE DIFFERENTIAL TRANSFORMER	MPC PRODUCTS CORP
S251N403-17	TRANSMITTER, FLAP POSITION	HONEYWELL
S251N403-18	TRANSMITTER, FLAP POSITION	HONEYWELL
S251T362-2	LINEAR TRANSDUCER RUDDER RATIO CHANGER	COLLINS
S256A404-50	FLAP POSITION SENSOR	HONEYWELL
S256A404-53	FLAP POSITION SENSOR	HONEYWELL
S271T452-1	HYDRAULIC PRESSURE SWITCH	EATON
S271T452-2	HYDRAULIC PRESSURE SWITCH	EATON
S271T452-3	HYDRAULIC PRESSURE SWITCH	EATON
S271T452-4	HYDRAULIC PRESSURE SWITCH	EATON
S271T452-5	HYDRAULIC PRESSURE SWITCH	EATON
S271T452-7	HYDRAULIC PRESSURE SWITCH	EATON

PART NUMBER	DESCRIPTION	OEM
S271T452-8	HYDRAULIC PRESSURE SWITCH	EATON
S271T452-9	HYDRAULIC PRESSURE SWITCH	EATON
S271T452-10	HYDRAULIC PRESSURE SWITCH	EATON
S271T452-11	HYDRAULIC PRESSURE SWITCH	EATON
S271T452-12	HYDRAULIC PRESSURE SWITCH	EATON
S271T452-13	HYDRAULIC PRESSURE SWITCH	EATON
S271T452-16	HYDRAULIC PRESSURE SWITCH	EATON
S271T452-17	HYDRAULIC PRESSURE SWITCH	EATON
S282T002-2	BATTERY CHARGER	CRANE ELDEC CORP
S282T002-4	BATTERY CHARGER	CRANE ELDEC CORP
S282T002-5	BATTERY CHARGER	CRANE ELDEC CORP
S282T002-6	BATTERY CHARGER	CRANE ELDEC CORP
S282T005-1	ISFD DEDICATED BATTERY/CHARGER (DBC)	ACME AEROSPACE
S283A313-103	REAR POSITION NAVIGATIONAL LIGHT	HONEYWELL
S283A317-1	LOGO LIGHT ASSEMBLY	KOITO
S283A317-2	LOGO LIGHT ASSEMBLY	KOITO
S283A321-1	RETRACTABLE LANDING LIGHT	HONEYWELL
S283A321-2	RETRACTABLE LANDING LIGHT	HONEYWELL
S283A321-3	RETRACTABLE LANDING LIGHT	HONEYWELL
S283A321-4	RETRACTABLE LANDING LIGHT	HONEYWELL
S283A321-5	RETRACTABLE LANDING LIGHT	HONEYWELL
S283A321-6	RETRACTABLE LANDING LIGHT	HONEYWELL
S283T008-15	LOGO LIGHT ASSEMBLY	KOITO
S283T008-16	LOGO LIGHT ASSEMBLY	KOITO
S283T008-17	LOGO LIGHT ASSEMBLY	KOITO
S283T008-18	LOGO LIGHT ASSEMBLY	KOITO
S283T008-33	LOGO FLOOD LIGHTS	GULTON
S283T008-34	LOGO FLOOD LIGHTS	GULTON
S283T008-35	LOGO FLOOD LIGHTS	GULTON
S283T008-36	LOGO FLOOD LIGHTS	GULTON
S283T008-75	LOGO LIGHT ASSEMBLY	KOITO
S283T008-76	LOGO LIGHT ASSEMBLY	KOITO
S283T014-2	BATTERY POWER SUPPLY	RADIANT POWER CORP
S283T014-3	BATTERY POWER SUPPLY	RADIANT POWER CORP
S283U008-16	ELECTRONIC BALLAST	AVTECHTYEE
S283U008-16 MOD A	ELECTRONIC BALLAST	AVTECHTYEE
S283W008-3	BATTERY AND CHARGER SYSTEM	RADIANT POWER CORP
S283W603-1	EMERGENCY POWER SUPPLY	PAGE AEROSPACE
S283W603-2	EMERGENCY POWER SUPPLY	PAGE AEROSPACE
S332T100-29	FIRE/OVERHEAT DETECTOR ASSEMBLY	MEGGITT
S332T100-30	FIRE/OVERHEAT DETECTOR ASSEMBLY	MEGGITT
S332T100-31	FIRE/OVERHEAT DETECTOR ASSEMBLY	MEGGITT
S332T100-38	FIRE/OVERHEAT DETECTOR ASSEMBLY	MEGGITT
S332T100-43	FIRE/OVERHEAT DETECTOR ASSEMBLY	MEGGITT
S332T100-44	FIRE/OVERHEAT DETECTOR ASSEMBLY	MEGGITT
S332T101-1	FIRE/OVERHEAT DETECTORS	KIDDE AEROSPACE
S332T101-2	FIRE/OVERHEAT DETECTORS	KIDDE AEROSPACE
S332T101-3	FIRE/OVERHEAT DETECTORS	KIDDE AEROSPACE
S332T101-4	FIRE/OVERHEAT DETECTORS	KIDDE AEROSPACE
S332T101-19	FIRE/OVERHEAT DETECTORS	KIDDE AEROSPACE
S332T101-19M	FIRE/OVERHEAT DETECTORS	KIDDE AEROSPACE
S332T101-20	FIRE/OVERHEAT DETECTORS	KIDDE AEROSPACE
S332T101-21	FIRE/OVERHEAT DETECTORS	KIDDE AEROSPACE
S332T101-22	FIRE/OVERHEAT DETECTORS	KIDDE AEROSPACE
S332T101-34	FIRE/OVERHEAT DETECTORS	KIDDE AEROSPACE
S332T101-35	FIRE/OVERHEAT DETECTORS	KIDDE AEROSPACE
S332T101-36	FIRE/OVERHEAT DETECTORS	KIDDE AEROSPACE
S332T101-38	FIRE/OVERHEAT DETECTORS	KIDDE AEROSPACE
S343T003-56	OPTO ELECTRONIC MOTOR OPERATED ACUTATOR ASSY	ITT AEROSPACE
S343T003-66	OPTO ELECTRONIC MOTOR OPERATED ACUTATOR ASSY	ITT AEROSPACE
S417N514-1	CEILING LIGHT	PAGE
S417N514-3	CEILING LIGHT	PAGE
S417N514-4	CEILING LIGHT	PAGE
S417N514-12	CEILING LIGHT	DIEHL AEROSPACE
S417N514-18	CEILING LIGHT	DIEHL AEROSPACE
S417N514-24	CEILING LIGHT	DIEHL AEROSPACE
S417N514-28	CEILING LIGHT	DIEHL AEROSPACE

PART NUMBER	DESCRIPTION	OEM
S417N514-48	CEILING LIGHT	DIEHL AEROSPACE
S417N514-58	CEILING LIGHT	DIEHL AEROSPACE
S417N514-70	CEILING LIGHT	DIEHL AEROSPACE
S417N514-301	CEILING LIGHT	DIEHL AEROSPACE
S417T105-7	LAVATORY DRAIN BALL VALVE ASSEMBLY	KAISER ELECTROPRECISION
S417T105-8	LAVATORY DRAIN BALL VALVE ASSEMBLY	KAISER ELECTROPRECISION
S417T600-7	WATER QUANTITY INDICATOR	AMETEK AEROSPACE
TD1514-1002	TOILET TIMER SWITCH	LEACH INTERNATIONAL
TD1535-1002	TOILET TIMER SWITCH	LEACH INTERNATIONAL
TD1702-1002	TOILET TIMER SWITCH	LEACH INTERNATIONAL
TD1715-1002	TOILET TIMER SWITCH	LEACH INTERNATIONAL
TSG420-102	STATIC INVERTER	THALES
U26A	RUDDER TRIM ACTUATOR	MPC PRODUCTS CORP
U26B	RUDDER TRIM ACTUATOR	MPC PRODUCTS CORP
U91A	ROTARY VARIABLE DIFFERENTIAL TRANSFORMER	MPC PRODUCTS CORP
U91B	ROTARY VARIABLE DIFFERENTIAL TRANSFORMER	MPC PRODUCTS CORP
VT061-2MODA	WATER QUANTITY TRANSMITTER	DIEHL AEROSPACE
VT061-2AMDTB	WATER QUANTITY TRANSMITTER	DIEHL AEROSPACE
VT061-2AMDTC	WATER QUANTITY TRANSMITTER	DIEHL AEROSPACE
WL101AMS1	ALTIMETER/AIRSPEED INDICATOR	GE AVIATION
WL101AMS2	ALTIMETER/AIRSPEED INDICATOR	GE AVIATION
WL101AMS5	ALTIMETER/AIRSPEED INDICATOR	GE AVIATION
WL101AMS6	ALTIMETER/AIRSPEED INDICATOR	GE AVIATION
WL101EED2	N1 PERCENTAGE RPM INDICATOR	GE AVIATION
WL101EED3	N1 PERCENTAGE RPM INDICATOR	GE AVIATION
WL102AMS1	ALTIMETER/AIRSPEED INDICATOR	GE AVIATION
WL102AMS2	ALTIMETER/AIRSPEED INDICATOR	GE AVIATION
WL102AMS3	ALTIMETER/AIRSPEED INDICATOR	GE AVIATION
WL102AMS4	ALTIMETER/AIRSPEED INDICATOR	GE AVIATION
WL102AMS5	ALTIMETER/AIRSPEED INDICATOR	GE AVIATION
WL102AMS6	ALTIMETER/AIRSPEED INDICATOR	GE AVIATION
WL201EED2	N2 PERCENTAGE RPM INDICATOR	GE AVIATION
WL202EED3	TEMPERATURE INDICATOR	GE AVIATION
WL202EED4	TEMPERATURE INDICATOR	GE AVIATION
WL202EED6	TEMPERATURE INDICATOR	GE AVIATION
WL501RC1	CABIN RATE OF CLIMB INDICATOR	GE AVIATION
WL502RC1	CABIN RATE OF CLIMB INDICATOR	GE AVIATION
WL503RC1	CABIN RATE OF CLIMB INDICATOR	GE AVIATION
001048-101	INSTRUMENT SWITCHING UNIT	BUTLER NAT'L CORP
0104244-001	LOGO FLOOD LIGHTS	GULTON
0104244-002	LOGO FLOOD LIGHTS	GULTON
0104244-003	LOGO FLOOD LIGHTS	GULTON
0104244-004	LOGO FLOOD LIGHTS	GULTON
011100-1	FORWARD POSITION LIGHT	BF GOODRICH
011100-2	FORWARD POSITION LIGHT	BF GOODRICH
0123CH1B	LOW FLOW DETECTOR	GOODRICH
0123FA2	LOW FLOW DETECTOR	UTC AEROSPACE
3980	DIMMING BALLAST	BRUCE INDUSTRIES
03980-5	DIMMING BALLAST	BRUCE INDUSTRIES
759980	DIMMING BALLAST	BRUCE INDUSTRIES
759981	DIMMING BALLAST	BRUCE INDUSTRIES
759982	DIMMING BALLAST	BRUCE INDUSTRIES
759983	DIMMING BALLAST	BRUCE INDUSTRIES
759986	DIMMING BALLAST	BRUCE INDUSTRIES
759994	DIMMING BALLAST	BRUCE INDUSTRIES
759998	DIMMING BALLAST	BRUCE INDUSTRIES
03980-10-501	DIMMING BALLAST	BRUCE INDUSTRIES
03980-108	DIMMING BALLAST	BRUCE INDUSTRIES
03980-20-1	DIMMING BALLAST	BRUCE INDUSTRIES
03980-20-2	DIMMING BALLAST	BRUCE INDUSTRIES
03980-20-3	DIMMING BALLAST	BRUCE INDUSTRIES
03980-20-4	DIMMING BALLAST	BRUCE INDUSTRIES
03980-20-6	DIMMING BALLAST	BRUCE INDUSTRIES
03980-20-16	DIMMING BALLAST	BRUCE INDUSTRIES
03980-20-19	DIMMING BALLAST	BRUCE INDUSTRIES
03980-20-501	DIMMING BALLAST	BRUCE INDUSTRIES
03980-208	DIMMING BALLAST	BRUCE INDUSTRIES

PART NUMBER	DESCRIPTION	OEM
03980-30-1	DIMMING BALLAST	BRUCE INDUSTRIES
03980-30-2	DIMMING BALLAST	BRUCE INDUSTRIES
03980-30-3	DIMMING BALLAST	BRUCE INDUSTRIES
03980-30-4	DIMMING BALLAST	BRUCE INDUSTRIES
03980-30-9	DIMMING BALLAST	BRUCE INDUSTRIES
03980-30-17	DIMMING BALLAST	BRUCE INDUSTRIES
03980-30-19	DIMMING BALLAST	BRUCE INDUSTRIES
03980-30-501	DIMMING BALLAST	BRUCE INDUSTRIES
03980-40-1	DIMMING BALLAST	BRUCE INDUSTRIES
03980-40-2	DIMMING BALLAST	BRUCE INDUSTRIES
03980-40-3	DIMMING BALLAST	BRUCE INDUSTRIES
03980-40-4	DIMMING BALLAST	BRUCE INDUSTRIES
03980-40-10	DIMMING BALLAST	BRUCE INDUSTRIES
03980-40-18	DIMMING BALLAST	BRUCE INDUSTRIES
03980-40-19	DIMMING BALLAST	BRUCE INDUSTRIES
03980-40-501	DIMMING BALLAST	BRUCE INDUSTRIES
03980-50	DIMMING BALLAST	BRUCE INDUSTRIES
03980-50-1	DIMMING BALLAST	BRUCE INDUSTRIES
03980-50-3	DIMMING BALLAST	BRUCE INDUSTRIES
03980-50-11	DIMMING BALLAST	BRUCE INDUSTRIES
03980-60	DIMMING BALLAST	BRUCE INDUSTRIES
03980-60-3	DIMMING BALLAST	BRUCE INDUSTRIES
03980-60-12	DIMMING BALLAST	BRUCE INDUSTRIES
03980-60-70	DIMMING BALLAST	BRUCE INDUSTRIES
03980-601	DIMMING BALLAST	BRUCE INDUSTRIES
03980-601-20	NON-DIMMING BALLAST	BRUCE INDUSTRIES
045000-1	LIGHT ASSEMBLY, WHEEL WELL	BFGOODRICH
046-55	HEADPHONE / HEADSET	SENNHEISER
046-55-999-0131	HEADPHONE / HEADSET	SENNHEISER
046-55-999-0141	HEADPHONE / HEADSET	SENNHEISER
046-55-999-0231	HEADPHONE / HEADSET	SENNHEISER
046-55-999-0831	HEADPHONE / HEADSET	SENNHEISER
046-69	HEADPHONE / HEADSET	SENNHEISER
046-69-999-0831	HEADPHONE / HEADSET	SENNHEISER
046-69-999-0931	HEADPHONE / HEADSET	SENNHEISER
4847	BALLAST, STEP DIMMING	BRUCE INDUSTRIES
04847-10	BALLAST, STEP DIMMING	BRUCE INDUSTRIES
04847-20	BALLAST, STEP DIMMING	BRUCE INDUSTRIES
04847-30	BALLAST, STEP DIMMING	BRUCE INDUSTRIES
04847-40	BALLAST, STEP DIMMING	BRUCE INDUSTRIES
0513AB1	ICE DETECTION SYSTEM	UTC AEROSPACE
0513AB2	ICE DETECTION SYSTEM	UTC AEROSPACE
0513AB2-1	ICE DETECTION SYSTEM	UTC AEROSPACE
0513AB2-1 MOD A	ICE DETECTION SYSTEM	UTC AEROSPACE
05939-3	FLUORESCENT LAMP BALLAST	BRUCE INDUSTRIES
05939-103	FLUORESCENT LAMP BALLAST	BRUCE INDUSTRIES
080-20325-01	TRANSFORMER-RECTIFIER POWER SUPPLY	OECO / MEGGITT
0851CM	PITOT TUBE	ROSEMOUNT
0851CM-2	PITOT TUBE	ROSEMOUNT
0851HF	PITOT TUBE	GOODRICH
0851HF-1	PITOT TUBE	GOODRICH
0851T	PITOT TUBE	ROSEMOUNT
0856AE7	PITOT-STATIC TUBE	UTC AEROSPACE
0856AE8	PITOT-STATIC TUBE	UTC AEROSPACE
0856AE12	PITOT-STATIC TUBE	UTC AEROSPACE
0856AE13	PITOT-STATIC TUBE	UTC AEROSPACE
0856AE14	PITOT-STATIC TUBE	UTC AEROSPACE
0856AE15	PITOT-STATIC TUBE	UTC AEROSPACE
0856AE16	PITOT-STATIC TUBE	UTC AEROSPACE
0856AE17	PITOT-STATIC TUBE	UTC AEROSPACE
0856AE18	PITOT-STATIC TUBE	UTC AEROSPACE
0856AE19	PITOT-STATIC TUBE	UTC AEROSPACE
0856CC9	PITOT-STATIC TUBE	UTC AEROSPACE
0856CC10	PITOT-STATIC TUBE	UTC AEROSPACE
0856CC11	PITOT-STATIC TUBE	UTC AEROSPACE
0856CC12	PITOT-STATIC TUBE	UTC AEROSPACE
0856CC13	PITOT-STATIC TUBE	UTC AEROSPACE

PART NUMBER	DESCRIPTION	OEM
0856CC14	PITOT-STATIC TUBE	UTC AEROSPACE
0856KB7	PITOT-STATIC TUBE	UTC AEROSPACE
0856KB8	PITOT-STATIC TUBE	UTC AEROSPACE
0856KB9	PITOT-STATIC TUBE	UTC AEROSPACE
0856KB10	PITOT-STATIC TUBE	UTC AEROSPACE
0856KV9	PITOT-STATIC TUBE	UTC AEROSPACE
0856KV10	PITOT-STATIC TUBE	UTC AEROSPACE
0856LU1	PITOT-STATIC TUBE	UTC AEROSPACE
0856LU2	PITOT-STATIC TUBE	UTC AEROSPACE
0856LU3	PITOT-STATIC TUBE	UTC AEROSPACE
0856LU4	PITOT-STATIC TUBE	UTC AEROSPACE
0856LU5	PITOT-STATIC TUBE	UTC AEROSPACE
0856LU6	PITOT-STATIC TUBE	UTC AEROSPACE
0856LU9	PITOT-STATIC TUBE	UTC AEROSPACE
0856LU10	PITOT-STATIC TUBE	UTC AEROSPACE
0856RE3	PITOT-STATIC TUBE	UTC AEROSPACE
0856RE4	PITOT-STATIC TUBE	UTC AEROSPACE
0856RE5	PITOT-STATIC TUBE	UTC AEROSPACE
0856RE6	PITOT-STATIC TUBE	UTC AEROSPACE
0856WB1	PITOT-STATIC TUBE	UTC AEROSPACE
0856WB2	PITOT-STATIC TUBE	UTC AEROSPACE
0861DR	ANGLE OF ATTACK SENSOR	UTC AEROSPACE
0861FL	ANGLE OF ATTACK SENSOR	UTC AEROSPACE
0861FL1	ANGLE OF ATTACK SENSOR	UTC AEROSPACE
0871BN3-3	ICE DETECTOR	ROSEMOUNT
0871BN3-4	ICE DETECTOR	UTC AEROSPACE
0871BN3-5	ICE DETECTOR	ROSEMOUNT
0871BN3-8	ICE DETECTOR	UTC AEROSPACE
0871BN8	ICE DETECTOR	GOODRICH
0871BN8-1	ICE DETECTOR	GOODRICH
0871DP3	ICE DETECTOR	ROSEMOUNT
0871DP4	ICE DETECTOR	UTC AEROSPACE
0871GD1	ICE DETECTION SYSTEM	UTC AEROSPACE
0871HY5	ICE DETECTOR	ROSEMOUNT
0871HY5 MOD 1	ICE DETECTOR	ROSEMOUNT
0871HY6	ICE DETECTOR	ROSEMOUNT
088-515-1031-X	INDICATOR LIGHT ASSEMBLY	KORRY MANUF
1A081-0157-12	HEATER ASSEMBLY – WATER	YOKOHAMA
1D600-1A-MD-0752	STATIC INVERTER	AVIONIC INSTRUMENTS
10000165-101	ANGLE OF ATTACK/SIDESLIP TRANSMITTER ASSY	TELEDYNE CONTROLS
100-0211-01	BATTERY CHARGER MODEL BC-1301	SECUREAPLANE
100-0211-03	BATTERY CHARGER MODEL BC-1301	SECUREAPLANE
10-0067-7	EMERGENCY EXIT LIGHT	HONEYWELL
10-0067-9	EMERGENCY EXIT LIGHT	HONEYWELL
100-1084-01	BC-1306 BATTERY CHARGER	SECUREAPLANE
10-0119-1	EMERGENCY EXIT LIGHT	HONEYWELL
10-0119-3	EMERGENCY EXIT LIGHT	HONEYWELL
1-002-0102-0752	STATIC INVERTER	AVIONIC INSTRUMENTS
10031-0000-01	ENGINE OIL QUANTITY INDICATOR	BFGOODRICH
10033-0000-02	HYDRAULIC OIL QUANTITY INDICATOR	BFGOODRICH
10034-0000-02	HYDRAULIC OIL QUANTITY INDICATOR	BFGOODRICH
10051-0000-01	ENGINE OIL QUANTITY INDICATOR	BFGOODRICH
10065-3000-01	PRESELECT CONTROL UNIT (PCU)	UTC AEROSPACE SYSTE
10065-3000-02	PRESELECT CONTROL UNIT (PCU)	UTC AEROSPACE SYSTE
100865	BATTERY POWER SUPPLY	BRUCE INDUSTRIES
10117N01N00	STABILO TRIM INDICATOR	AMETEK
10-1352-1	FLUORESCENT CEILING LIGHT	GRIMES AEROSPACE
10-1352-3	FLUORESCENT CEILING LIGHT	GRIMES AEROSPACE
10-1352-4	FLUORESCENT CEILING LIGHT	GRIMES AEROSPACE
10166N01N00	RUDDER TRIM INDICATOR ASSEMBLY	AMETEK
10168N01T00	INTERTURBINE TEMP INDICATOR ASSY	AMETEK
10170N01R00	NH% RPM INDICATOR	AMETEK
10175N01T00	INTERTURBINE TEMP INDICATOR ASSY	AMETEK
10177N01R00	NH% RPM INDICATOR	AMETEK
1019439-1-001	PRESSURE SELECTOR PANEL PSL105-1	UTC AEROSPACE
102LA2AG	TOTAL TEMPERATURE SENSOR	UTC AEROSPACE
102-00000	TEMPERATURE SENSOR	ESTERLINE NORWICH

PART NUMBER	DESCRIPTION	OEM
102200-246	FLIGHT ENGINEER'S ANNUNCIATOR	DOUGLAS AIRCRAFT CO
102200-247	FLIGHT ENGINEER'S ANNUNCIATOR	DOUGLAS AIRCRAFT CO
102200-248	FLIGHT ENGINEER'S ANNUNCIATOR	DOUGLAS AIRCRAFT CO
102200-249	FLIGHT ENGINEER'S ANNUNCIATOR	DOUGLAS AIRCRAFT CO
102200-250	FLIGHT ENGINEER'S ANNUNCIATOR	DOUGLAS AIRCRAFT CO
102200-251	FLIGHT ENGINEER'S ANNUNCIATOR	DOUGLAS AIRCRAFT CO
102200-252	FLIGHT ENGINEER'S ANNUNCIATOR	DOUGLAS AIRCRAFT CO
102200-253	FLIGHT ENGINEER'S ANNUNCIATOR	DOUGLAS AIRCRAFT CO
102200-254	FLIGHT ENGINEER'S ANNUNCIATOR	DOUGLAS AIRCRAFT CO
102200-255	FLIGHT ENGINEER'S ANNUNCIATOR	DOUGLAS AIRCRAFT CO
102200-256	FLIGHT ENGINEER'S ANNUNCIATOR	DOUGLAS AIRCRAFT CO
102200-257	FLIGHT ENGINEER'S ANNUNCIATOR	DOUGLAS AIRCRAFT CO
102200-258	FLIGHT ENGINEER'S ANNUNCIATOR	DOUGLAS AIRCRAFT CO
102200-259	FLIGHT ENGINEER'S ANNUNCIATOR	DOUGLAS AIRCRAFT CO
102200-260	FLIGHT ENGINEER'S ANNUNCIATOR	DOUGLAS AIRCRAFT CO
102200-261	FLIGHT ENGINEER'S ANNUNCIATOR	DOUGLAS AIRCRAFT CO
102200-262	FLIGHT ENGINEER'S ANNUNCIATOR	DOUGLAS AIRCRAFT CO
102200-263	FLIGHT ENGINEER'S ANNUNCIATOR	DOUGLAS AIRCRAFT CO
102200-264	FLIGHT ENGINEER'S ANNUNCIATOR	DOUGLAS AIRCRAFT CO
102200-265	FLIGHT ENGINEER'S ANNUNCIATOR	DOUGLAS AIRCRAFT CO
102200-266	FLIGHT ENGINEER'S ANNUNCIATOR	DOUGLAS AIRCRAFT CO
102200-267	FLIGHT ENGINEER'S ANNUNCIATOR	DOUGLAS AIRCRAFT CO
102200-268	FLIGHT ENGINEER'S ANNUNCIATOR	DOUGLAS AIRCRAFT CO
102200-269	FLIGHT ENGINEER'S ANNUNCIATOR	DOUGLAS AIRCRAFT CO
102200-270	FLIGHT ENGINEER'S ANNUNCIATOR	DOUGLAS AIRCRAFT CO
102200-271	FLIGHT ENGINEER'S ANNUNCIATOR	DOUGLAS AIRCRAFT CO
102200-272	FLIGHT ENGINEER'S ANNUNCIATOR	DOUGLAS AIRCRAFT CO
102200-273	FLIGHT ENGINEER'S ANNUNCIATOR	DOUGLAS AIRCRAFT CO
102200-274	FLIGHT ENGINEER'S ANNUNCIATOR	DOUGLAS AIRCRAFT CO
102200-275	FLIGHT ENGINEER'S ANNUNCIATOR	DOUGLAS AIRCRAFT CO
102200-276	FLIGHT ENGINEER'S ANNUNCIATOR	DOUGLAS AIRCRAFT CO
102200-277	FLIGHT ENGINEER'S ANNUNCIATOR	DOUGLAS AIRCRAFT CO
102200-280	FLIGHT ENGINEER'S ANNUNCIATOR	DOUGLAS AIRCRAFT CO
102200-281	FLIGHT ENGINEER'S ANNUNCIATOR	DOUGLAS AIRCRAFT CO
10-2638-4	ALTITUDE PRESSURE SWITCH	EATON AEROSPACE
10-3257-3	TRANSFORMER-RECTIFIER, 50 AMP, UNREGULATED	CRANE / ELDEC
10486N01Y00	WATER QUANTITY INDICATOR	AMETEK AEROSPACE
105846-1	HEATER ASSEMBLY	ELECTROFILM MFG CO
10-60091-101	EMERGENCY EXIT LIGHT	HONEYWELL
10-60091-102	EMERGENCY EXIT LIGHT	HONEYWELL
10-60554-31	HYDRAULIC OIL QUANTITY INDICATOR	BFGOODRICH
10-60554-32	HYDRAULIC OIL QUANTITY INDICATOR	BFGOODRICH
10-60554-40	HYDRAULIC OIL QUANTITY TRANSMITTER	UTC AEROSPACE
10-60554-41	HYDRAULIC OIL QUANTITY TRANSMITTER	UTC AEROSPACE
10-60702-3	PITOT TUBES	ROSEMOUNT
10-60702-4	PITOT TUBES	ROSEMOUNT
10-60702-5	PITOT TUBES	ROSEMOUNT
10-60722-8	ENGINE OIL QUANTITY INDICATOR	BFGOODRICH
10-60722-11	LIQUID QUANTITY ENGINE OIL TRANSMITTER	BFGOODRICH
10-60722-13	ENGINE OIL QUANTITY INDICATOR	BFGOODRICH
10-60737-14	ENGINE PRESSURE RATIO INDICATOR	GE AVIATION
10-60737-16	ENGINE PRESSURE RATIO INDICATOR	GE AVIATION
10-60752	FLUORESCENT LAMP BALLASTS	DAY-RAY PRODUCTS
10-60757-22	AC VOLTMETER	ROGERSON KRATOS
10-60757-23	DC VOLTMETER	ROGERSON KRATOS
10-60757-24	DC AMMETER	ROGERSON KRATOS
10-60757-28	INDICATOR, TEMPATURE	ROGERSON KRATOS
10-60757-144	DC AMMETER	ROGERSON KRATOS
10-60772-4	AURAL WARNING DEVICE	FARADAY, INC.
10-61096-41	CONTROL MODULE, ENGINE FIRE & OVERHEAT & APU FIRE	KIDDE AEROSPACE
10-61096-54	FIRE/OVERHEAT DETECTOR ASSEMBLY	MEGGITT
10-61096-55	FIRE/OVERHEAT DETECTOR ASSEMBLY	MEGGITT
10-61096-56	FIRE/OVERHEAT DETECTOR ASSEMBLY	MEGGITT
10-61096-57	FIRE/OVERHEAT DETECTOR ASSEMBLY	MEGGITT
10-61096-58	FIRE/OVERHEAT DETECTOR ASSEMBLY	MEGGITT
10-61096-71	CONTROL MODULE, ENGINE FIRE & OVERHEAT & APU FIRE	KIDDE AEROSPACE
10-61096-81	CONTROL MODULE, ENGINE FIRE & OVERHEAT & APU FIRE	KIDDE AEROSPACE

PART NUMBER	DESCRIPTION	OEM
10-61096-91	CONTROL MODULE, ENGINE FIRE & OVERHEAT & APU FIRE	KIDDE AEROSPACE
10-61096-92	CONTROL MODULE, ENGINE FIRE & OVERHEAT & APU FIRE	KIDDE AEROSPACE
10-61096-93	CONTROL MODULE, ENGINE FIRE & OVERHEAT & APU FIRE	KIDDE AEROSPACE
10-61096-94	CONTROL MODULE, ENGINE FIRE & OVERHEAT & APU FIRE	KIDDE AEROSPACE
10-61096-95	CONTROL MODULE, ENGINE FIRE & OVERHEAT & APU FIRE	KIDDE AEROSPACE
10-61096-96	CONTROL MODULE, ENGINE FIRE & OVERHEAT & APU FIRE	KIDDE AEROSPACE
10-61096-97	CONTROL MODULE, ENGINE FIRE & OVERHEAT & APU FIRE	KIDDE AEROSPACE
10-61224-4	BUS PROTECTION PANEL	UTC AEROSPACE
10-61224-21	GENERATOR CONTROL UNIT (GCU)	UTC AEROSPACE
10-61255-1	HYDRAULIC PRESSURE TRANSMITTER	ROGERSON KRATOS
10-61255-24	HYDRAULIC PRESSURE TRANSMITTER	ROGERSON KRATOS
10-61255-32	HYDRAULIC PRESSURE TRANSMITTER	ROGERSON KRATOS
10-61255-33	HYDRAULIC PRESSURE TRANSMITTER	ROGERSON KRATOS
10-61329-31	WINDSHIELD WIPER MOTOR CONVERTER ASSY	UTC AEROSPACE
10-61329-32	WINDSHIELD WIPER MOTOR CONVERTER ASSY	UTC AEROSPACE
10-61329-37	WINDSHIELD WIPER MOTOR CONVERTER ASSY	UTC AEROSPACE
10-61329-38	WINDSHIELD WIPER MOTOR CONVERTER ASSY	UTC AEROSPACE
10-61329-39	WINDSHIELD WIPER MOTOR CONVERTER ASSY	UTC AEROSPACE
10-61329-40	WINDSHIELD WIPER MOTOR CONVERTER ASSY	UTC AEROSPACE
10-61329-41	WINDSHIELD WIPER MOTOR CONVERTER ASSY	UTC AEROSPACE
10-61329-42	WINDSHIELD WIPER MOTOR CONVERTER ASSY	UTC AEROSPACE
10-61330-1	INDICATOR LIGHT ASSEMBLY	HONEYWELL
10-61330-2	INDICATOR LIGHT ASSEMBLY	HONEYWELL
10-61330-13	INDICATOR LIGHT ASSEMBLY	HONEYWELL
10-61330-19	INDICATOR LIGHT ASSEMBLY	HONEYWELL
10-61330-25	INDICATOR LIGHT ASSEMBLY	HONEYWELL
10-61330-26	INDICATOR LIGHT ASSEMBLY	HONEYWELL
10-61330-53	INDICATOR LIGHT ASSEMBLY	HONEYWELL
10-61330-54	INDICATOR LIGHT ASSEMBLY	HONEYWELL
10-61330-60	INDICATOR LIGHT ASSEMBLY	HONEYWELL
10-61330-61	INDICATOR LIGHT ASSEMBLY	HONEYWELL
10-61330-64	INDICATOR LIGHT ASSEMBLY	HONEYWELL
10-61383-1	WATER QUANTITY TRANSMITTER	KAISER AEROSPACE
10-61383-3	WATER QUANTITY TRANSMITTER	KAISER AEROSPACE
10-61826-8	SERVOED ALTITUDE INDICATOR	GE AVIATION
10-61826-10	SERVOED ALTITUDE INDICATOR	GE AVIATION
10-61833-1	WINDOW HEAT CONTROL	KOITO
10-61833-2	WINDOW HEAT CONTROL	KOITO
10-61833-3	WINDOW HEAT CONTROL	KOITO
10-61926-1	FLAP POSITION INDICATOR	GE AVIATION
10-61926-2	FLAP POSITION INDICATOR	GE AVIATION
10-61926-3	FLAP POSITION INDICATOR	GE AVIATION
10-61926-4	FLAP POSITION INDICATOR	GE AVIATION
10-62025-1	RUDDER TRIM ACTUATOR	MPC PRODUCTS CORP
10-62025-3	RUDDER TRIM ACTUATOR	MPC PRODUCTS CORP
10-62031-1	N2 PERCENTAGE RPM INDICATOR	GE AVIATION
10-62032-2	TEMPERATURE INDICATOR	GE AVIATION
10-62032-3	TEMPERATURE INDICATOR	GE AVIATION
10-62032-5	TEMPERATURE INDICATOR	GE AVIATION
10-62035-2	RUDDER TRIM INDICATOR ASSEMBLY	AMETEK
10-62044-001	CONTROL DISPLAY UNIT	GE AVIATION
10-62058-5	FLIGHT MODE ANNUNCIATOR	PAGE ENGINEERING
10-62067-1	VIBRATION MONITOR INDICATOR	AMETEK
10-62090-30	COCKPIT SPEAKER ASSEMBLY	AVTECH
10-62090-31	COCKPIT SPEAKER ASSEMBLY	AVTECH
10-62090-42	AUDIO CONTROL PANEL	AVTECH
10-62090-64	AUDIO CONTROL PANEL	AVTECHTYEE
10-62090-66	AUDIO CONTROL PANEL	AVTECH
10-62090-69	AUDIO CONTROL PANEL	AVTECH
10-62090-75	COCKPIT SPEAKER ASSEMBLY	AVTECH
10-62178-202	EIS SECONDARY DISPLAY PANEL	GE AVIATION
10-62231-1	PRESSURE SELECTOR PANEL	UTC AEROSPACE
10-62231-2	PRESSURE CONTROLLER	NORD-MICRO
10-62231-11	PRESSURE SELECTOR PANEL PSL105-1	UTC AEROSPACE
10-62231-12	PRESSURE CONTROLLER	NORD-MICRO
10-62231-21	PRESSURE SELECTOR PANEL PSL105-1	UTC AEROSPACE
10-62231-22	PRESSURE CONTROLLER	NORD-MICRO

PART NUMBER	DESCRIPTION	OEM
10-62231-32	PRESSURE CONTROLLER	NORD-MICRO
10-62231-42	PRESSURE CONTROLLER	NORD-MICRO
10-62231-52	PRESSURE CONTROLLER	NORD-MICRO
107C800-21	MICROPHONE ASSEMBLY	TELEPHONICS
107C800-22	MICROPHONE ASSEMBLY	TELEPHONICS
107C800-23	MICROPHONE ASSEMBLY	TELEPHONICS
107C800-24	MICROPHONE ASSEMBLY	TELEPHONICS
107C800-25	MICROPHONE ASSEMBLY	TELEPHONICS
107C800-26	MICROPHONE ASSEMBLY	TELEPHONICS
107484-2	HIGH STAGE REGULATOR	HONEYWELL
107484-3	HIGH STAGE REGULATOR	HONEYWELL
107484-4	HIGH STAGE REGULATOR	HONEYWELL
107484-5	HIGH STAGE REGULATOR	HONEYWELL
107484-6	HIGH STAGE REGULATOR	HONEYWELL
107484-7	HIGH STAGE REGULATOR	HONEYWELL
11050-11	COFFEE MAKER ASSEMBLY	BE AEROSPACE
11225-1	COFFEE MAKER ASSEMBLY	BE AEROSPACE
1122514	RESISTANCE BULB	BE AEROSPACE
11225-3	COFFEE MAKER ASSEMBLY	BE AEROSPACE
11225-31	COFFEE MAKER ASSEMBLY	BE AEROSPACE
11276-3	COFFEE MAKER/WATER BOILER ASSEMBLY	ROGERSON KRATOS
114.114	VALVE POSITION INDICATOR	ROGERSON KRATOS
114-114	VALVE POSITION INDICATOR	ROGERSON KRATOS
114.114-1	VALVE POSITION INDICATOR	ROGERSON KRATOS
114-114-1	VALVE POSITION INDICATOR	ROGERSON KRATOS
114.115	VALVE POSITION INDICATOR	ROGERSON KRATOS
114-115	VALVE POSITION INDICATOR	ROGERSON KRATOS
114.115-1	VALVE POSITION INDICATOR	ROGERSON KRATOS
114-115-1	VALVE POSITION INDICATOR	KAISER AEROSPACE
1145-0015	WATER QUANTITY TRANSMITTER	KAISER AEROSPACE
1145-0035	WATER QUANTITY TRANSMITTER	HONEYWELL
1152682-1	BEACON	HONEYWELL
1152682-2	ELT SYSTEM	HONEYWELL
1152682-3	ELT SYSTEM	ITT AEROSPACE
1163P0041	DIFFERENTIAL PRESSURE SWITCH	ITT AEROSPACE
1173T0640	TEMPERATURE SWITCH	ITT NEO-DYN
1173T10-1	TEMPERATURE SWITCH	ITT AEROSPACE
1173T211	TEMPERATURE SWITCH	ITT AEROSPACE
1173T234	TEMPERATURE SWITCH	ITT AEROSPACE
1201-01-00	COFFEE MAKER DA12 SERIES	BE AEROSPACE
1225P6-1	PRESSURE SWITCH	ITT AEROSPACE
123CH1A	LOW FLOW DETECTOR	GOODRICH
12411-0-221F	MIDGET THERMOSWITCH UNIT LINE	FENWAL SAFETY SYS
12411-0-239F	MIDGET THERMOSWITCH UNIT LINE	FENWAL SAFETY SYS
12411-0-250F	MIDGET THERMOSWITCH UNIT LINE	FENWAL SAFETY SYS
12411-14-275F	MIDGET THERMOSWITCH UNIT LINE	FENWAL SAFETY SYS
12411-2-230F	MIDGET THERMOSWITCH UNIT LINE	FENWAL SAFETY SYS
12411-2-237F	MIDGET THERMOSWITCH UNIT LINE	FENWAL SAFETY SYS
12411-2-250F	MIDGET THERMOSWITCH UNIT LINE	FENWAL SAFETY SYS
12411-2-450F	MIDGET THERMOSWITCH UNIT LINE	FENWAL SAFETY SYS
124.133	DC AMMETER	ROGERSON KRATOS
124.832	AC VOLTMETER	ROGERSON KRATOS
124.833	DC VOLTMETER	ROGERSON KRATOS
124.834	DC AMMETER	ROGERSON KRATOS
124.838	INDICATOR, TEMPERATURE	ROGERSON KRATOS
1266-100	DIFFERENTIAL PRESSURE SWITCH	ZODIAC AEROSPACE
128941-001	ASSEMBLY SELECTOR	LUCAS LEDEX
129112-1-1	PNEUMATIC ANTICIPATOR	HONEYWELL
130476-1	CABIN AIR PRESSURE SELECTOR	HONEYWELL
130476-2	CABIN AIR PRESSURE SELECTOR	HONEYWELL
130476-3	CABIN AIR PRESSURE SELECTOR	HONEYWELL
130476-4	CABIN AIR PRESSURE SELECTOR	HONEYWELL
130476-5	CABIN AIR PRESSURE SELECTOR	HONEYWELL
130476-6	CABIN AIR PRESSURE SELECTOR	HONEYWELL
130476-7	CABIN AIR PRESSURE SELECTOR	HONEYWELL
130476-8	CABIN AIR PRESSURE SELECTOR	HONEYWELL
130502-4	CABIN PRESSURE SELECTOR	HONEYWELL

PART NUMBER	DESCRIPTION	OEM
130502-5	CABIN PRESSURE SELECTOR	HONEYWELL
130502-6	CABIN PRESSURE SELECTOR	HONEYWELL
130502-7	CABIN PRESSURE SELECTOR	HONEYWELL
130590-1	CABIN AIR PRESSURE SELECTOR	HONEYWELL
130590-2	CABIN AIR PRESSURE SELECTOR	HONEYWELL
130590-3	CABIN AIR PRESSURE SELECTOR	HONEYWELL
130590-4	CABIN AIR PRESSURE SELECTOR	HONEYWELL
1335M77P02	FUEL PRESSURE TRANSMITTER	EDISON
1338-1450	WHEEL PRESSURE TRANSDUCER	SAFRAN MESSIER
1400-01-00	COFFEE MAKER DA14 SERIES	B/E AEROSPACE
1401-01-00	COFFEE MAKER DA14 SERIES	B/E AEROSPACE
14300-330	LOGIC CONTROL UNIT	MONOGRAM
14300-335	LEVEL SENSOR	MONOGRAM
14312-026	DRAIN VALVE ASSEMBLY	ZODIAC MONOGRAM
14312-046	DRAIN VALVE ASSEMBLY	ZODIAC MONOGRAM
14312-076	DRAIN VALVE ASSEMBLY	ZODIAC MONOGRAM
14312-078	DRAIN VALVE ASSEMBLY	ZODIAC MONOGRAM
14312-079	DRAIN VALVE ASSEMBLY	ZODIAC MONOGRAM
14312-080	DRAIN VALVE ASSEMBLY	ZODIAC MONOGRAM
14330-044	FLUSH CONTROL UNIT	ZODIAC MONOGRAM
14330-144	FLUSH CONTROL UNIT	ZODIAC MONOGRAM
14330-344	FLUSH CONTROL UNIT	ZODIAC MONOGRAM
14400-359NP	FLUSH CONTROL UNIT	ZODIAC MONOGRAM
14400-359-10NP	FLUSH CONTROL UNIT	ZODIAC MONOGRAM
149270-01-01	ENGINE PRESSURE RATIO LIMIT INDICATOR	SMITHS
149270-02-01	ENGINE PRESSURE RATIO LIMIT INDICATOR	SMITHS
149270-03-01	ENGINE PRESSURE RATIO LIMIT INDICATOR	SMITHS
149270-04-01	ENGINE PRESSURE RATIO LIMIT INDICATOR	SMITHS
149270-05-01	ENGINE PRESSURE RATIO LIMIT INDICATOR	SMITHS
15-0069-1	SPOTLIGHT	HONEYWELL
15-0069-3	SPOTLIGHT	HONEYWELL
15-0069-5	SPOTLIGHT	HONEYWELL
15-0069-13	SPOTLIGHT	HONEYWELL
15-0069-15	SPOTLIGHT	HONEYWELL
15-0069-17	SPOTLIGHT	HONEYWELL
15-0069-19	SPOTLIGHT	HONEYWELL
15-0069-21	SPOTLIGHT	HONEYWELL
15-0069-23	SPOTLIGHT	HONEYWELL
15-0069-25	SPOTLIGHT	HONEYWELL
15-0188-1	DOME LIGHT	HONEYWELL
15-0188-5	DOME LIGHT	HONEYWELL
15-0188-7	DOME LIGHT	HONEYWELL
15-0188-9	DOME LIGHT	HONEYWELL
15-0188-11	DOME LIGHT	HONEYWELL
15-0188-13	DOME LIGHT	HONEYWELL
15-0188-15	DOME LIGHT	HONEYWELL
15-0306-1	CARGO FREIGHTER CEILING LIGHT ASSEMBLY	HONEYWELL
15-0306-3	CARGO FREIGHTER CEILING LIGHT ASSEMBLY	HONEYWELL
15-0306-5	CARGO FREIGHTER CEILING LIGHT ASSEMBLY	HONEYWELL
15-0306-7	CARGO FREIGHTER CEILING LIGHT ASSEMBLY	HONEYWELL
15-0306-9	CARGO FREIGHTER CEILING LIGHT ASSEMBLY	HONEYWELL
15-0306-11	CARGO FREIGHTER CEILING LIGHT ASSEMBLY	HONEYWELL
152BL702	THERMOCOUPLE TEMP INDICATORS, INTEGRALLY LIGHTED	HORIZON AEROSPACE
152BL702A	THERMOCOUPLE TEMP INDICATORS, INTEGRALLY LIGHTED	HORIZON AEROSPACE
152BL702C	THERMOCOUPLE TEMP INDICATORS, INTEGRALLY LIGHTED	HORIZON AEROSPACE
152BL702D	THERMOCOUPLE TEMP INDICATORS, INTEGRALLY LIGHTED	HORIZON AEROSPACE
152BL702E	THERMOCOUPLE TEMP INDICATORS, INTEGRALLY LIGHTED	HORIZON AEROSPACE
152BL703	THERMOCOUPLE TEMP INDICATORS, INTEGRALLY LIGHTED	HORIZON AEROSPACE
152BL704	THERMOCOUPLE TEMP INDICATORS, INTEGRALLY LIGHTED	HORIZON AEROSPACE
152BL705A	THERMOCOUPLE TEMP INDICATORS, INTEGRALLY LIGHTED	LEWIS ENGINEERING
152BL705E	THERMOCOUPLE TEMP INDICATORS, INTEGRALLY LIGHTED	LEWIS ENGINEERING
152BL705F	THERMOCOUPLE TEMP INDICATORS, INTEGRALLY LIGHTED	LEWIS ENGINEERING
152BL705G	THERMOCOUPLE TEMP INDICATORS, INTEGRALLY LIGHTED	LEWIS ENGINEERING
152BL705H	THERMOCOUPLE TEMP INDICATORS, INTEGRALLY LIGHTED	LEWIS ENGINEERING
152BL705J	THERMOCOUPLE TEMP INDICATORS, INTEGRALLY LIGHTED	LEWIS ENGINEERING
152BL705L	THERMOCOUPLE TEMP INDICATORS, INTEGRALLY LIGHTED	LEWIS ENGINEERING
152BL705N	THERMOCOUPLE TEMP INDICATORS, INTEGRALLY LIGHTED	LEWIS ENGINEERING

PART NUMBER	DESCRIPTION	OEM
152BL705P	THERMOCOUPLE TEMP INDICATORS, INTEGRALLY LIGHTED	LEWIS ENGINEERING
152BL705R	THERMOCOUPLE TEMP INDICATORS, INTEGRALLY LIGHTED	LEWIS ENGINEERING
152BL705S	THERMOCOUPLE TEMP INDICATORS, INTEGRALLY LIGHTED	LEWIS ENGINEERING
152BL706	THERMOCOUPLE TEMP INDICATORS, INTEGRALLY LIGHTED	HORIZON AEROSPACE
152BL708	THERMOCOUPLE TEMP INDICATORS, INTEGRALLY LIGHTED	HORIZON AEROSPACE
152BL708A	THERMOCOUPLE TEMP INDICATORS, INTEGRALLY LIGHTED	HORIZON AEROSPACE
152BL708B	THERMOCOUPLE TEMP INDICATORS, INTEGRALLY LIGHTED	HORIZON AEROSPACE
152BL708H	THERMOCOUPLE TEMP INDICATORS, INTEGRALLY LIGHTED	HORIZON AEROSPACE
152BL709	THERMOCOUPLE TEMP INDICATORS, INTEGRALLY LIGHTED	HORIZON AEROSPACE
152BL709A	THERMOCOUPLE TEMP INDICATORS, INTEGRALLY LIGHTED	HORIZON AEROSPACE
152BL722	THERMOCOUPLE TEMP INDICATORS, INTEGRALLY LIGHTED	HORIZON AEROSPACE
152BL801	THERMOCOUPLE TEMP INDICATORS, INTEGRALLY LIGHTED	HORIZON AEROSPACE
152BL801A	THERMOCOUPLE TEMP INDICATORS, INTEGRALLY LIGHTED	HORIZON AEROSPACE
152BL801B	THERMOCOUPLE TEMP INDICATORS, INTEGRALLY LIGHTED	HORIZON AEROSPACE
152BL801C	THERMOCOUPLE TEMP INDICATORS, INTEGRALLY LIGHTED	HORIZON AEROSPACE
152BL801D	THERMOCOUPLE TEMP INDICATORS, INTEGRALLY LIGHTED	HORIZON AEROSPACE
152BL801E	THERMOCOUPLE TEMP INDICATORS, INTEGRALLY LIGHTED	HORIZON AEROSPACE
152BL802A	THERMOCOUPLE TEMP INDICATORS, INTEGRALLY LIGHTED	HORIZON AEROSPACE
152BL802B	THERMOCOUPLE TEMP INDICATORS, INTEGRALLY LIGHTED	HORIZON AEROSPACE
152BL802C	THERMOCOUPLE TEMP INDICATORS, INTEGRALLY LIGHTED	HORIZON AEROSPACE
152BL802D	THERMOCOUPLE TEMP INDICATORS, INTEGRALLY LIGHTED	HORIZON AEROSPACE
152BL803	THERMOCOUPLE TEMP INDICATORS, INTEGRALLY LIGHTED	HORIZON AEROSPACE
152BL803A	THERMOCOUPLE TEMP INDICATORS, INTEGRALLY LIGHTED	HORIZON AEROSPACE
152BL803B	THERMOCOUPLE TEMP INDICATORS, INTEGRALLY LIGHTED	HORIZON AEROSPACE
152BL803C	THERMOCOUPLE TEMP INDICATORS, INTEGRALLY LIGHTED	HORIZON AEROSPACE
154BY	T12 TEMPERATURE SENSOR	ROSEMOUNT
1543	OVEN ASSEMBLY, MODEL 1543	TIA (RICHARDS CORP)
1560	SINGLE TONE ELECTRONIC CHIME	SEABOARD ELECTRONIC
157405-01-01	ENGINE N1 LIMIT INDICATOR	SMITHS
157405-02-01	ENGINE N1 LIMIT INDICATOR	SMITHS
157405-03-01	ENGINE N1 LIMIT INDICATOR	SMITHS
157770-01-01	MAXIMUM ENGINE PRESSURE RATIO INDICATOR	SMITHS
162BL402	ELECTRICAL RESISTANCE THERMOMETER	LEWIS ENGINEERING
162BL402A	ELECTRICAL RESISTANCE THERMOMETER	LEWIS ENGINEERING
162BL403	ELECTRICAL RESISTANCE THERMOMETER	LEWIS ENGINEERING
162BL403A	ELECTRICAL RESISTANCE THERMOMETER	LEWIS ENGINEERING
162BL403B	ELECTRICAL RESISTANCE THERMOMETER	LEWIS ENGINEERING
162BL403C	ELECTRICAL RESISTANCE THERMOMETER	LEWIS ENGINEERING
162BL501	ELECTRICAL RESISTANCE THERMOMETER	ULTRA ELECTRONICS
162BL502	ELECTRICAL RESISTANCE THERMOMETER	ULTRA ELECTRONICS
162BL503	ELECTRICAL RESISTANCE THERMOMETER	ULTRA ELECTRONICS
162BL504	ELECTRICAL RESISTANCE THERMOMETER	ULTRA ELECTRONICS
162BL505	ELECTRICAL RESISTANCE THERMOMETER	ULTRA ELECTRONICS
162BL602	ELECTRICAL RESISTANCE THERMOMETER	ULTRA ELECTRONICS
162BL701	ELECTRICAL RESISTANCE THERMOMETER	ULTRA ELECTRONICS
162BL701A	ELECTRICAL RESISTANCE THERMOMETER	ULTRA ELECTRONICS
162BL702	ELECTRICAL RESISTANCE THERMOMETER	ULTRA ELECTRONICS
162BL703	ELECTRICAL RESISTANCE THERMOMETER	ULTRA ELECTRONICS
162BL704	ELECTRICAL RESISTANCE THERMOMETER	ULTRA ELECTRONICS
162BL704A	ELECTRICAL RESISTANCE THERMOMETER	ULTRA ELECTRONICS
162BL704C	ELECTRICAL RESISTANCE THERMOMETER	ULTRA ELECTRONICS
162BL704D	ELECTRICAL RESISTANCE THERMOMETER	ULTRA ELECTRONICS
162BL704F	ELECTRICAL RESISTANCE THERMOMETER	ULTRA ELECTRONICS
162BL704H	ELECTRICAL RESISTANCE THERMOMETER	ULTRA ELECTRONICS
162BL704K	ELECTRICAL RESISTANCE THERMOMETER	ULTRA ELECTRONICS
162BL704L	ELECTRICAL RESISTANCE THERMOMETER	ULTRA ELECTRONICS
162BL704N	ELECTRICAL RESISTANCE THERMOMETER	ULTRA ELECTRONICS
162BL708	ELECTRICAL RESISTANCE THERMOMETER	HORIZON AEROSPACE
162BL709	ELECTRICAL RESISTANCE THERMOMETER	HORIZON AEROSPACE
162BL709A	ELECTRICAL RESISTANCE THERMOMETER	HORIZON AEROSPACE
162BL709B	ELECTRICAL RESISTANCE THERMOMETER	HORIZON AEROSPACE
162BL709C	ELECTRICAL RESISTANCE THERMOMETER	HORIZON AEROSPACE
162BL710	ELECTRICAL RESISTANCE THERMOMETER	HORIZON AEROSPACE
162BL711	ELECTRICAL RESISTANCE THERMOMETER	HORIZON AEROSPACE
162BL801	ELECTRICAL RESISTANCE THERMOMETER	ULTRA ELECTRONICS
162BL802	ELECTRICAL RESISTANCE THERMOMETER	ULTRA ELECTRONICS
162BL802A	ELECTRICAL RESISTANCE THERMOMETER	ULTRA ELECTRONICS

PART NUMBER	DESCRIPTION	OEM
162BL803	ELECTRICAL RESISTANCE THERMOMETER	ULTRA ELECTRONICS
162BL803A	ELECTRICAL RESISTANCE THERMOMETER	ULTRA ELECTRONICS
162BL804A	ELECTRICAL RESISTANCE THERMOMETER	ULTRA ELECTRONICS
162BL901	ELECTRICAL RESISTANCE THERMOMETER	ULTRA ELECTRONICS
162BL902	ELECTRICAL RESISTANCE THERMOMETER	ULTRA ELECTRONICS
162BL903	ELECTRICAL RESISTANCE THERMOMETER	ULTRA ELECTRONICS
162BL906	ELECTRICAL RESISTANCE THERMOMETER	ULTRA ELECTRONICS
162BL907	ELECTRICAL RESISTANCE THERMOMETER	ULTRA ELECTRONICS
16432	VARIABLE POWER TRANSFORMER	OECO, LLC
164474-01-01	MAXIMUM ENGINE PRESSURE RATIO INDICATOR	SMITHS
1646-1-6	DIMMABLE FLUORESCENT LAMP CONTROLLER	AVTECH
1646-1-6 MOD A	DIMMABLE FLUORESCENT LAMP CONTROLLER	AVTECH
1646-1-6 MOD B	DIMMABLE FLUORESCENT LAMP CONTROLLER	AVTECH
1646-1-7	DIMMABLE FLUORESCENT LAMP CONTROLLER	AVTECH
1646-1-7 MOD A	DIMMABLE FLUORESCENT LAMP CONTROLLER	AVTECH
1646-1-7 MOD B	DIMMABLE FLUORESCENT LAMP CONTROLLER	AVTECH
166891-01-01	CONTROL DISPLAY UNIT	GE AVIATION
1721-1-000-1	COFFEE MAKER DA5 SERIES	BE AEROSPACE
172934-001	RELAY	LEDEX INC
172937-001	RELAY	LUCAS LEDEX
17343-116-825F	AIRCRAFT OVERHEAT DETECTOR	FENWAL
175096-001	ROTARY SELECTOR SWITCH	JOHNSON ELECTRIC
1753M20P03	THERMOCOUPLE CABLE ASSEMBLIES	AMETEK AEROSPACE
1753M21P03	THERMOCOUPLE CABLE ASSEMBLIES	AMETEK AEROSPACE
1775143	POWER SUPPLY	HONEYWELL
1812-209LW	PNEUMATIC TEMPERATURE INDICATOR WITH AIDS	WESTON
18-1738-6	TRANSMITTER, FLAP POSITION & STALL WARNING	HONEYWELL
18-1738-7	TRANSMITTER, FLAP POSITION & STALL WARNING	HONEYWELL
18-1738-8	TRANSMITTER, FLAP POSITION	HONEYWELL
18-1738-9	TRANSMITTER, FLAP POSITION & STALL WARNING	HONEYWELL
18-1738-10	FLAP POSITION SENSOR	HONEYWELL
18-1738-12	FLAP POSITION SENSOR	HONEYWELL
18-1969-17	TRANSMITTER, FLAP POSITION	HONEYWELL
18-1969-18	TRANSMITTER, FLAP POSITION	HONEYWELL
1822-112LW	EXHAUST GAS TEMPERATURE APU INDICATOR	AMETEK
1954355-4	AUTOMATIC THROTTLE CONTROL PANEL	ALLIED BENDIX
1990554-4	VHF NAV CONTROL PANEL	ALLIED SIGNAL
2LA408353-00	LIGHT ASSEMBLY, HOUSING ASSEMBLY	GOODRICH
20022-0000-0101	FUEL QUANTITY TANK UNITS	UTC AEROSPACE
20022-0000-0102	FUEL QUANTITY TANK UNITS	UTC AEROSPACE
20022-0000-0103	FUEL QUANTITY TANK UNITS	UTC AEROSPACE
20022-0000-0104	FUEL QUANTITY TANK UNITS	UTC AEROSPACE
20022-0000-0105	FUEL QUANTITY TANK UNITS	UTC AEROSPACE
20022-0000-0106	FUEL QUANTITY TANK UNITS	UTC AEROSPACE
20022-0000-0107	FUEL QUANTITY TANK UNITS	UTC AEROSPACE
20022-0000-0108	FUEL QUANTITY TANK UNITS	UTC AEROSPACE
200-26604-02	VARIABLE POWER TRANSFORMER	OECO / MEGGITT
20-035008-300	CONTINUOUS-FIRE AND OVERHEAT-DETECTION (CFD) CONTROL UNIT	FENWAL SAFETY SYS
20041-0000-03	LIQUID QUANTITY ENGINE OIL TRANSMITTER	BF GOODRICH
20043-0000-01	LIQUID QUANTITY TRANSMITTER	BF GOODRICH
20044-0000-01	LIQUID QUANTITY TRANSMITTER	BF GOODRICH
20067-0000-0101	FUEL QUANTITY TANK UNITS	UTC AEROSPACE
20068-0000-0101	FUEL QUANTITY TANK UNITS	UTC AEROSPACE
20095-01	LIQUID QUANTITY TRANSMITTER	BF GOODRICH
201EDP1-1	SYSTEM DISPLAY PANEL	SMITHS GROUP
20138-1000-0101	LIQUID QUANTITY TRANSMITTER	BF GOODRICH
20139-1000-0101	LIQUID QUANTITY TRANSMITTER	BF GOODRICH
20140-1000-0101	LIQUID QUANTITY TRANSMITTER	BF GOODRICH
20219-0101	HYDRAULIC OIL QUANTITY TRANSMITTER	UTC AEROSPACE
20220-0101	HYDRAULIC OIL QUANTITY TRANSMITTER	UTC AEROSPACE
2022014-1	MOTOR	HONEYWELL
2022014-2	MOTOR	HONEYWELL
2022014-3	MOTOR	HONEYWELL
20288	TRANSFORMER-RECTIFIER	OECO, LLC
203BC101-1	BATTERY CHARGER	ACME ELECTRIC
203BC102-1	BATTERY CHARGER	ACME ELECTRIC
53114	ENGINE PRESSURE RATIO INDICATOR	GE AVIATION

PART NUMBER	DESCRIPTION	OEM
53175	ENGINE PRESSURE RATIO INDICATOR	GE AVIATION
53724	ENGINE PRESSURE RATIO INDICATOR	GE AVIATION
2056-105	COFFEE BREWER	REF DYNAMICS
57346	SERVOED ALTITUDE INDICATOR	GE AVIATION
57377	SERVOED ALTITUDE INDICATOR	GE AVIATION
59111	FLAP POSITION INDICATOR	GE AVIATION
59141	FLAP POSITION INDICATOR	GE AVIATION
2061-13-1	FLAP POSITION INDICATOR	GE AVIATION
2061-14-1	FLAP POSITION INDICATOR	GE AVIATION
67054	SERVOED MACH AIRSPEED INDICATOR	GE AVIATION
67085	SERVOED MACH AIRSPEED INDICATOR	GE AVIATION
67115	SERVOED MACH AIRSPEED INDICATOR	GE AVIATION
67146	SERVOED MACH AIRSPEED INDICATOR	GE AVIATION
67176	SERVOED MACH AIRSPEED INDICATOR	GE AVIATION
2094-0004	INDICATOR, WATER QUANTITY	KAISER ELECTROPRECISI
2094-0011	INDICATOR, WATER QUANTITY	KAISER ELECTROPRECISI
21C1-3-21	LOW FUEL PRESSURE SWITCH	EATON AEROSPACE
21C1-3-22	LOW FUEL PRESSURE SWITCH	EATON AEROSPACE
21SN04-23F	LP OIL WARNING PRESSURE SWITCH ASSY	EATON AEROSPACE
21SN04-23G	LP OIL WARNING PRESSURE SWITCH ASSY	EATON AEROSPACE
21SN04-23H	LP OIL WARNING PRESSURE SWITCH ASSY	EATON AEROSPACE
21SN04-23J	LP OIL WARNING PRESSURE SWITCH ASSY	EATON AEROSPACE
21SN04-23K	LP OIL WARNING PRESSURE SWITCH ASSY	EATON AEROSPACE
21SN04-24F	ENG FUEL FILTER DIFF PRES SWITCH ASSY	EATON AEROSPACE
21SN04-24G	ENG FUEL FILTER DIFF PRES SWITCH ASSY	EATON AEROSPACE
21SN04-24H	ENG FUEL FILTER DIFF PRES SWITCH ASSY	EATON AEROSPACE
21SN04-24J	ENG FUEL FILTER DIFF PRES SWITCH ASSY	EATON AEROSPACE
21SN04-24K	ENG FUEL FILTER DIFF PRES SWITCH ASSY	EATON AEROSPACE
21SN04-25F	ENG FUEL LOW PRESSURE SWITCH ASSY	EATON AEROSPACE
21SN04-25G	ENG FUEL LOW PRESSURE SWITCH ASSY	EATON AEROSPACE
21SN04-25H	ENG FUEL LOW PRESSURE SWITCH ASSY	EATON AEROSPACE
21SN04-25J	ENG FUEL LOW PRESSURE SWITCH ASSY	EATON AEROSPACE
21SN04-25K	ENG FUEL LOW PRESSURE SWITCH ASSY	EATON AEROSPACE
21SN04-26E	LP OIL FILTER PRESSURE SWITCH ASSEMBLY	EATON AEROSPACE
21SN04-26F	LP OIL FILTER PRESSURE SWITCH ASSEMBLY	EATON AEROSPACE
21SN04-26G	LP OIL FILTER PRESSURE SWITCH ASSEMBLY	EATON AEROSPACE
21SN04-26H	LP OIL FILTER PRESSURE SWITCH ASSEMBLY	EATON AEROSPACE
21SN04-26J	LP OIL FILTER PRESSURE SWITCH ASSEMBLY	EATON AEROSPACE
21SN04-104A	SCAVENGE OIL FILTER DIFF PRES SWITCH ASSY	EATON AEROSPACE
21SN04-104B	SCAVENGE OIL FILTER DIFF PRES SWITCH ASSY	EATON AEROSPACE
21SN04-104D	SCAVENGE OIL FILTER DIFF PRES SWITCH ASSY	EATON AEROSPACE
21SN04-104E	SCAVENGE OIL FILTER DIFF PRES SWITCH ASSY	EATON AEROSPACE
21SN04-104F	SCAVENGE OIL FILTER DIFF PRES SWITCH ASSY	EATON AEROSPACE
21SN04-158A	ENG FUEL FILTER DIFF PRESSURE SWITCH ASSY	EATON AEROSPACE
21SN04-158B	ENG FUEL FILTER DIFF PRESSURE SWITCH ASSY	EATON AEROSPACE
21SN04-158C	ENG FUEL FILTER DIFF PRESSURE SWITCH ASSY	EATON AEROSPACE
21SN04-158D	ENG FUEL FILTER DIFF PRESSURE SWITCH ASSY	EATON AEROSPACE
21SN04-159	ENG FUEL LOW PRESSURE SWITCH ASSY	EATON AEROSPACE
21SN04-159A	ENG FUEL LOW PRESSURE SWITCH ASSY	EATON AEROSPACE
21SN04-159B	ENG FUEL LOW PRESSURE SWITCH ASSY	EATON AEROSPACE
21SN04-159C	ENG FUEL LOW PRESSURE SWITCH ASSY	EATON AEROSPACE
21SN04-159D	ENG FUEL LOW PRESSURE SWITCH ASSY	EATON AEROSPACE
21SN04-306	LP OIL WARNING PRESSURE SWITCH ASSY	EATON AEROSPACE
21SN04-306A	LP OIL WARNING PRESSURE SWITCH ASSY	EATON AEROSPACE
21SN04-306B	LP OIL WARNING PRESSURE SWITCH ASSY	EATON AEROSPACE
21SN41-42	PRESSURE SWITCH	EATON
21SN41-52	PRESSURE SWITCH	EATON
21SN41-84	PRESSURE SWITCH	EATON
211C223-175	HYDRAULIC PRESSURE SWITCH	EATON
211C223-176	HYDRAULIC PRESSURE SWITCH	EATON
211C223-177	HYDRAULIC PRESSURE SWITCH	EATON
211C223-178	HYDRAULIC PRESSURE SWITCH	EATON
211C223-199	HYDRAULIC PRESSURE SWITCH	EATON
211C223-200	HYDRAULIC PRESSURE SWITCH	EATON
211C223-203	HYDRAULIC PRESSURE SWITCH	EATON
211C223-208	HYDRAULIC PRESSURE SWITCH	EATON
211C223-209	HYDRAULIC PRESSURE SWITCH	EATON

PART NUMBER	DESCRIPTION	OEM
211C223-211	HYDRAULIC PRESSURE SWITCH	EATON
211C223-212	HYDRAULIC PRESSURE SWITCH	EATON
211C223-214	HYDRAULIC PRESSURE SWITCH	EATON
211C223-216	HYDRAULIC PRESSURE SWITCH	EATON
211C223-252	HYDRAULIC PRESSURE SWITCH	EATON
211C223-253	HYDRAULIC PRESSURE SWITCH	EATON
211C223-275	HYDRAULIC PRESSURE SWITCH	EATON
211C223-278	HYDRAULIC PRESSURE SWITCH	EATON
211C223-296	HYDRAULIC PRESSURE SWITCH	EATON
211C223-297	HYDRAULIC PRESSURE SWITCH	EATON
211C223-301	HYDRAULIC PRESSURE SWITCH	EATON
211C223-312	HYDRAULIC PRESSURE SWITCH	EATON
211C223-319	HYDRAULIC PRESSURE SWITCH	EATON
211C223-320	HYDRAULIC PRESSURE SWITCH	EATON
211C223-321	HYDRAULIC PRESSURE SWITCH	EATON
211C223-322	HYDRAULIC PRESSURE SWITCH	EATON
211C223-323	HYDRAULIC PRESSURE SWITCH	EATON
211C223-324	HYDRAULIC PRESSURE SWITCH	EATON
211C223-516	HYDRAULIC PRESSURE SWITCH	EATON
211C223-517	HYDRAULIC PRESSURE SWITCH	EATON
211C223-518	HYDRAULIC PRESSURE SWITCH	EATON
211C223-519	HYDRAULIC PRESSURE SWITCH	EATON
211C223-520	HYDRAULIC PRESSURE SWITCH	EATON
211C223-521	HYDRAULIC PRESSURE SWITCH	EATON
211C223-522	HYDRAULIC PRESSURE SWITCH	EATON
211C223-523	HYDRAULIC PRESSURE SWITCH	EATON
211C223-524	HYDRAULIC PRESSURE SWITCH	EATON
211C223-526	HYDRAULIC PRESSURE SWITCH	EATON
211C223-527	HYDRAULIC PRESSURE SWITCH	EATON
211C223-534	HYDRAULIC PRESSURE SWITCH	EATON
212C139-1	PRESSURE SWITCH	EATON
212C139-3	PRESSURE SWITCH	EATON
212EDP1-1	EIS SECONDARY DISPLAY PANEL	GE AVIATION
212EDP1-2	EIS SECONDARY DISPLAY PANEL	GE AVIATION
212EDP1-3	EIS SECONDARY DISPLAY PANEL	GE AVIATION
214C40-1-110	ALTITUDE SWITCHES	EATON AEROSPACE
214C40-1-122	ALTITUDE SWITCHES	EATON AEROSPACE
214C40-1-151	ALTITUDE SWITCHES	EATON AEROSPACE
214C40-1-183	ALTITUDE SWITCHES	EATON AEROSPACE
214C50-2	ALTITUDE PRESSURE SWITCH	EATON AEROSPACE
214C50-68	ALTITUDE PRESSURE SWITCH	EATON AEROSPACE
2165-4	VOLTAGE AVERAGING MODULE	CURTISS-WRIGHT
21933-01AA	PRESSURE CONTROLLER	NORD-MICRO
21933-01AB	PRESSURE CONTROLLER	NORD-MICRO
21933-01AC	PRESSURE CONTROLLER	NORD-MICRO
21933-01AD	PRESSURE CONTROLLER	NORD-MICRO
132585	COMPARTMENT TEMPERATURE INDICATOR	GE AVIATION
22640-005	IMMERSION THERMOCOUPLE	HARCO LABORATORIES
2-299	TRANSFORMER-RECTIFIER, 50 AMP, UNREGULATED	CRANE / ELDEC
2-299-1	TRANSFORMER-RECTIFIER, 50 AMP, UNREGULATED	CRANE / ELDEC
2-301	BATTERY CHARGER ASSEMBLY	ELDEC CORP
2-301-3	BATTERY CHARGER ASSEMBLY	ELDEC CORP
231-2	WINDSHIELD TEMPERATURE CONTROLLER	PRIMEX AEROSPACE
2313M-347-1	WINDSHIELD WIPER MOTOR CONVERTER ASSY	UTC AEROSPACE
2313M-347-2	WINDSHIELD WIPER MOTOR CONVERTER ASSY	UTC AEROSPACE
2313M-347-3	WINDSHIELD WIPER MOTOR CONVERTER ASSY	UTC AEROSPACE
2313M-347-4	WINDSHIELD WIPER MOTOR CONVERTER ASSY	UTC AEROSPACE
2313M-348-1	WINDSHIELD WIPER MOTOR CONVERTER ASSY	UTC AEROSPACE
2313M-348-2	WINDSHIELD WIPER MOTOR CONVERTER ASSY	UTC AEROSPACE
2313M-348-3	WINDSHIELD WIPER MOTOR CONVERTER ASSY	UTC AEROSPACE
2313M-348-4	WINDSHIELD WIPER MOTOR CONVERTER ASSY	UTC AEROSPACE
231-5	WINDSHIELD TEMPERATURE CONTROLLER	GENERAL DYNAMICS
233A7202-2	MAP/CHART LIGHT CONTROL PANEL ASSY, P23-1	BAE SYSTEMS
233A7202-3	MAP/CHART LIGHT CONTROL PANEL ASSY, P23-1	BAE SYSTEMS
233A7202-4	MAP/CHART LIGHT CONTROL PANEL ASSY, P23-1	BAE SYSTEMS
233N3209-12	ELECTRICAL SYSTEM PANEL ASSEMBLY, M10063	BAE SYSTEMS
233N3209-14	ELECTRICAL SYSTEM PANEL ASSEMBLY, M10063	BAE SYSTEMS

PART NUMBER	DESCRIPTION	OEM
233U3206-310	ENGINE IGNITION CONTROL/FUEL JETTISON MODULE ASSEMBLY, M7325	BAE SYSTEMS
233U3206-311	ENGINE IGNITION CONTROL/FUEL JETTISON MODULE ASSEMBLY, M7325	BAE SYSTEMS
233U3206-312	ENGINE IGNITION CONTROL/FUEL JETTISON MODULE ASSEMBLY, M7325	BAE SYSTEMS
233U3206-314	ENGINE IGNITION CONTROL/FUEL JETTISON MODULE ASSEMBLY, M7325	BAE SYSTEMS
233U3206-315	ENGINE IGNITION CONTROL/FUEL JETTISON MODULE ASSEMBLY, M7325	BAE SYSTEMS
233U3206-316	ENGINE IGNITION CONTROL/FUEL JETTISON MODULE ASSEMBLY, M7325	BAE SYSTEMS
233U3206-317	ENGINE IGNITION CONTROL/FUEL JETTISON MODULE ASSEMBLY, M7325	BAE SYSTEMS
233U3206-318	ENGINE IGNITION CONTROL/FUEL JETTISON MODULE ASSEMBLY, M7325	BAE SYSTEMS
233U3206-319	ENGINE IGNITION CONTROL/FUEL JETTISON MODULE ASSEMBLY, M7325	BAE SYSTEMS
233U3206-319 MOD A	ENGINE IGNITION CONTROL/FUEL JETTISON MODULE ASSEMBLY, M7325	BAE SYSTEMS
233U3206-1052	ENGINE IGNITION CONTROL/FUEL JETTISON MODULE ASSEMBLY, M7325	BAE SYSTEMS
233U3206-1053	ENGINE IGNITION CONTROL/FUEL JETTISON MODULE ASSEMBLY, M7325	BAE SYSTEMS
233U3206-1054	ENGINE IGNITION CONTROL/FUEL JETTISON MODULE ASSEMBLY, M7325	BAE SYSTEMS
233U3206-1058	ENGINE IGNITION CONTROL/FUEL JETTISON MODULE ASSEMBLY, M7325	BAE SYSTEMS
233U3206-1065	ENGINE IGNITION CONTROL/FUEL JETTISON MODULE ASSEMBLY, M7325	BAE SYSTEMS
233U3206-1067	ENGINE IGNITION CONTROL/FUEL JETTISON MODULE ASSEMBLY, M7325	BAE SYSTEMS
233U3206-1070	ENGINE IGNITION CONTROL/FUEL JETTISON MODULE ASSEMBLY, M7325	BAE SYSTEMS
233U3206-1071	ENGINE IGNITION CONTROL/FUEL JETTISON MODULE ASSEMBLY, M7325	BAE SYSTEMS
233U3206-1073	ENGINE IGNITION CONTROL/FUEL JETTISON MODULE ASSEMBLY, M7325	BAE SYSTEMS
233U3206-1075	ENGINE IGNITION CONTROL/FUEL JETTISON MODULE ASSEMBLY, M7325	BAE SYSTEMS
233U3206-1300	ENGINE IGNITION CONTROL/FUEL JETTISON MODULE ASSEMBLY, M7325	BAE SYSTEMS
233U3206-1301	ENGINE IGNITION CONTROL/FUEL JETTISON MODULE ASSEMBLY, M7325	BAE SYSTEMS
233U3206-1302	ENGINE IGNITION CONTROL/FUEL JETTISON MODULE ASSEMBLY, M7325	BAE SYSTEMS
233U3206-1303	ENGINE IGNITION CONTROL/FUEL JETTISON MODULE ASSEMBLY, M7325	BAE SYSTEMS
233U3206-1304	ENGINE IGNITION CONTROL/FUEL JETTISON MODULE ASSEMBLY, M7325	BAE SYSTEMS
233U3206-1305	ENGINE IGNITION CONTROL/FUEL JETTISON MODULE ASSEMBLY, M7325	BAE SYSTEMS
233U3206-1306	ENGINE IGNITION CONTROL/FUEL JETTISON MODULE ASSEMBLY, M7325	BAE SYSTEMS
233U3206-1307	ENGINE IGNITION CONTROL/FUEL JETTISON MODULE ASSEMBLY, M7325	BAE SYSTEMS
233U3206-1309	ENGINE IGNITION CONTROL/FUEL JETTISON MODULE ASSEMBLY, M7325	BAE SYSTEMS
233U3206-1310	ENGINE IGNITION CONTROL/FUEL JETTISON MODULE ASSEMBLY, M7325	BAE SYSTEMS
233U3206-1311	ENGINE IGNITION CONTROL/FUEL JETTISON MODULE ASSEMBLY, M7325	BAE SYSTEMS
233U3206-1312	ENGINE IGNITION CONTROL/FUEL JETTISON MODULE ASSEMBLY, M7325	BAE SYSTEMS
233U3206-1313	ENGINE IGNITION CONTROL/FUEL JETTISON MODULE ASSEMBLY, M7325	BAE SYSTEMS
233U3206-1314	ENGINE IGNITION CONTROL/FUEL JETTISON MODULE ASSEMBLY, M7325	BAE SYSTEMS
233U3206-1315	ENGINE IGNITION CONTROL/FUEL JETTISON MODULE ASSEMBLY, M7325	BAE SYSTEMS
233U3206-1316	ENGINE IGNITION CONTROL/FUEL JETTISON MODULE ASSEMBLY, M7325	BAE SYSTEMS
233U3206-1317	ENGINE IGNITION CONTROL/FUEL JETTISON MODULE ASSEMBLY, M7325	BAE SYSTEMS
233U3206-1318	ENGINE IGNITION CONTROL/FUEL JETTISON MODULE ASSEMBLY, M7325	BAE SYSTEMS
233U3206-1319	ENGINE IGNITION CONTROL/FUEL JETTISON MODULE ASSEMBLY, M7325	BAE SYSTEMS
233U3206-1320	ENGINE IGNITION CONTROL/FUEL JETTISON MODULE ASSEMBLY, M7325	BAE SYSTEMS
233U3206-1321	ENGINE IGNITION CONTROL/FUEL JETTISON MODULE ASSEMBLY, M7325	BAE SYSTEMS
233U3206-2312	ENGINE IGNITION CONTROL/FUEL JETTISON MODULE ASSEMBLY, M7325	BAE SYSTEMS
238D1015-507	DIFFERENTIAL PRESSURE TRANSDUCER	EATON AEROSPACE
238D1016-513	OIL QUANTITY TRANSMITTER	ROHR, INC.
23830-000	EXHAUST GAS TEMPERATURE (EGT) / T3 HARNESS	HARCO LABORATORIES
24E507040G01	WATER HEATER	UTC AEROSPACE
24E507040G02	WATER HEATER	UTC AEROSPACE
24E507040G03	WATER HEATER	UTC AEROSPACE
24E507040G04	WATER HEATER	UTC AEROSPACE
24E507040G05	WATER HEATER	UTC AEROSPACE
24E507040G06	WATER HEATER	UTC AEROSPACE
222981	SINGLE CAVITY OVEN	BE AEROSPACE
222982	SINGLE CAVITY OVEN	BE AEROSPACE
222983	SINGLE CAVITY OVEN	BE AEROSPACE
222984	SINGLE CAVITY OVEN	BE AEROSPACE
25130	VANEAXIAL FAN	HAMILTON SUNDSTRA
25130-1	VANEAXIAL FAN	HAMILTON SUNDSTRA
255-5	PASSENGER ADDRESS AMPLIFIER	PRIMEX AEROSPACE
255-7	PASSENGER ADDRESS AMPLIFIER	PRIMEX AEROSPACE
255-52	PASSENGER ADDRESS AMPLIFIER	PRIMEX AEROSPACE
2566A40S	ANGLE-OF-ATTACK SENSOR ASSEMBLY	CONRAC
2577B	CONTROL DISPLAY UNIT	GE AVIATION
2587567	CI-600 GYROSYN COMPASS INDICATOR	HONEYWELL
2587567-901	CI-600 GYROSYN COMPASS INDICATOR	HONEYWELL
2588371-901	RADIO DIRECTION INDICATOR	HONEYWELL
2588371-902	RADIO DIRECTION INDICATOR	HONEYWELL
2589210-901	COMPASS SYSTEM RACK	HONEYWELL

PART NUMBER	DESCRIPTION	OEM
2589210-902	COMPASS SYSTEM RACK	HONEYWELL
2591092-903	ATTITUDE DIRECTOR INDICATOR	HONEYWELL
2591092-904	ATTITUDE DIRECTOR INDICATOR	HONEYWELL
2593564-917	ALTITUDE SELECT CONTROLLER	HONEYWELL
2593564-918	ALTITUDE SELECT CONTROLLER	HONEYWELL
2593564-919	ALTITUDE SELECT CONTROLLER	HONEYWELL
2593564-921	ALTITUDE SELECT CONTROLLER	HONEYWELL
2593564-924	ALTITUDE SELECT CONTROLLER	HONEYWELL
2594466-901	MACH AIRSPEED INDICATOR	HONEYWELL
2594466-902	MACH AIRSPEED INDICATOR	HONEYWELL
2594466-904	MACH AIRSPEED INDICATOR	HONEYWELL
2594466-905	MACH AIRSPEED INDICATOR	HONEYWELL
2594466-906	MACH AIRSPEED INDICATOR	HONEYWELL
2594467-901	TRUE AIRSPEED/STATIC AIR TEMP INDICATOR	HONEYWELL
2594467-903	TRUE AIRSPEED/STATIC AIR TEMP INDICATOR	HONEYWELL
2594625-903	RADIO DIGITAL DISTANCE MAGNETIC INDICATOR	HONEYWELL
2594625-904	RADIO DIGITAL DISTANCE MAGNETIC INDICATOR	HONEYWELL
2594914-902	ATTITUDE MONITORING & SWITCHING UNIT	HONEYWELL
2594914-903	ATTITUDE MONITORING & SWITCHING UNIT	HONEYWELL
2594914-904	ATTITUDE MONITORING & SWITCHING UNIT	HONEYWELL
255731	DIGITAL ELECTRONIC CLOCK	GE AVIATION
255762	DIGITAL ELECTRONIC CLOCK	GE AVIATION
255792	DIGITAL ELECTRONIC CLOCK	GE AVIATION
255823	DIGITAL ELECTRONIC CLOCK	GE AVIATION
255915	DIGITAL ELECTRONIC CLOCK	GE AVIATION
260686	TACHOMETER, APU & EXHAUST GAS TEMP, APU IND	AMETEK
260687	TACHOMETER, APU & EXHAUST GAS TEMP, APU IND	AMETEK
2609913	BRAKE TEMPATURE SENSOR	HONEYWELL
259505	DIGITAL ELECTRONIC CHRONOMETER	GE AVIATION
259536	DIGITAL ELECTRONIC CHRONOMETER	GE AVIATION
259597	DIGITAL ELECTRONIC CHRONOMETER	GE AVIATION
259658	DIGITAL ELECTRONIC CHRONOMETER	GE AVIATION
2610-13-1	DIGITAL ELECTRONIC CHRONOMETER	GE AVIATION
2613013	BRAKE TEMPATURE SENSOR	HONEYWELL
2616891	BRAKE TEMPATURE SENSOR	HONEYWELL
26340061 SERIES	BATTERY CHARGER	HAMILTON SUNDRSTRA
2651-278-7	LAVATORY DRAIN BALL VALVE ASSEMBLY	KAISER ELECTROPRECISION
2651-278-8	LAVATORY DRAIN BALL VALVE ASSEMBLY	KAISER ELECTROPRECISION
2651-278-16	LAVATORY DRAIN BALL VALVE ASSEMBLY	KAISER ELECTROPRECISION
285N0200-201	ENGINE SPEED PRINTED WIRING ASSEMBLY	BAE SYSTEMS
285N0200-201 MOD A	ENGINE SPEED PRINTED WIRING ASSEMBLY	BAE SYSTEMS
285N0200-202	ENGINE SPEED PRINTED WIRING ASSEMBLY	BAE SYSTEMS
285N0200-202 MOD A	ENGINE SPEED PRINTED WIRING ASSEMBLY	BAE SYSTEMS
285N0200-203	ENGINE SPEED PRINTED WIRING ASSEMBLY	BAE SYSTEMS
285N0200-204	ENGINE SPEED PRINTED WIRING ASSEMBLY	BAE SYSTEMS
285T0001-21	AUDIO ACCESSORY UNIT ASSEMBLY	BAE SYSTEMS
285T0001-22	AUDIO ACCESSORY UNIT ASSEMBLY	BAE SYSTEMS
285T0001-23	AUDIO ACCESSORY UNIT ASSEMBLY	BAE SYSTEMS
285T0001-32	AUDIO ACCESSORY UNIT ASSEMBLY	BAE SYSTEMS
285T0001-33	AUDIO ACCESSORY UNIT ASSEMBLY	BAE SYSTEMS
285T0001-35	AUDIO ACCESSORY UNIT ASSEMBLY	BAE SYSTEMS
285T0001-36	AUDIO ACCESSORY UNIT ASSEMBLY	BAE SYSTEMS
285T0001-37	AUDIO ACCESSORY UNIT ASSEMBLY	BAE SYSTEMS
285T0001-40	AUDIO ACCESSORY UNIT ASSEMBLY	BAE SYSTEMS
285T0001-41	AUDIO ACCESSORY UNIT ASSEMBLY	BAE SYSTEMS
285T0001-42	AUDIO ACCESSORY UNIT ASSEMBLY	BAE SYSTEMS
285T0001-43	AUDIO ACCESSORY UNIT ASSEMBLY	BAE SYSTEMS
285T0001-46	AUDIO ACCESSORY UNIT ASSEMBLY	BAE SYSTEMS
285T0001-47	AUDIO ACCESSORY UNIT ASSEMBLY	BAE SYSTEMS
285T0001-48	AUDIO ACCESSORY UNIT ASSEMBLY	BAE SYSTEMS
285T0001-49	AUDIO ACCESSORY UNIT ASSEMBLY	BAE SYSTEMS
285T0001-50	AUDIO ACCESSORY UNIT ASSEMBLY	BAE SYSTEMS
285T0001-51	AUDIO ACCESSORY UNIT ASSEMBLY	BAE SYSTEMS
285T0001-52	AUDIO ACCESSORY UNIT ASSEMBLY	BAE SYSTEMS
285T0001-53	AUDIO ACCESSORY UNIT ASSEMBLY	BAE SYSTEMS
285T0001-54	AUDIO ACCESSORY UNIT ASSEMBLY	BAE SYSTEMS
285T0001-55	AUDIO ACCESSORY UNIT ASSEMBLY	BAE SYSTEMS

PART NUMBER	DESCRIPTION	OEM
285T0554-6 MOD A	VOR CONTROL PANEL ASSEMBLY	BAE SYSTEMS
285T0554-6 MOD AB	VOR CONTROL PANEL ASSEMBLY	BAE SYSTEMS
285T0557-1	DUAL ADF CONTROL PANEL ASSEMBLY	BAE SYSTEMS
285T0557-1 MOD A	DUAL ADF CONTROL PANEL ASSEMBLY	BAE SYSTEMS
285T0557-1 MOD B	DUAL ADF CONTROL PANEL ASSEMBLY	BAE SYSTEMS
285T0557-1 MOD AB	DUAL ADF CONTROL PANEL ASSEMBLY	BAE SYSTEMS
285T0557-1 MOD ABC	DUAL ADF CONTROL PANEL ASSEMBLY	BAE SYSTEMS
285T0557-2	DUAL ADF CONTROL PANEL ASSEMBLY	BAE SYSTEMS
285T0557-2 MOD A	DUAL ADF CONTROL PANEL ASSEMBLY	BAE SYSTEMS
285T0557-2 MOD B	DUAL ADF CONTROL PANEL ASSEMBLY	BAE SYSTEMS
285T0557-2 MOD AB	DUAL ADF CONTROL PANEL ASSEMBLY	BAE SYSTEMS
285T0557-2 MOD ABC	DUAL ADF CONTROL PANEL ASSEMBLY	BAE SYSTEMS
285T0852-1	FLIGHT DECK ACCESS SYSTEM (FDAS) KEYPAD MODULE ASSY	BAE SYSTEMS
285T0852-1 MOD A	FLIGHT DECK ACCESS SYSTEM (FDAS) KEYPAD MODULE ASSY	BAE SYSTEMS
285T0852-1 MOD AB	FLIGHT DECK ACCESS SYSTEM (FDAS) KEYPAD MODULE ASSY	BAE SYSTEMS
285U0037-101	RADIO COMMUNICATION PANEL MODULE ASSY	BAE SYSTEMS
285U0037-101 MOD A	RADIO COMMUNICATION PANEL MODULE ASSY	BAE SYSTEMS
285U0037-104	RADIO COMMUNICATION PANEL MODULE ASSY	BAE SYSTEMS
285U0037-104 MOD A	RADIO COMMUNICATION PANEL MODULE ASSY	BAE SYSTEMS
285U0037-105	RADIO COMMUNICATION PANEL MODULE ASSY	BAE SYSTEMS
285U0037-201	RADIO COMMUNICATION PANEL MODULE ASSY	BAE SYSTEMS
285U0037-201 MOD A	RADIO COMMUNICATION PANEL MODULE ASSY	BAE SYSTEMS
285U0037-202	RADIO COMMUNICATION PANEL MODULE ASSY	BAE SYSTEMS
285U0037-203	RADIO COMMUNICATION PANEL MODULE ASSY	BAE SYSTEMS
285U0037-301	RADIO COMMUNICATION PANEL MODULE ASSY	BAE SYSTEMS
285U0037-301 MOD A	RADIO COMMUNICATION PANEL MODULE ASSY	BAE SYSTEMS
285U0037-301 MOD AB	RADIO COMMUNICATION PANEL MODULE ASSY	BAE SYSTEMS
285U0037-302	RADIO COMMUNICATION PANEL MODULE ASSY	BAE SYSTEMS
285U0037-302 MOD A	RADIO COMMUNICATION PANEL MODULE ASSY	BAE SYSTEMS
285U0037-302 MOD AB	RADIO COMMUNICATION PANEL MODULE ASSY	BAE SYSTEMS
285U0037-303	RADIO COMMUNICATION PANEL MODULE ASSY	BAE SYSTEMS
285U0037-303 MOD A	RADIO COMMUNICATION PANEL MODULE ASSY	BAE SYSTEMS
285U0037-303 MOD B	RADIO COMMUNICATION PANEL MODULE ASSY	BAE SYSTEMS
285U0037-304	RADIO COMMUNICATION PANEL MODULE ASSY	BAE SYSTEMS
285U0037-304 MOD A	RADIO COMMUNICATION PANEL MODULE ASSY	BAE SYSTEMS
285U0037-304 MOD AB	RADIO COMMUNICATION PANEL MODULE ASSY	BAE SYSTEMS
285U0037-305	RADIO COMMUNICATION PANEL MODULE ASSY	BAE SYSTEMS
285U0037-305 MOD A	RADIO COMMUNICATION PANEL MODULE ASSY	BAE SYSTEMS
285U0037-305 MOD AB	RADIO COMMUNICATION PANEL MODULE ASSY	BAE SYSTEMS
285U0037-306	RADIO COMMUNICATION PANEL MODULE ASSY	BAE SYSTEMS
285U0037-306 MOD A	RADIO COMMUNICATION PANEL MODULE ASSY	BAE SYSTEMS
285U0037-306 MOD B	RADIO COMMUNICATION PANEL MODULE ASSY	BAE SYSTEMS
285U0037-306 MOD AB	RADIO COMMUNICATION PANEL MODULE ASSY	BAE SYSTEMS
285U0037-307	RADIO COMMUNICATION PANEL MODULE ASSY	BAE SYSTEMS
285U0037-307 MOD A	RADIO COMMUNICATION PANEL MODULE ASSY	BAE SYSTEMS
285U0037-307 MOD AB	RADIO COMMUNICATION PANEL MODULE ASSY	BAE SYSTEMS
285U0037-602	RADIO COMMUNICATION PANEL MODULE ASSY	BAE SYSTEMS
285U0037-603	RADIO COMMUNICATION PANEL MODULE ASSY	BAE SYSTEMS
285U0037-604	RADIO COMMUNICATION PANEL MODULE ASSY	BAE SYSTEMS
285U0037-605	RADIO COMMUNICATION PANEL MODULE ASSY	BAE SYSTEMS
285U0037-606	RADIO COMMUNICATION PANEL MODULE ASSY	BAE SYSTEMS
285U0037-607	RADIO COMMUNICATION PANEL MODULE ASSY	BAE SYSTEMS
285U0037-612	RADIO COMMUNICATION PANEL MODULE ASSY	BAE SYSTEMS
285U0037-613	RADIO COMMUNICATION PANEL MODULE ASSY	BAE SYSTEMS
285U0037-614	RADIO COMMUNICATION PANEL MODULE ASSY	BAE SYSTEMS
285U0037-615	RADIO COMMUNICATION PANEL MODULE ASSY	BAE SYSTEMS
285U0037-616	RADIO COMMUNICATION PANEL MODULE ASSY	BAE SYSTEMS
285U0037-617	RADIO COMMUNICATION PANEL MODULE ASSY	BAE SYSTEMS
3M3-203C	POSITION TRANSDUCER CENTER DRIVE UNIT	MPC PRODUCTS
3M3-205A	POSITION TRANSDUCER CENTER DRIVE UNIT	MPC PRODUCTS
30-0191-1	WING-POSITION NAVIGATIONAL LIGHT	GRIMES AEROSPACE
30-0191-2	WING-POSITION NAVIGATIONAL LIGHT	GRIMES AEROSPACE
30-0191-5	WING-POSITION NAVIGATIONAL LIGHT	GRIMES AEROSPACE
30-0191-6	WING-POSITION NAVIGATIONAL LIGHT	GRIMES AEROSPACE
30-0191-7	WING-POSITION NAVIGATIONAL LIGHT	GRIMES AEROSPACE
30-0191-8	WING-POSITION NAVIGATIONAL LIGHT	GRIMES AEROSPACE
30-0191-9	WING-POSITION NAVIGATIONAL LIGHT	GRIMES AEROSPACE

PART NUMBER	DESCRIPTION	OEM
301EDP1-5	ENGINE DISPLAY PANEL	GE AVIATION
301EDP2-2	ENGINE DISPLAY PANEL	GE AVIATION
30-1098-1	AIRCRAFT NAVIGATIONAL ANTICOLLISION STROBE LIGHT	HONEYWELL
30-1098-3	AIRCRAFT NAVIGATIONAL ANTICOLLISION STROBE LIGHT	HONEYWELL
30-1099-1	AIRCRAFT NAVIGATIONAL ANTICOLLISION STROBE LIGHT	HONEYWELL
30-1099-1A	AIRCRAFT NAVIGATIONAL ANTICOLLISION STROBE LIGHT	HONEYWELL
30-1099-1M	AIRCRAFT NAVIGATIONAL ANTICOLLISION STROBE LIGHT	HONEYWELL
30-1099-3	AIRCRAFT NAVIGATIONAL ANTICOLLISION STROBE LIGHT	HONEYWELL
30-1099-5	AIRCRAFT NAVIGATIONAL ANTICOLLISION STROBE LIGHT	HONEYWELL
30-1099-7	AIRCRAFT NAVIGATIONAL ANTICOLLISION STROBE LIGHT	HONEYWELL
30-1133-1	AIRCRAFT WING POSITION NAVIGATIONAL LIGHT	GRIMES AEROSPACE
30-1133-1M	AIRCRAFT WING POSITION NAVIGATIONAL LIGHT	GRIMES AEROSPACE
30-1133-1M1	AIRCRAFT WING POSITION NAVIGATIONAL LIGHT	GRIMES AEROSPACE
30-1133-2	AIRCRAFT WING POSITION NAVIGATIONAL LIGHT	GRIMES AEROSPACE
30-1133-2M	AIRCRAFT WING POSITION NAVIGATIONAL LIGHT	GRIMES AEROSPACE
30-1133-2M1	AIRCRAFT WING POSITION NAVIGATIONAL LIGHT	GRIMES AEROSPACE
30-1133-3	AIRCRAFT WING POSITION NAVIGATIONAL LIGHT	GRIMES AEROSPACE
30-1133-3M	AIRCRAFT WING POSITION NAVIGATIONAL LIGHT	GRIMES AEROSPACE
30-1133-4	AIRCRAFT WING POSITION NAVIGATIONAL LIGHT	GRIMES AEROSPACE
30-1133-4M	AIRCRAFT WING POSITION NAVIGATIONAL LIGHT	GRIMES AEROSPACE
30-1133-5	AIRCRAFT WING POSITION NAVIGATIONAL LIGHT	GRIMES AEROSPACE
30-1133-5M	AIRCRAFT WING POSITION NAVIGATIONAL LIGHT	GRIMES AEROSPACE
30-1133-6	AIRCRAFT WING POSITION NAVIGATIONAL LIGHT	GRIMES AEROSPACE
30-1133-6M	AIRCRAFT WING POSITION NAVIGATIONAL LIGHT	GRIMES AEROSPACE
30-1521-3	REAR-POSITION NAVIGATIONAL LIGHT	HONEYWELL
30-1521-4	REAR-POSITION NAVIGATIONAL LIGHT	HONEYWELL
30-1521-5	REAR-POSITION NAVIGATIONAL LIGHT	HONEYWELL
30-1521-6	REAR-POSITION NAVIGATIONAL LIGHT	HONEYWELL
30-1526-3	AIRCRAFT ANTI-COLLISION LIGHT UPPER & LOWER FUSELAGE STROBE	HONEYWELL
30-1526-5	AIRCRAFT ANTI-COLLISION LIGHT UPPER & LOWER FUSELAGE STROBE	HONEYWELL
30-1526-7	AIRCRAFT ANTI-COLLISION LIGHT UPPER & LOWER FUSELAGE STROBE	HONEYWELL
30-1526-9	AIRCRAFT ANTI-COLLISION LIGHT UPPER & LOWER FUSELAGE STROBE	HONEYWELL
30-1526-11	AIRCRAFT ANTI-COLLISION LIGHT UPPER & LOWER FUSELAGE STROBE	HONEYWELL
301-771-601-0	T12 TEMPERATURE SENSOR	ROSEMOUNT
30-2043-1	SLIDE & GROUND ILLUMINATION LIGHT-EMERGENCY DOOR	FL AEROSPACE
30-2043-2	SLIDE & GROUND ILLUMINATION LIGHT-EMERGENCY DOOR	FL AEROSPACE
30-2043-3	SLIDE & GROUND ILLUMINATION LIGHT-EMERGENCY DOOR	FL AEROSPACE
30-2043-4	SLIDE & GROUND ILLUMINATION LIGHT-EMERGENCY DOOR	FL AEROSPACE
30-2481-3	REAR POSITION NAVIGATIONAL LIGHT	HONEYWELL
30-2481-5	REAR POSITION NAVIGATIONAL LIGHT	HONEYWELL
312BS101-1	ISFD DEDICATED BATTERY / CHARGER (DBC)	ACME AEROSPACE
32V92	VACUUM SWITCH	CUSTOM COMPONENT
3202122-1	NINE-INCH DIAMETER CHECK VALVE	HONEYWELL
321858-1-1	ELECTRIC SHUTOFF BUTTERFLY VALVE	HONEYWELL
321858-3-1	ELECTRIC SHUTOFF BUTTERFLY VALVE	HONEYWELL
321942-1-1	2 1/2" DIA ELECTRIC BUTTERFLY SHUTOFF VALVE	HONEYWELL
322200-10M00	HANDWHEEL TRANSMITTER	SKF
322200-10M00AMDTA	HANDWHEEL TRANSMITTER	SKF
322200-10M00AMDTB	HANDWHEEL TRANSMITTER	SKF
322200-10M00AMDTC	HANDWHEEL TRANSMITTER	SKF
322200-10M00AMDTD	HANDWHEEL TRANSMITTER	SKF
322200-10M00AMDTE	HANDWHEEL TRANSMITTER	SKF
322200-1M00	HANDWHEEL TRANSMITTER	SKF
322200-1M00AMDTB	HANDWHEEL TRANSMITTER	SKF
322200-1M00AMDTC	HANDWHEEL TRANSMITTER	SKF
322200-1M00AMDTD	HANDWHEEL TRANSMITTER	SKF
322200-1M00AMDTE	HANDWHEEL TRANSMITTER	SKF
322200-2M00	HANDWHEEL TRANSMITTER	SKF
322200-2M00AMDTB	HANDWHEEL TRANSMITTER	SKF
322200-2M00AMDTC	HANDWHEEL TRANSMITTER	SKF
322200-2M00AMDTD	HANDWHEEL TRANSMITTER	SKF
322200-2M00AMDTE	HANDWHEEL TRANSMITTER	SKF
322200-7M00	HANDWHEEL TRANSMITTER	SKF
322200-7M00AMDTA	HANDWHEEL TRANSMITTER	SKF
322200-7M00AMDTB	HANDWHEEL TRANSMITTER	SKF
322200-7M00AMDTC	HANDWHEEL TRANSMITTER	SKF
322200-8M00	HANDWHEEL TRANSMITTER	SKF

PART NUMBER	DESCRIPTION	OEM
322200-8M00AMDTA	HANDWHEEL TRANSMITTER	SKF
322200-8M00AMDTB	HANDWHEEL TRANSMITTER	SKF
322200-8M00AMDTC	HANDWHEEL TRANSMITTER	SKF
322200-9M00	HANDWHEEL TRANSMITTER	SKF
322200-9M00AMDTA	HANDWHEEL TRANSMITTER	SKF
322200-9M00AMDTB	HANDWHEEL TRANSMITTER	SKF
322200-9M00AMDTC	HANDWHEEL TRANSMITTER	SKF
322200-9M00AMDTD	HANDWHEEL TRANSMITTER	SKF
322200-9M00AMDTE	HANDWHEEL TRANSMITTER	SKF
3247-10	BALLAST UNIT	DIEHL AEROSPACE
3247-15	BALLAST UNIT	DIEHL AEROSPACE
3247-16	BALLAST UNIT	DIEHL AEROSPACE
3247-20	BALLAST UNIT	DIEHL AEROSPACE
3247-30	BALLAST UNIT	DIEHL AEROSPACE
3247-32	BALLAST UNIT	DIEHL AEROSPACE
3247-40	BALLAST UNIT	DIEHL AEROSPACE
3247-42	BALLAST UNIT	DIEHL AEROSPACE
3250-70	BALLAST UNIT	DIEHL AEROSPACE
3250-80	BALLAST UNIT	DIEHL LUFTFAHRT
329B-8J	FLIGHT DIRECTOR INDICATOR	ROCKWELL COLLINS
329B-8Y	ATTITUDE DIRECTOR INDICATOR	ROCKWELL INT'L
331A-8A	HORIZONTAL SITUATION INDICATOR	ROCKWELL COLLINS
331A-8G	COURSE INDICATOR	ROCKWELL COLLINS
331A-8K	HORIZONTAL SITUATION INDICATOR	ROCKWELL COLLINS
339D-1	DISTANCE INDICATOR	ROCKWELL COLLINS
339D-1A	DISTANCE INDICATOR	ROCKWELL COLLINS
339D-3B	DISTANCE INDICATOR	ROCKWELL COLLINS
339D-3C	DISTANCE INDICATOR	ROCKWELL COLLINS
339D-3D	DISTANCE INDICATOR	ROCKWELL COLLINS
339H-1	RADIO ALTITUDE INDICATOR	ROCKWELL COLLINS
339H-1A	RADIO ALTITUDE INDICATOR	ROCKWELL COLLINS
339H-1B	RADIO ALTITUDE INDICATOR	ROCKWELL COLLINS
339H-6	RADIO ALTITUDE INDICATOR	ROCKWELL COLLINS
342B040000	TEMPERATURE CONTROL THERMOSTAT	LIEBHERR
342B050000	TEMPERATURE CONTROL THERMOSTAT	LIEBHERR
34265	COCKPIT LIGHT	HONEYWELL
34265-1	COCKPIT LIGHT	HONEYWELL
34265-2	COCKPIT LIGHT	HONEYWELL
34265-3	COCKPIT LIGHT	HONEYWELL
34265-4	COCKPIT LIGHT	HONEYWELL
34265-5	COCKPIT LIGHT	HONEYWELL
34265-6	COCKPIT LIGHT	HONEYWELL
34265-7	COCKPIT LIGHT	HONEYWELL
34265-8	COCKPIT LIGHT	HONEYWELL
34265-9	COCKPIT LIGHT	HONEYWELL
34265-10	COCKPIT LIGHT	HONEYWELL
34265-11	COCKPIT LIGHT	HONEYWELL
34265-12	COCKPIT LIGHT	HONEYWELL
34265-13	COCKPIT LIGHT	HONEYWELL
34265-14	COCKPIT LIGHT	HONEYWELL
34265-15	COCKPIT LIGHT	HONEYWELL
34265-16	COCKPIT LIGHT	HONEYWELL
34265-17	COCKPIT LIGHT	HONEYWELL
34402-2A22-1	TRANSMITTER FOR OIL AND FUEL PRESSURE SYSTEMS	HONEYWELL
34402-30A22-1	TRANSMITTER FOR OIL AND FUEL PRESSURE SYSTEMS	HONEYWELL
34402-123A22-1	TRANSMITTER FOR OIL AND FUEL PRESSURE SYSTEMS	HONEYWELL
35-0D5-1002	COCKPIT AMPLIFIER LOUDSPEAKER	AIRBUS
35-0D5-1003	COCKPIT AMPLIFIER LOUDSPEAKER	AIRBUS
3510-0032-01	COFFEE MAKER	FL AEROSPACE
3510-0039-01	COFFEE MAKER	B/E AEROSPACE
3510-0039-03	COFFEE MAKER	B/E AEROSPACE
3510-0040-03	COFFEE MAKER/WATER BOILER ASSY	B/E AIRCRAFT PRODUC
3510-0040-05	COFFEE MAKER/WATER BOILER ASSY	B/E AIRCRAFT PRODUC
3510-0041-03	COFFEE MAKER	AIRCRAFT PRODUCTS
3510-0044-05	COFFEE MAKER/WATER BOILER ASSY	B/E AEROSPACE
3510-0044-07	COFFEE MAKER/WATER BOILER ASSY	B/E AEROSPACE
3510-0044-11	COFFEE MAKER/WATER BOILER ASSY	B/E AEROSPACE

PART NUMBER	DESCRIPTION	OEM
3510-0053-01	COFFEE MAKER	B/E AEROSPACE
3510-0066-01	ESPRESSO COFFEE MAKER	B/E AEROSPACE
3510-0070-01	COFFEE MAKER ASSEMBLY	B/E AEROSPACE
3510-0072-01	COFFEE MAKER ASSEMBLY	B/E AEROSPACE
355XX-2	SENSING ELEMENTS	FENWAL SAFETY SYS
355XX-3	SENSING ELEMENTS	FENWAL SAFETY SYS
355XX-4	SENSING ELEMENTS	FENWAL SAFETY SYS
35518-48-400	SENSING ELEMENTS	FENWAL SAFETY SYS
356XX-2	SENSING ELEMENTS	FENWAL SAFETY SYS
356XX-3	SENSING ELEMENTS	FENWAL SAFETY SYS
356XX-4	SENSING ELEMENTS	FENWAL SAFETY SYS
3567402-0201	TRANSMITTER FOR OIL AND FUEL PRESSURE SYSTEMS	HONEYWELL
3567403-3001	TRANSMITTER FOR OIL AND FUEL PRESSURE SYSTEMS	HONEYWELL
3567404-7001	TRANSMITTER FOR OIL AND FUEL PRESSURE SYSTEMS	HONEYWELL
3567407-0101	TRANSMITTER FOR OIL AND FUEL PRESSURE SYSTEMS	HONEYWELL
3600	DRAIN VALVE ASSEMBLY	MONOGRAM
3600-1	DRAIN VALVE ASSEMBLY	MONOGRAM
620914	DRAIN VALVE ASSEMBLY	MONOGRAM
620915	DRAIN VALVE ASSEMBLY	MONOGRAM
620916	DRAIN VALVE ASSEMBLY	MONOGRAM
620917	DRAIN VALVE ASSEMBLY	MONOGRAM
3600-2	DRAIN VALVE ASSEMBLY	MONOGRAM
3600-5	DRAIN VALVE ASSEMBLY	MONOGRAM
3600-6	DRAIN VALVE ASSEMBLY	MONOGRAM
3600-7	DRAIN VALVE ASSEMBLY	MONOGRAM
3600-8	DRAIN VALVE ASSEMBLY	MONOGRAM
3600-9	DRAIN VALVE ASSEMBLY	MONOGRAM
3600-12	DRAIN VALVE ASSEMBLY	MONOGRAM
3600-13	DRAIN VALVE ASSEMBLY	MONOGRAM
3600-14	DRAIN VALVE ASSEMBLY	MONOGRAM
3600-15	DRAIN VALVE ASSEMBLY	MONOGRAM
3600-16	DRAIN VALVE ASSEMBLY	MONOGRAM
3601-01	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-02	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-03	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-04	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-08	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-09	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-10	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-11	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-12	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-13	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-35	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-36	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-37	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-38	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-46	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-47	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-48	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-49	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-50	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-52	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-53	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-59	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-60	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-62	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-63	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-64	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-65	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-66	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-67	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-68	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-69	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-70	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-71	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-72	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-73	FIRE / OVERHEAT DETECTOR	MEGGITT

PART NUMBER	DESCRIPTION	OEM
3601-74	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-75	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-76	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-77	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-80	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-81	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-82	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-87	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-88	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-89	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-90	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-105	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-108	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-109	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-110	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-111	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-112	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-113	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-114	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-115	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-116	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-117	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-118	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-119	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-120	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-121	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-122	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-125	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-126	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-127	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-128	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-129	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-130	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-131	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-132	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-133	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-134	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-135	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-142	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-143	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-145	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-147	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-148	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-155	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-156	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-157	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-173	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-174	FIRE / OVERHEAT DETECTOR	MEGGITT
3601-175	FIRE / OVERHEAT DETECTOR	MEGGITT
364-1	PHASE CONVERTER	PACIFIC ELECTRO
3759028-6	PITCH GUIDANCE CONTROL PANEL	HONEYWELL
3759029-6	PITCH GUIDANCE CONTROL PANEL	HONEYWELL
3759078-6	PITCH GUIDANCE CONTROL PANEL	HONEYWELL
3759082-6	PITCH GUIDANCE CONTROL PANEL	HONEYWELL
3801-01	FIRE/OVERHEAT DETECTOR	MEGGITT
3801-02	FIRE/OVERHEAT DETECTOR	MEGGITT
3801-03	FIRE/OVERHEAT DETECTOR	MEGGITT
3801-04	FIRE/OVERHEAT DETECTOR	MEGGITT
3822182-4	VHF NAV CONTROL PANEL	ALLIED SIGNAL
3876211-3	OIL LEVEL/TEMPERATURE SENSOR	AMETEK
391046-04128	LIQUID QUANTITY TRANSMITTER	BFGOODRICH
391046-04129	LIQUID QUANTITY TRANSMITTER	BFGOODRICH
391046-04130	LIQUID QUANTITY TRANSMITTER	BFGOODRICH
391046-04131	LIQUID QUANTITY TRANSMITTER	BFGOODRICH
391046-04132	LIQUID QUANTITY TRANSMITTER	BFGOODRICH
391046-04133	LIQUID QUANTITY TRANSMITTER	BFGOODRICH
391046-04134	LIQUID QUANTITY TRANSMITTER	BFGOODRICH

PART NUMBER	DESCRIPTION	OEM
391046-04135	LIQUID QUANTITY TRANSMITTER	BFGOODRICH
391046-04136	LIQUID QUANTITY TRANSMITTER	BFGOODRICH
391046-04137	LIQUID QUANTITY TRANSMITTER	BFGOODRICH
391046-04138	LIQUID QUANTITY TRANSMITTER	BFGOODRICH
391046-04159	LIQUID QUANTITY TRANSMITTER	BFGOODRICH
391046-04160	LIQUID QUANTITY TRANSMITTER	BFGOODRICH
391046-04161	LIQUID QUANTITY TRANSMITTER	BFGOODRICH
391046-04162	LIQUID QUANTITY TRANSMITTER	BFGOODRICH
391046-04165	LIQUID QUANTITY TRANSMITTER	BFGOODRICH
391046-05128	LIQUID QUANTITY TRANSMITTER	BFGOODRICH
391046-05129	LIQUID QUANTITY TRANSMITTER	BFGOODRICH
391046-05130	LIQUID QUANTITY TRANSMITTER	BFGOODRICH
391046-05131	LIQUID QUANTITY TRANSMITTER	BFGOODRICH
391046-05132	LIQUID QUANTITY TRANSMITTER	BFGOODRICH
391046-05133	LIQUID QUANTITY TRANSMITTER	BFGOODRICH
391046-05134	LIQUID QUANTITY TRANSMITTER	BFGOODRICH
391046-05135	LIQUID QUANTITY TRANSMITTER	BFGOODRICH
391046-05136	LIQUID QUANTITY TRANSMITTER	BFGOODRICH
391046-05137	LIQUID QUANTITY TRANSMITTER	BFGOODRICH
391046-05138	LIQUID QUANTITY TRANSMITTER	BFGOODRICH
391046-085	LIQUID QUANTITY TRANSMITTER	BFGOODRICH
391046-183	LIQUID QUANTITY TRANSMITTER	BFGOODRICH
391046-184	LIQUID QUANTITY TRANSMITTER	BFGOODRICH
391046-299	LIQUID QUANTITY TRANSMITTER	BFGOODRICH
391046-300	LIQUID QUANTITY TRANSMITTER	BFGOODRICH
391046-477	LIQUID QUANTITY TRANSMITTER	BFGOODRICH
391046-478	LIQUID QUANTITY TRANSMITTER	BFGOODRICH
391046-479	LIQUID QUANTITY TRANSMITTER	BFGOODRICH
391046-480	LIQUID QUANTITY TRANSMITTER	BFGOODRICH
391046-481	LIQUID QUANTITY TRANSMITTER	BFGOODRICH
391046-482	LIQUID QUANTITY TRANSMITTER	BFGOODRICH
391046-483	LIQUID QUANTITY TRANSMITTER	BFGOODRICH
391046-484	LIQUID QUANTITY TRANSMITTER	BFGOODRICH
391046-485	LIQUID QUANTITY TRANSMITTER	BFGOODRICH
391046-486	LIQUID QUANTITY TRANSMITTER	BFGOODRICH
392710-1-1	PNEUMATIC SHUTOFF MODULATING BUTTERFLY VALVE	HONEYWELL
392710-1-2	PNEUMATIC SHUTOFF MODULATING BUTTERFLY VALVE	HONEYWELL
392710-2	PNEUMATIC SHUTOFF MODULATING BUTTERFLY VALVE	HONEYWELL
396-00740	OIL PRESSURE INDICATOR	EDISON
396-01740	OIL PRESSURE INDICATOR	EDISON
396-100S1	OIL PRESSURE INDICATOR	EDISON
396-100S1-D1	OIL PRESSURE INDICATOR	EDISON
396442-1	THREE & ONE-HALF INCH DIAMETER FLOW CONTROL VALVE	HONEYWELL
396498-1	THREE & ONE-HALF INCH DIAMETER FLOW CONTROL VALVE	HONEYWELL
396498-2	THREE & ONE-HALF INCH DIAMETER FLOW CONTROL VALVE	HONEYWELL
40-0074-11	AIRCRAFT NAVIGATIONAL LIGHT	GRIMES
40-0074-13	AIRCRAFT NAVIGATIONAL LIGHT	GRIMES
40-0074-15	AIRCRAFT NAVIGATIONAL LIGHT	GRIMES
40-0074-17	AIRCRAFT NAVIGATIONAL LIGHT	GRIMES
40-0074-19	AIRCRAFT NAVIGATIONAL LIGHT	GRIMES
400-1794	COFFEE BREWER	TIA
400-1907	COFFEE BREWER	TIA
4003733-902	HORIZONTAL SITUATION INDICATOR	SPERRY CORP
4003733-903	HORIZONTAL SITUATION INDICATOR	SPERRY CORP
4003733-905	HORIZONTAL SITUATION INDICATOR	SPERRY CORP
4005123-901	ALTIMETER	HONEYWELL
4005123-902	ALTIMETER	HONEYWELL
4005123-903	ALTIMETER	HONEYWELL
4005123-906	ALTIMETER	HONEYWELL
4005123-907	ALTIMETER	HONEYWELL
4006454	LIQUID QUANTITY TRANSMITTER	BF GOODRICH
4006534	LIQUID QUANTITY TRANSMITTER	BF GOODRICH
4006584-901	ATTITUDE DIRECTOR INDICATOR	HONEYWELL
4006584-902	ATTITUDE DIRECTOR INDICATOR	HONEYWELL
4019700-902	TYPE AD-300C ATTITUDE DIRECTOR INDICATOR	HONEYWELL
4019700-903	TYPE AD-300C ATTITUDE DIRECTOR INDICATOR	HONEYWELL
4019700-904	TYPE AD-300C ATTITUDE DIRECTOR INDICATOR	HONEYWELL

PART NUMBER	DESCRIPTION	OEM
4019700-905	TYPE AD-300C ATTITUDE DIRECTOR INDICATOR	HONEYWELL
4019700-906	TYPE AD-300C ATTITUDE DIRECTOR INDICATOR	HONEYWELL
4019700-907	TYPE AD-300C ATTITUDE DIRECTOR INDICATOR	HONEYWELL
4019700-908	TYPE AD-300C ATTITUDE DIRECTOR INDICATOR	HONEYWELL
4020917-901	ATTITUDE DIRECTOR INDICATOR	HONEYWELL
4025767-901	TEMPERATURE SELECT PANEL	SPERRY CORP
4025767-902	TEMPERATURE SELECT PANEL	SPERRY CORP
40-302	TOTAL AIR TEMP INDICATOR	RAGEN DATA SYS
40-302-1	TOTAL AIR TEMP INDICATOR	RAGEN DATA SYS
40-302-3	TOTAL AIR TEMP INDICATOR	RAGEN DATA SYS
40-302-4	TOTAL AIR TEMP INDICATOR	RAGEN DATA SYS
4034233-901	POSITION SENSOR	HONEYWELL
4034233-902	POSITION SENSOR	HONEYWELL
4034233-903	POSITION SENSOR	HONEYWELL
4034234-901	FLIGHT MODE ANNUNCIATOR	HONEYWELL
4034234-902	FLIGHT MODE ANNUNCIATOR	HONEYWELL
4034234-903	FLIGHT MODE ANNUNCIATOR	HONEYWELL
4034235-901	STATUS/TEST PANEL	HONEYWELL
4034240-901	VHF/NAV CONTROL PANEL	HONEYWELL
4034240-902	VHF/NAV CONTROL PANEL	HONEYWELL
4034240-903	VHF/NAV CONTROL PANEL	HONEYWELL
4034240-904	VHF/NAV CONTROL PANEL	HONEYWELL
4034240-905	VHF/NAV CONTROL PANEL	HONEYWELL
4034240-906	VHF/NAV CONTROL PANEL	HONEYWELL
4034242-901	FLIGHT GUIDANCE CONTROL PANEL	HONEYWELL
4034242-902	FLIGHT GUIDANCE CONTROL PANEL	HONEYWELL
4034242-903	FLIGHT GUIDANCE CONTROL PANEL	HONEYWELL
4034242-904	FLIGHT GUIDANCE CONTROL PANEL	HONEYWELL
4034242-906	FLIGHT GUIDANCE CONTROL PANEL	HONEYWELL
4034242-911	FLIGHT GUIDANCE CONTROL PANEL	HONEYWELL
4034242-913	FLIGHT GUIDANCE CONTROL PANEL	HONEYWELL
4034242-915	FLIGHT GUIDANCE CONTROL PANEL	HONEYWELL
4034242-917	FLIGHT GUIDANCE CONTROL PANEL	HONEYWELL
4034242-921	FLIGHT GUIDANCE CONTROL PANEL	HONEYWELL
4034242-922	FLIGHT GUIDANCE CONTROL PANEL	HONEYWELL
4034242-923	FLIGHT GUIDANCE CONTROL PANEL	HONEYWELL
4034242-924	FLIGHT GUIDANCE CONTROL PANEL	HONEYWELL
4034242-932	FLIGHT GUIDANCE CONTROL PANEL	HONEYWELL
4034242-934	FLIGHT GUIDANCE CONTROL PANEL	HONEYWELL
4034242-942	FLIGHT GUIDANCE CONTROL PANEL	HONEYWELL
4034242-944	FLIGHT GUIDANCE CONTROL PANEL	HONEYWELL
4034242-952	FLIGHT GUIDANCE CONTROL PANEL	HONEYWELL
4034242-954	FLIGHT GUIDANCE CONTROL PANEL	HONEYWELL
4034242-962	FLIGHT GUIDANCE CONTROL PANEL	HONEYWELL
4034242-964	FLIGHT GUIDANCE CONTROL PANEL	HONEYWELL
4034242-972	FLIGHT GUIDANCE CONTROL PANEL	HONEYWELL
4034242-974	FLIGHT GUIDANCE CONTROL PANEL	HONEYWELL
4034242-991	FLIGHT GUIDANCE CONTROL PANEL	HONEYWELL
4034242-992	FLIGHT GUIDANCE CONTROL PANEL	HONEYWELL
4034242-993	FLIGHT GUIDANCE CONTROL PANEL	HONEYWELL
4034242-994	FLIGHT GUIDANCE CONTROL PANEL	HONEYWELL
4034242-996	FLIGHT GUIDANCE CONTROL PANEL	HONEYWELL
4034559-901	DISTANCE BEARING INDICATOR/MODEL DB-100	HONEYWELL
4034559-902	DISTANCE BEARING INDICATOR/MODEL DB-100	HONEYWELL
4034559-908	DISTANCE BEARING INDICATOR/MODEL DB-100	HONEYWELL
4034559-909	DISTANCE BEARING INDICATOR/MODEL DB-100	HONEYWELL
4034559-910	DISTANCE BEARING INDICATOR/MODEL DB-100	HONEYWELL
4039892-904	BAROMETRIC ALTIMETER	HONEYWELL
4039892-905	BAROMETRIC ALTIMETER	HONEYWELL
4039892-906	BAROMETRIC ALTIMETER	HONEYWELL
4039892-907	BAROMETRIC ALTIMETER	HONEYWELL
4039892-908	BAROMETRIC ALTIMETER	HONEYWELL
4039892-909	BAROMETRIC ALTIMETER	HONEYWELL
4039892-910	BAROMETRIC ALTIMETER	HONEYWELL
4041-12	CEILING LIGHT	DIEHL AEROSPACE
4041-18	CEILING LIGHT	DIEHL AEROSPACE
4041-24	CEILING LIGHT	DIEHL AEROSPACE

PART NUMBER	DESCRIPTION	OEM
4041-28	CEILING LIGHT	DIEHL AEROSPACE
4041-48	CEILING LIGHT	DIEHL AEROSPACE
4041-58	CEILING LIGHT	DIEHL AEROSPACE
4041-70	CEILING LIGHT	DIEHL AEROSPACE
4042-10	CEILING LIGHT	DIEHL AEROSPACE
4051601-932	MODE CONTROL PANEL	HONEYWELL
4051601-935	MODE CONTROL PANEL	HONEYWELL
4055372-901	TRUE AIRSPEED/STATIC AIR TEMP INDICATOR	HONEYWELL
4055372-903	TRUE AIRSPEED/STATIC AIR TEMP INDICATOR	HONEYWELL
4056511-903	DIMMING PANEL	HONEYWELL
4056511-904	DIMMING PANEL	HONEYWELL
4056512-901	MODE SELECT PANEL	HONEYWELL
4056512-902	MODE SELECT PANEL	HONEYWELL
4056512-904	MODE SELECT PANEL	HONEYWELL
4056512-905	MODE SELECT PANEL	HONEYWELL
4056512-906	MODE SELECT PANEL	HONEYWELL
4056512-907	MODE SELECT PANEL	HONEYWELL
4056512-912	MODE SELECT PANEL	HONEYWELL
4056512-915	MODE SELECT PANEL	HONEYWELL
4056512-917	MODE SELECT PANEL	HONEYWELL
4056512-927	MODE SELECT PANEL	HONEYWELL
4057800-901	MACH AIRSPEED INDICATOR	HONEYWELL
4057800-902	MACH AIRSPEED INDICATOR	HONEYWELL
4057800-904	MACH AIRSPEED INDICATOR	HONEYWELL
4057800-905	MACH AIRSPEED INDICATOR	HONEYWELL
4057800-906	MACH AIRSPEED INDICATOR	HONEYWELL
4059032-901	AUTOMATIC FLIGHT SYSTEM CONTROL PANEL	HONEYWELL
415G381-1	DIFFERENTIAL PRESSURE TRANSDUCER	EATON AEROSPACE
411-0001-126	COFFEE MAKER ASSEMBLY	B/E AEROSPACE
411-0001-127	COFFEE MAKER ASSEMBLY	B/E AEROSPACE
411-0001-130	COFFEE MAKER ASSEMBLY	B/E AEROSPACE
411-0001-131	COFFEE MAKER ASSEMBLY	B/E AEROSPACE
411-0001-133	COFFEE MAKER ASSEMBLY	B/E AEROSPACE
411-0001-135	COFFEE MAKER ASSEMBLY	B/E AEROSPACE
411-0001-137	COFFEE MAKER ASSEMBLY	B/E AEROSPACE
411-0001-139	COFFEE MAKER ASSEMBLY	B/E AEROSPACE
411-0001-139A	COFFEE MAKER ASSEMBLY	B/E AEROSPACE
411-0001-141	COFFEE MAKER ASSEMBLY	B/E AEROSPACE
411-0001-143	COFFEE MAKER ASSEMBLY	B/E AEROSPACE
411-0001-147	COFFEE MAKER ASSEMBLY	B/E AEROSPACE
4133801030	WHEEL PRESSURE TRANSDUCER	SAFRAN MESSIER
416-0001-1	COFFEE MAKER	B/E AEROSPACE
416-0001-1P	COFFEE MAKER	B/E AEROSPACE
416-0001-3	COFFEE MAKER	B/E AEROSPACE
416-0001-5	COFFEE MAKER	B/E AEROSPACE
416-0001-7	COFFEE MAKER	B/E AEROSPACE
416-0001-9	COFFEE MAKER	B/E AEROSPACE
416-0001-13	COFFEE MAKER	B/E AEROSPACE
416-0001-15	COFFEE MAKER	B/E AEROSPACE
416-0001-17	COFFEE MAKER	B/E AEROSPACE
416-0001-19	COFFEE MAKER	B/E AEROSPACE
416-0001-21	COFFEE MAKER	B/E AEROSPACE
416-0001-23	COFFEE MAKER	B/E AEROSPACE
416-0001-25	COFFEE MAKER	B/E AEROSPACE
416-0001-29	COFFEE MAKER	B/E AEROSPACE
416-0001-35	COFFEE MAKER	B/E AEROSPACE
416-0001-39	COFFEE MAKER	B/E AEROSPACE
416-0001-41	COFFEE MAKER	B/E AEROSPACE
416-0001-45	COFFEE MAKER	B/E AEROSPACE
416-0001-47	COFFEE MAKER	B/E AEROSPACE
416-0001-49	COFFEE MAKER	B/E AEROSPACE
416-1001-1	COFFEE MAKER ASSEMBLY	B/E AEROSPACE
416-1001-1P	COFFEE MAKER ASSEMBLY	B/E AEROSPACE
416-1001-3	COFFEE MAKER ASSEMBLY	B/E AEROSPACE
416-1001-5	COFFEE MAKER ASSEMBLY	B/E AEROSPACE
416-1001-7	COFFEE MAKER ASSEMBLY	B/E AEROSPACE
416-1001-9	COFFEE MAKER ASSEMBLY	B/E AEROSPACE

PART NUMBER	DESCRIPTION	OEM
416-1001-13	COFFEE MAKER ASSEMBLY	B/E AEROSPACE
416-1001-17	COFFEE MAKER ASSEMBLY	B/E AEROSPACE
416-1001-19	COFFEE MAKER ASSEMBLY	B/E AEROSPACE
416-1001-21	COFFEE MAKER ASSEMBLY	B/E AEROSPACE
416-1001-23	COFFEE MAKER ASSEMBLY	B/E AEROSPACE
416-1001-25	COFFEE MAKER ASSEMBLY	B/E AEROSPACE
416-1001-29	COFFEE MAKER ASSEMBLY	B/E AEROSPACE
416-1001-41	COFFEE MAKER ASSEMBLY	B/E AEROSPACE
416-1001-45	COFFEE MAKER ASSEMBLY	B/E AEROSPACE
416-1001-47	COFFEE MAKER ASSEMBLY	B/E AEROSPACE
416-1001-49	COFFEE MAKER ASSEMBLY	B/E AEROSPACE
418-00014	OIL PRESSURE TRANSMITTER	ARMTEC/EDISON
418-00041	OIL PRESSURE TRANSMITTER	ARMTEC
418-00044	OIL PRESSURE TRANSMITTER	ARMTEC
418-00141	OIL PRESSURE TRANSMITTER	ARMTEC
418-00453-102	UCC PA 155P CONTROL UNIT	SFIM INDUSTRIES
418-00453-202	UCC PA 155P CONTROL UNIT	SFIM INDUSTRIES
418-00453-500	UCC PA 155P CONTROL UNIT	SFIM INDUSTRIES
418-00453-600	UCC PA 155P CONTROL UNIT	SFIM INDUSTRIES
418-00453-800	UCC PA 155P CONTROL UNIT	SFIM INDUSTRIES
418-00453-810	UCC PA 155P CONTROL UNIT	SFIM INDUSTRIES
418-04124	OIL/FUEL PRESSURE TRANSMITTER	EDISON/ARMTEC
418-05124	OIL/FUEL PRESSURE TRANSMITTER	EDISON/ARMTEC
418-06124	OIL/FUEL PRESSURE TRANSMITTER	EDISON/ARMTEC
418-17054	FUEL PRESSURE TRANSMITTER	MEGGITT
418-20044	OIL PRESSURE TRANSMITTER	EDISON
418-24054	FUEL PRESSURE TRANSMITTER	EDISON
4191695	RETRACTABLE LANDING LIGHT	ZODIAC AEROSPACE
42D109-1A	ENGINE OIL FILTER DIFFERENTIAL PRESSURE SWITCH	CUSTOM CONTROL SEN
42-091-3	SPOILER CONTROL UNIT	CRANE
42-109	SKID CONTROL BOX	HYDRO AIRE
421-1-000-1B	COFFEE MAKER DA5 SERIES	BE AEROSPACE
4236534	RUNWAY TURN-OFF LIGHT	ZODIAC AEROSPACE
425-0001-7	COFFEE MAKER	B/E AEROSPACE
425-0001-11	COFFEE MAKER	B/E AEROSPACE
4-254-02	BATTERY CHARGER	CRANE ELDEC CORP
4-254-03	BATTERY CHARGER	CRANE ELDEC CORP
4-254-04	BATTERY CHARGER	CRANE ELDEC CORP
4289452	WING SCAN LIGHT	TELEFLEX-SYNERAVIA
4289453	WING SCAN LIGHT	TELEFLEX-SYNERAVIA
4289454	WING SCAN LIGHT	TELEFLEX-SYNERAVIA
4289455	WING SCAN LIGHT	TELEFLEX-SYNERAVIA
4289456	WING SCAN LIGHT	TELEFLEX-SYNERAVIA
4289457	WING SCAN LIGHT	TELEFLEX-SYNERAVIA
4289458	WING SCAN LIGHT	TELEFLEX-SYNERAVIA
4289459	WING SCAN LIGHT	TELEFLEX-SYNERAVIA
4289460	WING SCAN LIGHT	TELEFLEX-SYNERAVIA
4289461	WING SCAN LIGHT	TELEFLEX-SYNERAVIA
4289462	WING SCAN LIGHT	TELEFLEX-SYNERAVIA
4289463	WING SCAN LIGHT	TELEFLEX-SYNERAVIA
4289464	WING SCAN LIGHT	TELEFLEX-SYNERAVIA
4289465	WING SCAN LIGHT	TELEFLEX-SYNERAVIA
4289466	WING SCAN LIGHT	TELEFLEX-SYNERAVIA
4289467	WING SCAN LIGHT	TELEFLEX-SYNERAVIA
4289468	WING SCAN LIGHT	TELEFLEX-SYNERAVIA
430M1	EMERGENCY WARNING HORN	FARADAY, INC.
4300167 LH	LOGO LIGHT (INBOARD)	TELEFLEX-SYNERAVIA
4300174 RH	LOGO LIGHT (INBOARD)	TELEFLEX-SYNERAVIA
4300181 LH	LOGO LIGHT (OUTBOARD)	TELEFLEX-SYNERAVIA
4300181A LH	LOGO LIGHT (OUTBOARD)	TELEFLEX-SYNERAVIA
4300197 RH	LOGO LIGHT (OUTBOARD)	TELEFLEX-SYNERAVIA
4300197A RH	LOGO LIGHT (OUTBOARD)	TELEFLEX-SYNERAVIA
4305990020	WHEEL PRESSURE TRANSDUCER	SAFRAN MESSIER
4305990040	WHEEL PRESSURE TRANSDUCER	SAFRAN MESSIER
4305990050	PRESSURE SENSOR	SAFRAN MESSIER
4305990070	PRESSURE SENSOR	SAFRAN MESSIER
4305990071	PRESSURE SENSOR	SAFRAN MESSIER

PART NUMBER	DESCRIPTION	OEM
4310000-00-55	HIGH SPEED OVEN DF110/115	BE AEROSPACE
4311500-00-55-00	HIGH SPEED OVEN DF110/115	BE AEROSPACE
4311501-00-55-00	HIGH SPEED OVEN DF110/115	BE AEROSPACE
4313100-00-66-00	3000/3075 OVEN SERIES	B/E AEROSPACE
4313100-01-6600	3000/3075 OVEN SERIES	B/E AEROSPACE
4313101-00-66-00	3000/3075 OVEN SERIES	B/E AEROSPACE
4313101-01-6600	3000/3075 OVEN SERIES	B/E AEROSPACE
4315542	RETRACTABLE LANDING LIGHT	ZODIAC AEROSPACE
4318746 LH	LOGO LIGHT (INBOARD)	TELEFLEX-SYNERAVIA
4318769 RH	LOGO LIGHT (INBOARD)	TELEFLEX-SYNERAVIA
4322245 RH	LOGO LIGHT (OUTBOARD)	TELEFLEX-SYNERAVIA
4322252 LH	LOGO LIGHT (OUTBOARD)	TELEFLEX-SYNERAVIA
4322268 RH	LOGO LIGHT (INBOARD)	TELEFLEX-SYNERAVIA
4322275 LH	LOGO LIGHT (INBOARD)	TELEFLEX-SYNERAVIA
4323070-00-66-26	3000/3075 OVEN SERIES	B/E AEROSPACE
4323070-01-6626	3000/3075 OVEN SERIES	B/E AEROSPACE
4323071-00-66-26	3000/3075 OVEN SERIES	B/E AEROSPACE
4323071-01-6626	3000/3075 OVEN SERIES	B/E AEROSPACE
4323100-00-66-22	3000/3075 OVEN SERIES	B/E AEROSPACE
4323100-01-6622	3000/3075 OVEN SERIES	B/E AEROSPACE
4323101-00-66-22	3000/3075 OVEN SERIES	B/E AEROSPACE
4323101-01-6622	3000/3075 OVEN SERIES	B/E AEROSPACE
4331772	RETRACTABLE LANDING LIGHT	ZODIAC AEROSPACE
4333100-00-66-00	3000/3075 OVEN SERIES	B/E AEROSPACE
4333100-01-6600	3000/3075 OVEN SERIES	B/E AEROSPACE
4333101-00-66-00	3000/3075 OVEN SERIES	B/E AEROSPACE
4333101-01-6600	3000/3075 OVEN SERIES	B/E AEROSPACE
4333302	LOGO LIGHT	ZODIAC AEROSPACE
4333318	LOGO LIGHT	ZODIAC AEROSPACE
4333325	LOGO LIGHT	ZODIAC AEROSPACE
4333332	LOGO LIGHT	ZODIAC AEROSPACE
4360004-80SQ18	WATER HEATER DR4180 SERIES	B/E AEROSPACE
4360004-80-00-18	WATER HEATER DR4180 SERIES	B/E AEROSPACE
4360004-80-00-25	WATER HEATER DR4180 SERIES	B/E AEROSPACE
4360004-81-00-18	WATER HEATER DR4180 SERIES	B/E AEROSPACE
4360004-85-00-18	WATER HEATER DR4180 SERIES	B/E AEROSPACE
4360004-86-00-18	WATER HEATER DR4180 SERIES	B/E AEROSPACE
4360004-87-00-18	WATER HEATER DR4180 SERIES	B/E AEROSPACE
4360004-88-00-18	WATER HEATER DR4180 SERIES	B/E AEROSPACE
45D16	SWITCH, GAGE PRESSURE	CUSTOM CONTROL SEN
45D16-1	SWITCH, GAGE PRESSURE	CUSTOM CONTROL SEN
45-0083-1	RETRACTABLE AIRCRAFT LANDING LIGHT	HONEYWELL
45-0083-2	RETRACTABLE AIRCRAFT LANDING LIGHT	HONEYWELL
45-0083-3	RETRACTABLE AIRCRAFT LANDING LIGHT	HONEYWELL
45-0083-5	RETRACTABLE AIRCRAFT LANDING LIGHT	HONEYWELL
45-0083-7	RETRACTABLE AIRCRAFT LANDING LIGHT	HONEYWELL
45-0351-1	RETRACTABLE LANDING LIGHT	HONEYWELL
45-0351-2	RETRACTABLE LANDING LIGHT	HONEYWELL
45-0351-3	RETRACTABLE LANDING LIGHT	HONEYWELL
45-0351-4	RETRACTABLE LANDING LIGHT	HONEYWELL
45-0351-5	RETRACTABLE LANDING LIGHT	HONEYWELL
45-0351-6	RETRACTABLE LANDING LIGHT	HONEYWELL
453-5000	C406-2 SERIES ELT	COBHAM
453-5001	C406-2 SERIES ELT	COBHAM
453-5002	C406-1 SERIES ELT	ARTEX
453-5003	C406-1 SERIES ELT	ARTEX
4603KPS-23-5	PRESSURE SWITCH	MEGGITT
4604KPS-27-40	PRESSURE SWITCH	MEGGITT
467-0001-1	COFFEE MAKER	BE AEROSPACE
467-0001-7	COFFEE MAKER	BE AEROSPACE
472565	FIRE/OVERHEAT DETECTORS	KIDDE AEROSPACE
472566	FIRE/OVERHEAT DETECTORS	KIDDE AEROSPACE
472567	FIRE/OVERHEAT DETECTORS	KIDDE AEROSPACE
472568	FIRE/OVERHEAT DETECTORS	KIDDE AEROSPACE
472568-1	FIRE/OVERHEAT DETECTORS	KIDDE AEROSPACE
472568-1M	FIRE/OVERHEAT DETECTORS	KIDDE AEROSPACE
472581	FIRE/OVERHEAT DETECTORS	KIDDE AEROSPACE

PART NUMBER	DESCRIPTION	OEM
472581-1	FIRE/OVERHEAT DETECTORS	KIDDE AEROSPACE
472581-2	FIRE/OVERHEAT DETECTORS	KIDDE AEROSPACE
472582	FIRE/OVERHEAT DETECTORS	KIDDE AEROSPACE
472582-1	FIRE/OVERHEAT DETECTORS	KIDDE AEROSPACE
472583	FIRE/OVERHEAT DETECTORS	KIDDE AEROSPACE
472583-1	FIRE/OVERHEAT DETECTORS	KIDDE AEROSPACE
472584	FIRE/OVERHEAT DETECTORS	KIDDE AEROSPACE
472584-1	FIRE/OVERHEAT DETECTORS	KIDDE AEROSPACE
472619	FIRE/OVERHEAT DETECTORS	KIDDE AEROSPACE
472621	FIRE/OVERHEAT DETECTORS	KIDDE AEROSPACE
473108	OPEN-AREA SMOKE-DETECTOR ASSEMBLY	KIDDE AEROSPACE
473108-02	OPEN-AREA SMOKE-DETECTOR ASSEMBLY	KIDDE AEROSPACE
473108-1	OPEN-AREA SMOKE-DETECTOR ASSEMBLY	KIDDE AEROSPACE
473108-1-03	OPEN-AREA SMOKE-DETECTOR ASSEMBLY	KIDDE AEROSPACE
473108-2	OPEN-AREA SMOKE-DETECTOR ASSEMBLY	KIDDE AEROSPACE
473597-X	SMOKE DETECTOR	KIDDE AEROSPACE
473597-2	MODEL 2000 SMOKE DETECTOR ASSEMBLY	KIDDE AEROSPACE
473597-4	MODEL 2000 SMOKE DETECTOR ASSEMBLY	KIDDE AEROSPACE
473597-4-01	MODEL 2000 SMOKE DETECTOR ASSEMBLY	KIDDE AEROSPACE
473597-4-02	MODEL 2000 SMOKE DETECTOR ASSEMBLY	KIDDE AEROSPACE
473597-4-03	MODEL 2000 SMOKE DETECTOR ASSEMBLY	KIDDE AEROSPACE
473597-4-04	MODEL 2000 SMOKE DETECTOR ASSEMBLY	KIDDE AEROSPACE
473597-4-05	MODEL 2000 SMOKE DETECTOR ASSEMBLY	KIDDE AEROSPACE
473597-4-06	MODEL 2000 SMOKE DETECTOR ASSEMBLY	KIDDE AEROSPACE
473597-4-07	MODEL 2000 SMOKE DETECTOR ASSEMBLY	KIDDE AEROSPACE
473597-14	SMOKE DETECTOR	KIDDE AEROSPACE
473597-15	SMOKE DETECTOR ASSEMBLY	KIDDE AEROSPACE
473597-22	SMOKE DETECTOR	KIDDE AEROSPACE
473955-1	CARGO BAY DETECTION/SUPPRESSION PANEL	KIDDE AEROSPACE
473955-1 MOD 01	CARGO BAY DETECTION/SUPPRESSION PANEL	KIDDE AEROSPACE
473955-9	CARGO BAY DETECTION/SUPPRESSION PANEL	KIDDE AEROSPACE
473955-15	CARGO BAY DETECTION/SUPPRESSION PANEL	KIDDE AEROSPACE
474278	MAIN DECK SMOKE DETECTION PANEL	KIDDE AEROSPACE
500U029	EXHAUST GAS TEMPERATURE (EGT) / T3 HARNESS	HARCO LABORATORIES
500-0443-01	CONTROL BOX ASSEMBLY, MODEL 500-443	TIA (RICHARDS CORP)
500-0444-01	OVEN ASSEMBLY, MODEL 1543	TIA (RICHARDS CORP)
500-0454-01	COFFEE BREWER (MODEL 1448 SERIES)	TIA (RICHARDS CORP)
500-0454-02	COFFEE BREWER (MODEL 1448 SERIES)	TIA (RICHARDS CORP)
500-0454-04	COFFEE BREWER (MODEL 1448 SERIES)	TIA (RICHARDS CORP)
5001396-01	THERMOCOUPLE BOX AND CABLE	PRATT & WHITNEY
500-387	COFFEE BREWER	TIA (RICHARDS CORP)
500-443	CONTROL BOX ASSEMBLY, MODEL 500-443	TIA (RICHARDS CORP)
50080	SHUTOFF VALVE	LAMAR ELECTRO-AIR
50234	HYDRAULIC PRESSURE TRANSMITTER	ROGERSON KRATOS
50234-1	HYDRAULIC PRESSURE TRANSMITTER	ROGERSON KRATOS
5034-1	AUDIO SELECTOR PANEL	AVTECH CORP
50405-200	COFFEE MAKER	B/E AEROSPACE
50405-201	COFFEE MAKER	B/E AEROSPACE
50460	COFFEE MAKER	B/E AEROSPACE
50629	HYDRAULIC PRESSURE TRANSMITTER	ROGERSON KRATOS
50629-1	HYDRAULIC PRESSURE TRANSMITTER	ROGERSON KRATOS
50648	WATER QUANTITY TRANSMITTER	ROGERSON KRATOS
50648-1	WATER QUANTITY TRANSMITTER	ROGERSON KRATOS
51U552	IMMERSION THERMOCOUPLE	HARCO LABORATORIES
5142-1	COCKPIT SPEAKER ASSEMBLY	AVTECH
1184118	COCKPIT SPEAKER ASSEMBLY	AVTECH
1185237	AUDIO CONTROL PANEL	AVTECHTYEE
5145-1-24A	AUDIO CONTROL PANEL	AVTECHTYEE
1185217	AUDIO CONTROL PANEL	AVTECHTYEE
5145-1-4A	AUDIO CONTROL PANEL	AVTECHTYEE
5145-1-40	AUDIO CONTROL PANEL	AVTECHTYEE
5145-1-40A	AUDIO CONTROL PANEL	AVTECHTYEE
5145-1-42	AUDIO CONTROL PANEL	AVTECH
5145-1-42 MOD A	AUDIO CONTROL PANEL	AVTECH
5145-1-42 MOD B	AUDIO CONTROL PANEL	AVTECH
5145-1-42 MOD C	AUDIO CONTROL PANEL	AVTECH
5145-1-42 MOD D	AUDIO CONTROL PANEL	AVTECH

PART NUMBER	DESCRIPTION	OEM
5145-1-43	AUDIO CONTROL PANEL	AVTECHTYEE
5145-1-43A	AUDIO CONTROL PANEL	AVTECHTYEE
5145-1-44	AUDIO CONTROL PANEL	AVTECHTYEE
5145-1-44A	AUDIO CONTROL PANEL	AVTECHTYEE
5145-1-46	AUDIO CONTROL PANEL	AVTECHTYEE
5145-1-46A	AUDIO CONTROL PANEL	AVTECHTYEE
5145-1-47	AUDIO CONTROL PANEL	AVTECHTYEE
5145-1-47A	AUDIO CONTROL PANEL	AVTECHTYEE
5145-1-48	AUDIO CONTROL PANEL	AVTECHTYEE
5145-1-48A	AUDIO CONTROL PANEL	AVTECHTYEE
5145-1-60	AUDIO CONTROL PANEL	AVTECHTYEE
5145-1-60A	AUDIO CONTROL PANEL	AVTECHTYEE
5145-1-61	AUDIO CONTROL PANEL	AVTECHTYEE
5145-1-61A	AUDIO CONTROL PANEL	AVTECHTYEE
5145-1-62A	AUDIO CONTROL PANEL	AVTECHTYEE
5145-1-62B	AUDIO CONTROL PANEL	AVTECHTYEE
5145-1-63	AUDIO CONTROL PANEL	AVTECHTYEE
5145-1-63A	AUDIO CONTROL PANEL	AVTECHTYEE
5145-1-64	AUDIO CONTROL PANEL	AVTECHTYEE
5145-1-64 MOD A	AUDIO CONTROL PANEL	AVTECHTYEE
5145-1-64 MOD B	AUDIO CONTROL PANEL	AVTECHTYEE
5145-1-65	AUDIO CONTROL PANEL	AVTECHTYEE
5145-1-65A	AUDIO CONTROL PANEL	AVTECHTYEE
5145-1-66	AUDIO CONTROL PANEL	AVTECH
5145-1-66 MOD A	AUDIO CONTROL PANEL	AVTECH
5145-1-66 MOD B	AUDIO CONTROL PANEL	AVTECH
5145-1-66 MOD C	AUDIO CONTROL PANEL	AVTECH
5145-1-66 MOD D	AUDIO CONTROL PANEL	AVTECH
5145-1-69	AUDIO CONTROL PANEL	AVTECH
5145-1-69 MOD A	AUDIO CONTROL PANEL	AVTECH
5145-1-69 MOD B	AUDIO CONTROL PANEL	AVTECH
5145-1-69 MOD C	AUDIO CONTROL PANEL	AVTECH
5145-1-69 MOD D	AUDIO CONTROL PANEL	AVTECH
5145-1-70	AUDIO CONTROL PANEL	AVTECHTYEE
5145-1-70A	AUDIO CONTROL PANEL	AVTECHTYEE
5145-1-71	AUDIO CONTROL PANEL	AVTECHTYEE
5145-1-71A	AUDIO CONTROL PANEL	AVTECHTYEE
5145-1-75	AUDIO CONTROL PANEL	AVTECH
5145-1-75 MOD A	AUDIO CONTROL PANEL	AVTECH
516029-1	ALTERNATING CURRENT MOTOR	HONEYWELL
516029-2	ALTERNATING CURRENT MOTOR	HONEYWELL
52U004	EXHAUST GAS TEMPERATURE (EGT) / T3 HARNESS	HARCO LABORATORIES
520487	TACHOMETER, APU & EXHAUST GAS TEMP, APU IND	AMETEK
520488	TACHOMETER, APU & EXHAUST GAS TEMP, APU IND	AMETEK
520576	CONSTANT SPEED DRIVE OIL TEMP INDICATOR	WESTON INSTRUMENT
521163	EXHAUST GAS TEMPERATURE APU INDICATOR	AMETEK
521205 (Bench Test Only)	PNEUMATIC TEMPERATURE INDICATOR	WESTON INSTRUMENT
521205	PNEUMATIC TEMPERATURE INDICATOR	WESTON INSTRUMENT
522-1261-00	RADIO SET CONTROL	ROCKWELL COLLINS
522-1859-003	DISTANCE INDICATOR	ROCKWELL COLLINS
522-1859-013	DISTANCE INDICATOR	ROCKWELL COLLINS
522-1859-023	DISTANCE INDICATOR	ROCKWELL COLLINS
522-1859-033	DISTANCE INDICATOR	ROCKWELL COLLINS
522-1859-043	DISTANCE INDICATOR	ROCKWELL COLLINS
522-1859-053	DISTANCE INDICATOR	ROCKWELL COLLINS
522-1859-063	DISTANCE INDICATOR	ROCKWELL COLLINS
522-1859-064	DISTANCE INDICATOR	ROCKWELL COLLINS
522-1859-065	DISTANCE INDICATOR	ROCKWELL COLLINS
522-1859-066	DISTANCE INDICATOR	ROCKWELL COLLINS
522-1859-067	DISTANCE INDICATOR	ROCKWELL COLLINS
522-1859-068	DISTANCE INDICATOR	ROCKWELL COLLINS
522-1859-069	DISTANCE INDICATOR	ROCKWELL COLLINS
522-1859-070	DISTANCE INDICATOR	ROCKWELL COLLINS
522-1859-071	DISTANCE INDICATOR	ROCKWELL COLLINS
522-2213-00	RADIO SET CONTROL	ROCKWELL COLLINS
522-2213-011	RADIO SET CONTROL	ROCKWELL COLLINS
522-2213-012	RADIO SET CONTROL	ROCKWELL COLLINS

PART NUMBER	DESCRIPTION	OEM
522-2604-023	DISTANCE INDICATOR	ROCKWELL COLLINS
522-2604-024	DISTANCE INDICATOR	ROCKWELL COLLINS
522-2604-025	DISTANCE INDICATOR	ROCKWELL COLLINS
522-2604-026	DISTANCE INDICATOR	ROCKWELL COLLINS
522-2892-00	RADIO SET CONTROL	ROCKWELL COLLINS
522-2892-011	RADIO SET CONTROL	ROCKWELL COLLINS
522-2892-012	RADIO SET CONTROL	ROCKWELL COLLINS
522-2892-013	RADIO SET CONTROL	ROCKWELL COLLINS
522-2892-014	RADIO SET CONTROL	ROCKWELL COLLINS
522-2892-015	RADIO SET CONTROL	ROCKWELL COLLINS
522-2892-016	RADIO SET CONTROL	ROCKWELL COLLINS
522-2892-017	RADIO SET CONTROL	ROCKWELL COLLINS
522-2892-018	RADIO SET CONTROL	ROCKWELL COLLINS
522-2919-003	DISTANCE INDICATOR	ROCKWELL COLLINS
522-2919-013	DISTANCE INDICATOR	ROCKWELL COLLINS
522-2919-015	DISTANCE INDICATOR	ROCKWELL COLLINS
522-2919-016	DISTANCE INDICATOR	ROCKWELL COLLINS
522-2920-003	DISTANCE INDICATOR	ROCKWELL COLLINS
522-3343-000	DISTANCE INDICATOR	ROCKWELL COLLINS
522-3343-011	DISTANCE INDICATOR	ROCKWELL COLLINS
522-3343-013	DISTANCE INDICATOR	ROCKWELL COLLINS
522-3903-001	RADIO SET CONTROL	ROCKWELL COLLINS
522-3903-002	RADIO SET CONTROL	ROCKWELL COLLINS
522-4114-002	RADIO ALTITUDE INDICATORS	ROCKWELL COLLINS
522-4114-003	RADIO ALTITUDE INDICATORS	ROCKWELL COLLINS
522-4114-004	RADIO ALTITUDE INDICATORS	ROCKWELL COLLINS
522-4114-006	RADIO ALTITUDE INDICATORS	ROCKWELL COLLINS
522-4114-008	RADIO ALTITUDE INDICATORS	ROCKWELL COLLINS
522-4354-002	RADIO ALTITUDE INDICATORS	ROCKWELL COLLINS
522-4363-004	RADIO ALTITUDE INDICATORS	ROCKWELL COLLINS
522-4825-002	RADIO ALTITUDE INDICATOR	ROCKWELL COLLINS
522-4825-004	RADIO ALTITUDE INDICATOR	ROCKWELL COLLINS
522-4825-005	RADIO ALTITUDE INDICATOR	ROCKWELL COLLINS
522-4825-006	RADIO ALTITUDE INDICATOR	ROCKWELL COLLINS
522-4825-007	RADIO ALTITUDE INDICATOR	ROCKWELL COLLINS
522-4825-008	RADIO ALTITUDE INDICATOR	ROCKWELL COLLINS
522782	VIBRATION MONITOR INDICATOR	AMETEK
53T424	IMMERSION THERMOCOUPLE	HARCO LABORATORIES
538958-1-1	DIFFERENTIAL PRESSURE SENSOR	HONEYWELL
541460-3-1	ROTARY ELECTROMECHANICAL ACTUATOR	HONEYWELL
541674-1-1	RAM AIR MODULATION LINEAR ELECTROMECHANICAL ACTUATOR	HONEYWELL
541674-3	RAM AIR MODULATION LINEAR ELECTROMECHANICAL ACTUATOR	HONEYWELL
541674-4	RAM AIR MODULATION LINEAR ELECTROMECHANICAL ACTUATOR	HONEYWELL
541674-5	RAM AIR MODULATION LINEAR ELECTROMECHANICAL ACTUATOR	HONEYWELL
541674-6	RAM AIR MODULATION LINEAR ELECTROMECHANICAL ACTUATOR	HONEYWELL
542-100001	HEATER CONTROLLER / MONITOR	BOEING
548376-6	CABIN TEMPERATURE CONTROLLER	HONEYWELL
548384-1	ANTICIPATOR/TEMPERATURE SENSORS	HONEYWELL
548384-1 SERIES 1	ANTICIPATOR/TEMPERATURE SENSORS	HONEYWELL
548384-1 SERIES 2	ANTICIPATOR/TEMPERATURE SENSORS	HONEYWELL
548386-1	ANTICIPATOR/TEMPERATURE SENSORS	HONEYWELL
548386-1 SERIES 1	ANTICIPATOR/TEMPERATURE SENSORS	HONEYWELL
548386-1 SERIES 2	ANTICIPATOR/TEMPERATURE SENSORS	HONEYWELL
548388-1	ANTICIPATOR/TEMPERATURE SENSORS	HONEYWELL
548388-1 SERIES 1	ANTICIPATOR/TEMPERATURE SENSORS	HONEYWELL
548388-1 SERIES 2	ANTICIPATOR/TEMPERATURE SENSORS	HONEYWELL
548392-1	ANTICIPATOR/TEMPERATURE SENSORS	HONEYWELL
548392-1 SERIES 1	ANTICIPATOR/TEMPERATURE SENSORS	HONEYWELL
548392-1 SERIES 2	ANTICIPATOR/TEMPERATURE SENSORS	HONEYWELL
548620-2	THERMOSTATIC SWITCHES	GARRETT AIRESEARCH
548620-6	THERMOSTATIC SWITCHES	GARRETT AIRESEARCH
558CA01	T.P.S.T. NO CONTACTOR	ZODIAC AEROSPACE
558CA01Y1	T.P.S.T. NO CONTACTOR	ZODIAC AEROSPACE
558CA04A30Y00	T.P.S.T. NO CONTACTOR	ZODIAC AEROSPACE
558CA04A31Y00	T.P.S.T. NO CONTACTOR	ZODIAC AEROSPACE
558CA04A40Y00	T.P.S.T. NO CONTACTOR	ZODIAC AEROSPACE
558CA04A41Y00	T.P.S.T. NO CONTACTOR	ZODIAC AEROSPACE

PART NUMBER	DESCRIPTION	OEM
559CA01Y1	T.P.S.T. NO CONTACTOR	ZODIAC AEROSPACE
56B17	RESISTANCE TEMPERATURE DETECTOR	LEWIS ENGINEERING
56B3A	RESISTANCE TEMPERATURE DETECTOR	LEWIS ENGINEERING
56B4A	RESISTANCE TEMPERATURE DETECTOR	LEWIS ENGINEERING
564CA01Y1	T.P.S.T. NO CONTACTOR	ZODIAC AEROSPACE
564CA02FY1	T.P.S.T. NO CONTACTOR	ZODIAC AEROSPACE
564CA04A01Y00	T.P.S.T. NO CONTACTOR	ZODIAC AEROSPACE
564CA04A10Y00	T.P.S.T. NO CONTACTOR	ZODIAC AEROSPACE
564CA04A11Y00	T.P.S.T. NO CONTACTOR	ZODIAC AEROSPACE
564CA04A20Y00	T.P.S.T. NO CONTACTOR	ZODIAC AEROSPACE
564CA04A21Y00	T.P.S.T. NO CONTACTOR	ZODIAC AEROSPACE
564CA04F10Y00	T.P.S.T. NO CONTACTOR	ZODIAC AEROSPACE
564CA04F11Y00	T.P.S.T. NO CONTACTOR	ZODIAC AEROSPACE
564CA04F11Y01	T.P.S.T. NO CONTACTOR	ZODIAC AEROSPACE
564CA04F20Y00	T.P.S.T. NO CONTACTOR	ZODIAC AEROSPACE
564CA04F21Y00	T.P.S.T. NO CONTACTOR	ZODIAC AEROSPACE
5701195-501	FUSELAGE AIR OUTFLOW BUTTERFLY VALVE ASSY	BOEING
570-487	FREQUENCY METER	HICKOK
572756-1	THERMAL SWITCH	HONEYWELL
572757-1	TURBINE INLET THERMAL SWITCH	ALLIED SIGNAL
59T255	EXHAUST GAS TEMPERATURE (EGT) / T3 HARNESS	HARCO LABORATORIES
5914613-3	APU FIRE DETECTOR ASSEMBLY	BOEING
5914613-5	APU FIRE DETECTOR ASSEMBLY	BOEING
5914613-25	APU FIRE DETECTOR ASSEMBLY	BOEING
5914613-45	APU FIRE DETECTOR ASSEMBLY	BOEING
5938323-501	BURN-THRU BARRIER FIRE DETECTOR ASSEMBLY	BOEING
5938323-502	BURN-THRU BARRIER FIRE DETECTOR ASSEMBLY	BOEING
5938323-503	BURN-THRU BARRIER FIRE DETECTOR ASSEMBLY	BOEING
5938323-504	BURN-THRU BARRIER FIRE DETECTOR ASSEMBLY	BOEING
5938323-505	BURN-THRU BARRIER FIRE DETECTOR ASSEMBLY	BOEING
5938323-506	BURN-THRU BARRIER FIRE DETECTOR ASSEMBLY	BOEING
5938323-507	BURN-THRU BARRIER FIRE DETECTOR ASSEMBLY	BOEING
5938323-508	BURN-THRU BARRIER FIRE DETECTOR ASSEMBLY	BOEING
593-8655-001	RADIO SET CONTROL	ROCKWELL COLLINS
5956888-1	FLIGHT COMPARTMENT CENTER INSTRUMENT & PEDESTAL LIGHT CONTROL ASSY	BOEING
5956888-501	FLIGHT COMPARTMENT CENTER INSTRUMENT & PEDESTAL LIGHT CONTROL ASSY	BOEING
5956888-503	FLIGHT COMPARTMENT CENTER INSTRUMENT & PEDESTAL LIGHT CONTROL ASSY	BOEING
5956888-505	FLIGHT COMPARTMENT CENTER INSTRUMENT & PEDESTAL LIGHT CONTROL ASSY	BOEING
5956888-507	FLIGHT COMPARTMENT CENTER INSTRUMENT & PEDESTAL LIGHT CONTROL ASSY	BOEING
5956888-509	FLIGHT COMPARTMENT CENTER INSTRUMENT & PEDESTAL LIGHT CONTROL ASSY	BOEING
5956888-511	FLIGHT COMPARTMENT CENTER INSTRUMENT & PEDESTAL LIGHT CONTROL ASSY	BOEING
5958570-1	ENGINE FIRE DETECTOR ELEMENT SUPPORT ASSY	BOEING
6RW176YN3	TRANSFORMER RECTIFIER	L3 COMMUNICATIONS
60B00126-9	EXHAUST GAS TEMPERATURE APU INDICATOR	AMETEK
60B00226-3	MODULAR ASSY, RESERVOIR PRESSURIZATION	SHIMADZU CORP
60B00226-5	MODULAR ASSY, RESERVOIR PRESSURIZATION	SHIMADZU CORP
60B00226-7	MODULAR ASSY, RESERVOIR PRESSURIZATION	SHIMADZU CORP
60B00226-8	MODULAR ASSY, RESERVOIR PRESSURIZATION	SHIMADZU CORP
60B00226-9	MODULAR ASSY, RESERVOIR PRESSURIZATION	SHIMADZU CORP
60B00279-1	PRESSURE SWITCH	EATON
60B00279-2	PRESSURE SWITCH	EATON
60B00303-105	DIGITAL ELECTRONIC CHRONOMETER	GE AVIATION
60B40025	FLUORESCENT LAMP BALLASTS	DAY-RAY PRODUCTS
60B40048-1	MOTOR OPERATED AIR SHUTOFF VALVE	HONEYWELL
60B40085-2	VOLTAGE AVERAGING MODULE	CURTISS-WRIGHT
60B50058-3	TOILET TIMER SWITCH	LEACH INTERNATIONAL
60B50058-4	TOILET TIMER SWITCH	LEACH INTERNATIONAL
60B50058-5	TOILET TIMER SWITCH	LEACH INTERNATIONAL
60B50058-6	TOILET TIMER SWITCH	LEACH INTERNATIONAL
60B50402-2	WATER QUANTITY TRANSMITTER	ROGERSON KRATOS
60B50402-16	WATER QUANTITY TRANSMITTER	ROGERSON KRATOS
60B92018-10	PRESELECT CONTROL UNIT (PCU)	UTC AEROSPACE SYSTE
60B92400-3	GAGE PRESSURE SWITCH	CUSTOM CONTROL SEN
60B92400-6	GAGE PRESSURE SWITCH	CUSTOM COMPONENT
60B92400-10	LOW FUEL PRESSURE SWITCH	EATON AEROSPACE
60B92400-11	LOW FUEL PRESSURE SWITCH	EATON AEROSPACE
6001KPS01	PRESSURE SWITCH	MEGGITT

PART NUMBER	DESCRIPTION	OEM
6002089	BTMS MONITOR	LORAL
6002089-1	BTMS MONITOR	LORAL
6002089-2	BTMS MONITOR	LORAL
6002701	SENSOR ASSEMBLY	AIRCRAFT BRAKING SYS
60-0304-31	RECHARGEABLE POWER FAILURE BATTERY POWER SUPPLY	HONEYWELL
60-0304-33	RECHARGEABLE POWER FAILURE BATTERY POWER SUPPLY	HONEYWELL
60-0304-51	RECHARGEABLE POWER FAILURE BATTERY POWER SUPPLY	HONEYWELL
60-1177-5	RECHARGEABLE BATTERY POWER SUPPLY	GRIMES AEROSPACE
60-1177-7	RECHARGEABLE BATTERY POWER SUPPLY	GRIMES AEROSPACE
60-1177-9	RECHARGEABLE BATTERY POWER SUPPLY	GRIMES AEROSPACE
602T	DYNAMIC HANDHELD MICROPHONE	ELECTRO VOICE
602TR	DYNAMIC MICROPHONE	ELECTRO VOICE
602-3374	DYNAMIC HANDHELD MICROPHONE	ELECTRO VOICE
602-3375	DYNAMIC HANDHELD MICROPHONE	ELECTRO VOICE
602-3376	DYNAMIC HANDHELD MICROPHONE	ELECTRO VOICE
60-3368-7	STROBE LIGHT POWER SUPPLY	HONEYWELL
6042H152	RELAY	EATON AEROSPACE
605457-7	MOTOR DRIVEN CENTRIFUGAL FAN	HONEYWELL
605675-1	MOTOR DRIVEN VANEAXIAL FAN	HONEYWELL
605675-2	MOTOR DRIVEN VANEAXIAL FAN	HONEYWELL
607400-1 SERIES 1	TEMPERATURE SELECTOR	HONEYWELL
607400-2 SERIES 1	TEMPERATURE SELECTOR	HONEYWELL
607400-3 SERIES 1	TEMPERATURE SELECTOR	HONEYWELL
607512-1	ANTICIPATOR/TEMPERATURE SENSORS	HONEYWELL
607512-1 SERIES 1	ANTICIPATOR/TEMPERATURE SENSORS	HONEYWELL
607518-2	TEMP CONTROL	HONEYWELL
609054	MOUNTING RAIL (COFFEE MAKER DA12 SERIES)	BE AEROSPACE
609200-01	THERMOCOUPLE CABLE ASSEMBLIES	AMETEK AEROSPACE
609201-01	THERMOCOUPLE CABLE ASSEMBLIES	AMETEK AEROSPACE
609609	MOUNTING RAIL ASSEMBLY	BE AEROSPACE
609635	MOUNTING RAIL ASSEMBLY	BE AEROSPACE
609642	MOUNTING RAIL ASSEMBLY	BE AEROSPACE
609669	MOUNTING RAIL ASSEMBLY	BE AEROSPACE
609767	OVEN CONTROL MODULE 700 SERIES	BE AEROSPACE
610318	OVEN CONTROL MODULE 700 SERIES	BE AEROSPACE
610915	OVEN CONTROL MODULE 700 SERIES	BE AEROSPACE
611004	OVEN CONTROL MODULE 700 SERIES	BE AEROSPACE
611527	OVEN CONTROL MODULE 700 SERIES	BE AEROSPACE
611529	OVEN CONTROL MODULE 700 SERIES	BE AEROSPACE
611530	OVEN CONTROL MODULE 700 SERIES	BE AEROSPACE
611636	OVEN CONTROL MODULE 700 SERIES	BE AEROSPACE
611911	OVEN CONTROL MODULE 700 SERIES	BE AEROSPACE
61-21-1	FLUORESCENT LAMP BALLASTS	DAY-RAY PRODUCTS
61-21-2	FLUORESCENT LAMP BALLASTS	DAY-RAY PRODUCTS
61-21-3	FLUORESCENT LAMP BALLASTS	DAY-RAY PRODUCTS
61-21-4	FLUORESCENT LAMP BALLASTS	DAY-RAY PRODUCTS
61-25-1	FLUORESCENT LAMP BALLASTS	DAY-RAY PRODUCTS
61-25-2	FLUORESCENT LAMP BALLASTS	DAY-RAY PRODUCTS
61-36	FLUORESCENT LAMP BALLASTS	DAY-RAY PRODUCTS
61-36-1	FLUORESCENT LAMP BALLASTS	DAY-RAY PRODUCTS
61-36-2	FLUORESCENT LAMP BALLASTS	DAY-RAY PRODUCTS
61-37	FLUORESCENT LAMP BALLASTS	DAY-RAY PRODUCTS
61-37-1	FLUORESCENT LAMP BALLASTS	DAY-RAY PRODUCTS
61-38	FLUORESCENT LAMP BALLASTS	DAY-RAY PRODUCTS
61-38-1	FLUORESCENT LAMP BALLASTS	DAY-RAY PRODUCTS
61-39	FLUORESCENT LAMP BALLASTS	DAY-RAY PRODUCTS
61-39-1	FLUORESCENT LAMP BALLASTS	DAY-RAY PRODUCTS
614E-5A	AUTOPILOT CONTROLLER	ROCKWELL COLLINS
614E-20R	FLIGHT MODE SELECTOR	ROCKWELL COLLINS
614E-20S	FLIGHT MODE SELECTOR	ROCKWELL COLLINS
614E-23R	FLIGHT MODE SELECTOR	ROCKWELL COLLINS
614E-37	FLIGHT MODE SELECTOR	ROCKWELL COLLINS
61-40	FLUORESCENT LAMP BALLASTS	DAY-RAY PRODUCTS
61-40-1	FLUORESCENT LAMP BALLASTS	DAY-RAY PRODUCTS
614107	THERMOCOUPLE BOX AND CABLE	PRATT & WHITNEY
61-42	FLUORESCENT LAMP BALLASTS	DAY-RAY PRODUCTS
61-42-1	FLUORESCENT LAMP BALLASTS	DAY-RAY PRODUCTS

PART NUMBER	DESCRIPTION	OEM
61-42-3	FLUORESCENT LAMP BALLASTS	DAY-RAY PRODUCTS
61-43	FLUORESCENT LAMP BALLASTS	DAY-RAY PRODUCTS
61-43-1	FLUORESCENT LAMP BALLASTS	DAY-RAY PRODUCTS
61-46	FLUORESCENT LAMP BALLASTS	DAY-RAY PRODUCTS
61-46-1	FLUORESCENT LAMP BALLASTS	DAY-RAY PRODUCTS
61-47	FLUORESCENT LAMP BALLASTS	DAY-RAY PRODUCTS
61-47-1	FLUORESCENT LAMP BALLASTS	DAY-RAY PRODUCTS
61-48	FLUORESCENT LAMP BALLASTS	DAY-RAY PRODUCTS
61-48-1	FLUORESCENT LAMP BALLASTS	DAY-RAY PRODUCTS
61-48-2	FLUORESCENT LAMP BALLASTS	DAY-RAY PRODUCTS
614937-10	COMPASS SYSTEM RACK	HONEYWELL
614937-11	COMPASS SYSTEM RACK	HONEYWELL
614937-101	COMPASS SYSTEM RACK	HONEYWELL
61-78A	FLUORESCENT LAMP BALLASTS	DAY-RAY PRODUCTS
61-78A-1	FLUORESCENT LAMP BALLASTS	DAY-RAY PRODUCTS
62-11	FLUORESCENT LAMP BALLASTS	DAY-RAY PRODUCTS
62197-001-001	WATER BOILER	RUMBOLD
62197-101-001	WATER BOILER	RUMBOLD
622-0944-003	FLIGHT MODE SELECTOR	ROCKWELL COLLINS
622-0944-006	FLIGHT MODE SELECTOR	ROCKWELL COLLINS
622-0944-007	FLIGHT MODE SELECTOR	ROCKWELL COLLINS
622-0945-003	FLIGHT MODE SELECTOR	ROCKWELL COLLINS
622-0945-006	FLIGHT MODE SELECTOR	ROCKWELL COLLINS
622-0945-007	FLIGHT MODE SELECTOR	ROCKWELL COLLINS
622-0945-008	FLIGHT MODE SELECTOR	ROCKWELL COLLINS
622-0945-017	FLIGHT MODE SELECTOR	ROCKWELL COLLINS
622-0950-001	FLIGHT MODE SELECTOR	ROCKWELL COLLINS
622-0950-002	FLIGHT MODE SELECTOR	ROCKWELL COLLINS
622-3986-001	RADIO SET CONTROL	ROCKWELL COLLINS
622-3986-002	RADIO SET CONTROL	ROCKWELL COLLINS
622-3986-003	RADIO SET CONTROL	ROCKWELL COLLINS
622-3986-004	RADIO SET CONTROL	ROCKWELL COLLINS
622-3986-005	RADIO SET CONTROL	ROCKWELL COLLINS
622-3987-001	RADIO SET CONTROL	ROCKWELL COLLINS
622-3987-002	RADIO SET CONTROL	ROCKWELL COLLINS
622-3987-003	RADIO SET CONTROL	ROCKWELL COLLINS
622-3987-004	RADIO SET CONTROL	ROCKWELL COLLINS
622-4096-001	AIRCRAFT PASSENGER ADDRESS AMP	ROCKWELL COLLINS
622-4096-002	AIRCRAFT PASSENGER ADDRESS AMP	ROCKWELL COLLINS
622-4096-003	AIRCRAFT PASSENGER ADDRESS AMP	ROCKWELL COLLINS
622-4487-001	AIRCRAFT PASSENGER ADDRESS AMP	ROCKWELL COLLINS
622-4563-001	339H-6 RADIO ALTITUDE INDICATOR	ROCKWELL COLLINS
622-4563-002	339H-6 RADIO ALTITUDE INDICATOR	ROCKWELL COLLINS
622-4563-004	339H-6 RADIO ALTITUDE INDICATOR	ROCKWELL COLLINS
622-4563-005	339H-6 RADIO ALTITUDE INDICATOR	ROCKWELL COLLINS
622-4563-006	339H-6 RADIO ALTITUDE INDICATOR	ROCKWELL COLLINS
622-4563-007	339H-6 RADIO ALTITUDE INDICATOR	ROCKWELL COLLINS
622-4563-008	339H-6 RADIO ALTITUDE INDICATOR	ROCKWELL COLLINS
622-4563-009	339H-6 RADIO ALTITUDE INDICATOR	ROCKWELL COLLINS
622-4563-011	339H-6 RADIO ALTITUDE INDICATOR	ROCKWELL COLLINS
622-5001-104	RDMI-743 RADIO DISTANCE MAGNETIC INDICATOR	ROCKWELL COLLINS
622-5001-106	RDMI-743 RADIO DISTANCE MAGNETIC INDICATOR	ROCKWELL COLLINS
622-5001-107	RDMI-743 RADIO DISTANCE MAGNETIC INDICATOR	ROCKWELL COLLINS
622-5001-108	RDMI-743 RADIO DISTANCE MAGNETIC INDICATOR	ROCKWELL COLLINS
622-5001-109	RDMI-743 RADIO DISTANCE MAGNETIC INDICATOR	ROCKWELL COLLINS
622-5001-110	RDMI-743 RADIO DISTANCE MAGNETIC INDICATOR	ROCKWELL COLLINS
622-5001-111	RDMI-743 RADIO DISTANCE MAGNETIC INDICATOR	ROCKWELL COLLINS
622-5001-112	RDMI-743 RADIO DISTANCE MAGNETIC INDICATOR	ROCKWELL COLLINS
622-5001-113	RDMI-743 RADIO DISTANCE MAGNETIC INDICATOR	ROCKWELL COLLINS
622-5001-114	RDMI-743 RADIO DISTANCE MAGNETIC INDICATOR	ROCKWELL COLLINS
622-5001-501	RDMI-743 RADIO DISTANCE MAGNETIC INDICATOR	ROCKWELL COLLINS
622-5001-502	RDMI-743 RADIO DISTANCE MAGNETIC INDICATOR	ROCKWELL COLLINS
622-5001-503	RDMI-743 RADIO DISTANCE MAGNETIC INDICATOR	ROCKWELL COLLINS
622-5001-504	RDMI-743 RADIO DISTANCE MAGNETIC INDICATOR	ROCKWELL COLLINS
622-5001-601	RDMI-743 RADIO DISTANCE MAGNETIC INDICATOR	ROCKWELL COLLINS
622-5001-602	RDMI-743 RADIO DISTANCE MAGNETIC INDICATOR	ROCKWELL COLLINS
622-5001-701	RDMI-743 RADIO DISTANCE MAGNETIC INDICATOR	ROCKWELL COLLINS

PART NUMBER	DESCRIPTION	OEM
622-5486-001	FLIGHT MODE SELECTOR	ROCKWELL COLLINS
622-5486-011	FLIGHT MODE SELECTOR	ROCKWELL COLLINS
622-6831-001	VHF COMM FREQ PANEL	ROCKWELL COLLINS
622-6831-002	VHF COMM FREQ PANEL	ROCKWELL COLLINS
622-6831-011	VHF COMM FREQ PANEL	ROCKWELL COLLINS
622-6831-012	VHF COMM FREQ PANEL	ROCKWELL COLLINS
622-6831-021	VHF COMM FREQ PANEL	ROCKWELL COLLINS
622-6831-022	VHF COMM FREQ PANEL	ROCKWELL COLLINS
622-8001-001	ELECTRONIC FLIGHT INSTR CONTROL	ROCKWELL COLLINS
622-8001-002	ELECTRONIC FLIGHT INSTR CONTROL	ROCKWELL COLLINS
622-8001-003	ELECTRONIC FLIGHT INSTR CONTROL	ROCKWELL COLLINS
622-8001-330	ELECTRONIC FLIGHT INSTR CONTROL	ROCKWELL COLLINS
622-8001-331	ELECTRONIC FLIGHT INSTR CONTROL	ROCKWELL COLLINS
622-8001-332	ELECTRONIC FLIGHT INSTR CONTROL	ROCKWELL COLLINS
622-8001-350	ELECTRONIC FLIGHT INSTR CONTROL	ROCKWELL COLLINS
622-8001-351	ELECTRONIC FLIGHT INSTR CONTROL	ROCKWELL COLLINS
622-8001-352	ELECTRONIC FLIGHT INSTR CONTROL	ROCKWELL COLLINS
622-8001-353	ELECTRONIC FLIGHT INSTR CONTROL	ROCKWELL COLLINS
62-37	FLUORESCENT LAMP BALLASTS	DAY-RAY PRODUCTS
624016-1 SERIES 1	DUCT AIR TEMPERATURE SENSOR	HONEYWELL
624016-2 SERIES 1	DUCT AIR TEMPERATURE SENSOR	HONEYWELL
624066-3	WINDOW HEAT CONTROL UNIT	HONEYWELL
624066-4	WINDOW HEAT CONTROL UNIT	HONEYWELL
624066-5	WINDOW HEAT CONTROL UNIT	HONEYWELL
624118-1 Series 1	RAM AIR CONTROL SENSOR	HONEYWELL
625HS	MODEL 625HS HANDSET MICROPHONE	ELECTRO-VOICE
625-3011	MODEL 625HS HANDSET MICROPHONE	ELECTRO-VOICE
625-9489	MODEL 625HS HANDSET MICROPHONE	ELECTRO-VOICE
627570-1	ANTICIPATOR/TEMPERATURE SENSORS	HONEYWELL
627570-1 SERIES 1	ANTICIPATOR/TEMPERATURE SENSORS	HONEYWELL
6291	TRANSFORMER (BENCH TEST ONLY)	OECO
630CC01Y1	S.P. NO CONTACTOR	ZODIAC AEROSPACE
630CC04A0Y00	S.P. NO CONTACTOR	ZODIAC AEROSPACE
630CC04A1Y00	S.P. NO CONTACTOR	ZODIAC AEROSPACE
630CC04A2Y00	S.P. NO CONTACTOR	ZODIAC AEROSPACE
63274-000	MODEL HS-500 HANDSET	TELEX
63274-001	MODEL HS-500 HANDSET	TELEX
63274-003	MODEL HS-500 HANDSET	TELEX
63274-004	MODEL HS-500 HANDSET	TELEX
63274-005	MODEL HS-500 HANDSET	TELEX
63274-006	MODEL HS-500 HANDSET	TELEX
63274-008	MODEL HS-500 HANDSET	TELEX
63274-010	MODEL HS-500 HANDSET	TELEX
63274-011	MODEL HS-500 HANDSET	TELEX
63274-012	MODEL HS-500 HANDSET	TELEX
6329E0001-01	ENGINE CONDITION CONTROL MOTOR ACTUATOR	EATON AEROSPACE
63600-250-2	E.G.T. INDICATOR	THALES
63600-251-2	E.G.T. INDICATOR	THALES
63600-252-2	E.G.T. INDICATOR	THALES
63600-253-2	E.G.T. INDICATOR	THALES
63600-254-1	E.G.T. INDICATOR	THALES
63600-255-1	E.G.T. INDICATOR	THALES
63600-256-1	E.G.T. INDICATOR	THALES
63600-257-1	E.G.T. INDICATOR	THALES
63600-258-1	E.G.T. INDICATOR	THALES
63600-259-1	E.G.T. INDICATOR	THALES
63600-260-1	E.G.T. INDICATOR	THALES
63600-261-1	E.G.T. INDICATOR	THALES
640CC01Y1	S.P. NO CONTACTOR	ZODIAC AEROSPACE
640CC04A2Y00	S.P. NO CONTACTOR	ZODIAC AEROSPACE
64050-860-1	AIRSPPEED INDICATOR	THALES
64050-862-1	AIRSPPEED INDICATOR	THALES
64050-866-1	AIRSPPEED INDICATOR	THALES
64050-868-1	AIRSPPEED INDICATOR	THALES
64-1	FLUORESCENT LAMP BALLASTS	DAY-RAY PRODUCTS
64111-960-1	ALTIMETER	THALES
64111-992-1	ALTIMETER	THALES

PART NUMBER	DESCRIPTION	OEM
641121-1	TEMPERTURE SWITCH	ITT AEROSPACE
641127-1	PACK OVERHEAT SWITCH	GARRETT AIRESEARCH
641137-1	TEMPERATURE SWITCH	ITT AEROSPACE
641172-1	PACK DISCHARGE OVERHEAT SWITCH	HONEYWELL/GARRETT
64141-580-1	ALTIMETER	THALES
64141-582-1	ALTIMETER	THALES
64141-590-1	ALTIMETER	THALES
64-21	FLUORESCENT LAMP BALLASTS	DAY-RAY PRODUCTS
6430A	VARIABLE POWER TRANSFORMER	OECO, LLC
64752	BEVERAGE MAKER	RUMBOLD
64752-001-003	BEVERAGE MAKER	RUMBOLD
64753	COFFEE MAKER	ZODIAC AEROSPACE
64753-001-003	COFFEE MAKER	ZODIAC AEROSPACE
64753-001-005	COFFEE MAKER	ZODIAC AEROSPACE
64771-001-003	COFFEE MAKER	RUMBOLD SELL GMBH
64882-206-1	TRIPLE PRESSURE INDICATOR	THALES
65B40647-11	CARGO CONTROL PANEL ASSEMBLY, M545, M546	BAE SYSTEMS
65B40647-13	CARGO CONTROL PANEL ASSEMBLY, M545, M546	BAE SYSTEMS
65B40647-15	CARGO CONTROL PANEL ASSEMBLY, M545, M546	BAE SYSTEMS
65B40647-17	CARGO CONTROL PANEL ASSEMBLY, M545, M546	BAE SYSTEMS
65B40647-19	CARGO CONTROL PANEL ASSEMBLY, M545, M546	BAE SYSTEMS
65B40647-20	CARGO CONTROL PANEL ASSEMBLY, M545, M546	BAE SYSTEMS
65B40647-23	CARGO CONTROL PANEL ASSEMBLY, M545, M546	BAE SYSTEMS
65B40647-24	CARGO CONTROL PANEL ASSEMBLY, M545, M546	BAE SYSTEMS
65B40647-25	CARGO CONTROL PANEL ASSEMBLY, M545, M546	BAE SYSTEMS
65B40647-26	CARGO CONTROL PANEL ASSEMBLY, M545, M546	BAE SYSTEMS
65B40647-30	CARGO CONTROL PANEL ASSEMBLY, M545, M546	BAE SYSTEMS
65B40647-31	CARGO CONTROL PANEL ASSEMBLY, M545, M546	BAE SYSTEMS
65B40647-32	CARGO CONTROL PANEL ASSEMBLY, M545, M546	BAE SYSTEMS
65B40647-33	CARGO CONTROL PANEL ASSEMBLY, M545, M546	BAE SYSTEMS
65B40647-34	CARGO CONTROL PANEL ASSEMBLY, M545, M546	BAE SYSTEMS
65B40647-35	CARGO CONTROL PANEL ASSEMBLY, M545, M546	BAE SYSTEMS
65B40647-36	CARGO CONTROL PANEL ASSEMBLY, M545, M546	BAE SYSTEMS
65B40647-40	CARGO CONTROL PANEL ASSEMBLY, M545, M546	BAE SYSTEMS
65B40647-45	CARGO CONTROL PANEL ASSEMBLY, M545, M546	BAE SYSTEMS
65B40647-46	CARGO CONTROL PANEL ASSEMBLY, M545, M546	BAE SYSTEMS
65B40647-47	CARGO CONTROL PANEL ASSEMBLY, M545, M546	BAE SYSTEMS
65B40647-48	CARGO CONTROL PANEL ASSEMBLY, M545, M546	BAE SYSTEMS
65B40647-50	CARGO CONTROL PANEL ASSEMBLY, M545, M546	BAE SYSTEMS
65B40647-51	CARGO CONTROL PANEL ASSEMBLY, M545, M546	BAE SYSTEMS
65B40647-53	CARGO CONTROL PANEL ASSEMBLY, M545, M546	BAE SYSTEMS
65B40647-54	CARGO CONTROL PANEL ASSEMBLY, M545, M546	BAE SYSTEMS
65B40647-55	CARGO CONTROL PANEL ASSEMBLY, M545, M546	BAE SYSTEMS
65B40647-56	CARGO CONTROL PANEL ASSEMBLY, M545, M546	BAE SYSTEMS
65B40647-56 MOD A	CARGO CONTROL PANEL ASSEMBLY, M545, M546	BAE SYSTEMS
65C33409-1	DIMMING RELAY MODULE ASSEMBLY	BAE SYSTEMS
65C33409-3	DIMMING RELAY MODULE ASSEMBLY	BAE SYSTEMS
65C35322-1	VHF NAV/DME CONTROL PANEL MODULE ASSEMBLY	BAE SYSTEMS
65-0294-1	INDICATOR LIGHT ASSEMBLY	HONEYWELL
65-0294-3	INDICATOR LIGHT ASSEMBLY	HONEYWELL
65-0294-5	INDICATOR LIGHT ASSEMBLY	HONEYWELL
65-0294-7	INDICATOR LIGHT ASSEMBLY	HONEYWELL
65-0294-9	INDICATOR LIGHT ASSEMBLY	HONEYWELL
65-0294-11	INDICATOR LIGHT ASSEMBLY	HONEYWELL
65-0294-13	INDICATOR LIGHT ASSEMBLY	HONEYWELL
65-0294-15	INDICATOR LIGHT ASSEMBLY	HONEYWELL
65-0294-17	INDICATOR LIGHT ASSEMBLY	HONEYWELL
65-0294-19	INDICATOR LIGHT ASSEMBLY	HONEYWELL
65-0294-21	INDICATOR LIGHT ASSEMBLY	HONEYWELL
65-0294-23	INDICATOR LIGHT ASSEMBLY	HONEYWELL
65-0294-25	INDICATOR LIGHT ASSEMBLY	HONEYWELL
655CC01Y1	S.P. NO CONTACTOR	ZODIAC AEROSPACE
655CC01Y2	S.P. NO CONTACTOR	ZODIAC AEROSPACE
655CC04A0Y00	S.P. NO CONTACTOR	ZODIAC AEROSPACE
655CC04A2Y00	S.P. NO CONTACTOR	ZODIAC AEROSPACE
655CC04B2Y00	S.P. NO CONTACTOR	ZODIAC AEROSPACE
65-50909-2	FIRE CONTROL AUXILIARY POWER UNIT ASSY	BOEING

PART NUMBER	DESCRIPTION	OEM
65-52806-348	MISC SOLID STATE SWITCHING ACCY UNIT ASSY M278	BAE SYSTEMS
65-52806-350	MISC SOLID STATE SWITCHING ACCY UNIT ASSY M278	BAE SYSTEMS
65-52806-352	MISC SOLID STATE SWITCHING ACCY UNIT ASSY M278	BAE SYSTEMS
65-52806-354	MISC SOLID STATE SWITCHING ACCY UNIT ASSY M278	BAE SYSTEMS
65-52806-354 MOD A	MISC SOLID STATE SWITCHING ACCY UNIT ASSY M278	BAE SYSTEMS
65-52806-357	MISC SOLID STATE SWITCHING ACCY UNIT ASSY M278	BAE SYSTEMS
65-52806-411	MISC SOLID STATE SWITCHING ACCY UNIT ASSY M278	BAE SYSTEMS
65-52806-412	MISC SOLID STATE SWITCHING ACCY UNIT ASSY M278	BAE SYSTEMS
65-52806-415	MISC SOLID STATE SWITCHING ACCY UNIT ASSY M278	BAE SYSTEMS
65-52806-419	MISC SOLID STATE SWITCHING ACCY UNIT ASSY M278	BAE SYSTEMS
65-52806-420	MISC SOLID STATE SWITCHING ACCY UNIT ASSY M278	BAE SYSTEMS
65-52806-445	MISC SOLID STATE SWITCHING ACCY UNIT ASSY M278	BAE SYSTEMS
65-52806-446	MISC SOLID STATE SWITCHING ACCY UNIT ASSY M278	BAE SYSTEMS
65-52806-447	MISC SOLID STATE SWITCHING ACCY UNIT ASSY M278	BAE SYSTEMS
65-52806-456	MISC SOLID STATE SWITCHING ACCY UNIT ASSY M278	BAE SYSTEMS
65-52806-468	MISC SOLID STATE SWITCHING ACCY UNIT ASSY M278	BAE SYSTEMS
65-52806-470	MISC SOLID STATE SWITCHING ACCY UNIT ASSY M278	BAE SYSTEMS
65-52807-19	LEADING EDGE FLAP & SLAT POSITION INDICATOR ACCESSORY UNIT ASSY, M229	BAE SYSTEMS
65-52807-21	LEADING EDGE FLAP & SLAT POSITION INDICATOR ACCESSORY UNIT ASSY, M229	BAE SYSTEMS
65-52807-26	LEADING EDGE FLAP & SLAT POSITION INDICATOR ACCESSORY UNIT ASSY, M229	BAE SYSTEMS
65-52807-26 MOD A	LEADING EDGE FLAP & SLAT POSITION INDICATOR ACCESSORY UNIT ASSY, M229	BAE SYSTEMS
65-52807-33	LEADING EDGE FLAP & SLAT POSITION INDICATOR ACCESSORY UNIT ASSY, M229	BAE SYSTEMS
65-52807-35	LEADING EDGE FLAP & SLAT POSITION INDICATOR ACCESSORY UNIT ASSY, M229	BAE SYSTEMS
65-52807-37	LEADING EDGE FLAP & SLAT POSITION INDICATOR ACCESSORY UNIT ASSY, M229	BAE SYSTEMS
65-52807-39	LEADING EDGE FLAP & SLAT POSITION INDICATOR ACCESSORY UNIT ASSY, M229	BAE SYSTEMS
65-52807-39 MOD A	LEADING EDGE FLAP & SLAT POSITION INDICATOR ACCESSORY UNIT ASSY, M229	BAE SYSTEMS
65-52807-43	LEADING EDGE FLAP & SLAT POSITION INDICATOR ACCESSORY UNIT ASSY, M229	BAE SYSTEMS
65-52807-63	LEADING EDGE FLAP & SLAT POSITION INDICATOR ACCESSORY UNIT ASSY, M229	BAE SYSTEMS
65-52807-65	LEADING EDGE FLAP & SLAT POSITION INDICATOR ACCESSORY UNIT ASSY, M229	BAE SYSTEMS
65-52807-66	LEADING EDGE FLAP & SLAT POSITION INDICATOR ACCESSORY UNIT ASSY, M229	BAE SYSTEMS
65-52807-69	LEADING EDGE FLAP & SLAT POSITION INDICATOR ACCESSORY UNIT ASSY, M229	BAE SYSTEMS
65-52807-71	LEADING EDGE FLAP & SLAT POSITION INDICATOR ACCESSORY UNIT ASSY, M229	BAE SYSTEMS
65-52807-74	LEADING EDGE FLAP & SLAT POSITION INDICATOR ACCESSORY UNIT ASSY, M229	BAE SYSTEMS
65-52807-76	LEADING EDGE FLAP & SLAT POSITION INDICATOR ACCESSORY UNIT ASSY, M229	BAE SYSTEMS
65-52807-76 MOD A	LEADING EDGE FLAP & SLAT POSITION INDICATOR ACCESSORY UNIT ASSY, M229	BAE SYSTEMS
65-52810-6	AIR CONDITIONING ACCESSORY UNIT ASSY, M324	BAE SYSTEMS
65-52810-19	AIR CONDITIONING ACCESSORY UNIT ASSY, M324	BAE SYSTEMS
65-52810-25	AIR CONDITIONING ACCESSORY UNIT ASSY, M324	BAE SYSTEMS
65-52810-28	AIR CONDITIONING ACCESSORY UNIT ASSY, M324	BAE SYSTEMS
65-52810-35	AIR CONDITIONING ACCESSORY UNIT ASSY, M324	BAE SYSTEMS
65-52810-37	AIR CONDITIONING ACCESSORY UNIT ASSY, M324	BAE SYSTEMS
65-52810-39	AIR CONDITIONING ACCESSORY UNIT ASSY, M324	BAE SYSTEMS
65-52810-46	AIR CONDITIONING ACCESSORY UNIT ASSY, M324	BAE SYSTEMS
65-52810-50	AIR CONDITIONING ACCESSORY UNIT ASSY, M324	BAE SYSTEMS
65-52810-57	AIR CONDITIONING ACCESSORY UNIT ASSY, M324	BAE SYSTEMS
65-52810-59	AIR CONDITIONING ACCESSORY UNIT ASSY, M324	BAE SYSTEMS
65-52810-64	AIR CONDITIONING ACCESSORY UNIT ASSY, M324	BAE SYSTEMS
65-52810-66	AIR CONDITIONING ACCESSORY UNIT ASSY, M324	BAE SYSTEMS
65-52810-68	AIR CONDITIONING ACCESSORY UNIT ASSY, M324	BAE SYSTEMS
65-52817-9	AUTOMATIC FLIGHT CONTROLS ACCESSORY UNIT ASSY	BAE SYSTEMS
65-52817-17	AUTOMATIC FLIGHT CONTROLS ACCESSORY UNIT ASSY	BAE SYSTEMS
65-52819-7	DIGITAL STALL WARNING COMPUTER UNIT	BAE SYSTEMS
65-52819-13	DIGITAL STALL WARNING COMPUTER UNIT	BAE SYSTEMS
65-52819-23	DIGITAL STALL WARNING COMPUTER UNIT	BAE SYSTEMS
65-52819-25	DIGITAL STALL WARNING COMPUTER UNIT	BAE SYSTEMS
65-52819-39	DIGITAL STALL WARNING COMPUTER UNIT	BAE SYSTEMS
65-52820-1	INTEGRATED FLIGHT SYSTEM ACCESSORY UNIT MODULE ASSY	BAE SYSTEMS
65-52820-2	INTEGRATED FLIGHT SYSTEM ACCESSORY UNIT MODULE ASSY	BAE SYSTEMS
65-52822-1	STALL MANAGEMENT COMPUTER MODULE ASSY	BAE SYSTEMS
65-52822-1 MOD A	STALL MANAGEMENT COMPUTER MODULE ASSY	BAE SYSTEMS
65-52822-1 MOD B	STALL MANAGEMENT COMPUTER MODULE ASSY	BAE SYSTEMS
65-52822-3	STALL MANAGEMENT COMPUTER MODULE ASSY	BAE SYSTEMS
65-52822-3 MOD A	STALL MANAGEMENT COMPUTER MODULE ASSY	BAE SYSTEMS
65-52822-5	STALL MANAGEMENT COMPUTER MODULE ASSY	BAE SYSTEMS
65-52822-7	STALL MANAGEMENT COMPUTER MODULE ASSY	BAE SYSTEMS
65-52822-7 MOD A	STALL MANAGEMENT COMPUTER MODULE ASSY	BAE SYSTEMS
65-54499-12	AURAL WARNING BOX ASSEMBLY	BAE SYSTEMS

PART NUMBER	DESCRIPTION	OEM
65-54499-15	AURAL WARNING BOX ASSEMBLY	BAE SYSTEMS
65-54499-17	AURAL WARNING BOX ASSEMBLY	BAE SYSTEMS
65-54499-21	AURAL WARNING BOX ASSEMBLY	BAE SYSTEMS
65-54499-23	AURAL WARNING BOX ASSEMBLY	BAE SYSTEMS
65-54499-25	AURAL WARNING BOX ASSEMBLY	BAE SYSTEMS
65-54499-26	AURAL WARNING BOX ASSEMBLY	BAE SYSTEMS
65-54499-27	AURAL WARNING BOX ASSEMBLY	BAE SYSTEMS
65-54499-28	AURAL WARNING BOX ASSEMBLY	BAE SYSTEMS
65-54499-29	AURAL WARNING BOX ASSEMBLY	BAE SYSTEMS
65-54499-32	AURAL WARNING BOX ASSEMBLY	BAE SYSTEMS
65-54499-34	AURAL WARNING BOX ASSEMBLY	BAE SYSTEMS
65-54499-36	AURAL WARNING BOX ASSEMBLY	BAE SYSTEMS
65-54499-38	AURAL WARNING BOX ASSEMBLY	BAE SYSTEMS
65-54499-40	AURAL WARNING BOX ASSEMBLY	BAE SYSTEMS
65-54499-41	AURAL WARNING BOX ASSEMBLY	BAE SYSTEMS
65-54499-42	AURAL WARNING BOX ASSEMBLY	BAE SYSTEMS
6577-1	VANEAXIAL FAN ASSEMBLY	HAMILTON SUNDSTRA
6577-2	VANEAXIAL FAN ASSEMBLY	HAMILTON SUNDSTRA
6577-7	VANEAXIAL FAN ASSEMBLY	HAMILTON SUNDSTRA
65-84209-1	AUTO SPEED BRAKE CONTROL ACCESSORY UNIT ASSY	BAE SYSTEMS
65-84209-3	AUTO SPEED BRAKE CONTROL ACCESSORY UNIT ASSY	BAE SYSTEMS
65-84209-5	AUTO SPEED BRAKE CONTROL ACCESSORY UNIT ASSY	BAE SYSTEMS
65-84209-7	AUTO SPEED BRAKE CONTROL ACCESSORY UNIT ASSY	BAE SYSTEMS
65-84209-8	AUTO SPEED BRAKE CONTROL ACCESSORY UNIT ASSY	BAE SYSTEMS
65-84209-11	AUTO SPEED BRAKE CONTROL ACCESSORY UNIT ASSY	BAE SYSTEMS
65-84209-13	AUTO SPEED BRAKE CONTROL ACCESSORY UNIT ASSY	BAE SYSTEMS
65-84209-17	AUTO SPEED BRAKE CONTROL ACCESSORY UNIT ASSY	BAE SYSTEMS
65-84209-19	AUTO SPEED BRAKE CONTROL ACCESSORY UNIT ASSY	BAE SYSTEMS
65-84209-21	AUTO SPEED BRAKE CONTROL ACCESSORY UNIT ASSY	BAE SYSTEMS
65807-040-1	ELECTRONIC CLOCK	SEXTANT AVIONIQUE
65807-050-1	ELECTRONIC CLOCK	SEXTANT AVIONIQUE
65807-051-1	ELECTRONIC CLOCK	SEXTANT AVIONIQUE
6600-2266	SWITCH-STARTER 30 DEGREE	COLE INSTRUMENT
6664287-0	WINDOW HEAT COMPUTER TEMP REGULATOR	SOCIETE ANONYME
6672	FIRE/OVERHEAT DETECTOR ASSEMBLY	MEGGITT
6672-01	FIRE/OVERHEAT DETECTOR ASSEMBLY	MEGGITT
6674	FIRE/OVERHEAT DETECTOR ASSEMBLY	MEGGITT
6676	FIRE/OVERHEAT DETECTOR ASSEMBLY	MEGGITT
6678	FIRE/OVERHEAT DETECTOR ASSEMBLY	MEGGITT
6700-400-80-10	DC POWER MONITOR	THALES
6700-400-80-11	DC POWER MONITOR	THALES
67100-1-350F	MIDGET THERMOSWITCH UNIT LINE	FENWAL SAFETY SYS
67121-25-200F	MIDGET THERMOSWITCH UNIT LINE	FENWAL SAFETY SYS
67121-32-298F	MIDGET THERMOSWITCH UNIT LINE	FENWAL SAFETY SYS
67121-52-180	MIDGET THERMOSWITCH UNIT LINE	FENWAL SAFETY SYS
67121-52-212	MIDGET THERMOSWITCH UNIT LINE	FENWAL SAFETY SYS
67121-52-440	MIDGET THERMOSWITCH UNIT LINE	FENWAL SAFETY SYS
67121-53-130	MIDGET THERMOSWITCH UNIT LINE	FENWAL SAFETY SYS
67261-001-001	SINGLE COMPARTMENT OVEN	RUMBOLD
67262-001-001	SINGLE COMPARTMENT OVEN	RUMBOLD
67262-001-002	SINGLE COMPARTMENT OVEN	RUMBOLD
67262-001-003	SINGLE COMPARTMENT OVEN	RUMBOLD
67262-001-004	SINGLE COMPARTMENT OVEN	RUMBOLD
67-2906-001	MOTOR OPERATED AIR SHUTOFF VALVE	HONEYWELL
67-2906-002	MOTOR OPERATED AIR SHUTOFF VALVE	HONEYWELL
67-2951-001	MOTOR OPERATED AIR SHUTOFF VALVE	HONEYWELL
67321-0-220F	MIDGET THERMOSWITCH UNIT LINE	FENWAL SAFETY SYS
67321-0-475F	MIDGET THERMOSWITCH UNIT LINE	FENWAL SAFETY SYS
67321-0-500F	MIDGET THERMOSWITCH UNIT LINE	FENWAL SAFETY SYS
67321-26-190F	MIDGET THERMOSWITCH UNIT LINE	FENWAL SAFETY SYS
67321-27-240F	MIDGET THERMOSWITCH UNIT LINE	FENWAL SAFETY SYS
67321-27-250	MIDGET THERMOSWITCH UNIT LINE	FENWAL SAFETY SYS
67321-27-250F	MIDGET THERMOSWITCH UNIT LINE	FENWAL SAFETY SYS
686-2000	CRADLE ASSEMBLY	TELEPHONICS
686-2000-001	CRADLE ASSEMBLY	TELEPHONICS
686-2000-002	CRADLE ASSEMBLY	TELEPHONICS
692525	OIL PRESSURE SWITCH	ALLIED-SIGNAL

PART NUMBER	DESCRIPTION	OEM
692525-7	OIL PRESSURE SWITCH	ALLIED-SIGNAL
692525-8	OIL PRESSURE SWITCH	ALLIED-SIGNAL
692525-9	OIL PRESSURE SWITCH	ALLIED-SIGNAL
692525-21	OIL PRESSURE SWITCH	ALLIED-SIGNAL
69-33D	FLUORESCENT LAMP BALLASTS	DAY-RAY PRODUCTS
69-34D	FLUORESCENT LAMP BALLASTS	DAY-RAY PRODUCTS
69-35D	FLUORESCENT LAMP BALLASTS	DAY-RAY PRODUCTS
69-36D	FLUORESCENT LAMP BALLASTS	DAY-RAY PRODUCTS
69-37D	FLUORESCENT LAMP BALLASTS	DAY-RAY PRODUCTS
69-37307-134	ENGINE & APU FIRE CONTROL MODULE ASSY, P8-1	BAE SYSTEMS
69-37307-136	ENGINE & APU FIRE CONTROL MODULE ASSY, P8-1	BAE SYSTEMS
69-37307-138	ENGINE & APU FIRE CONTROL MODULE ASSY, P8-1	BAE SYSTEMS
69-37307-141	ENGINE & APU FIRE CONTROL MODULE ASSY, P8-1	BAE SYSTEMS
69-37307-143	ENGINE & APU FIRE CONTROL MODULE ASSY, P8-1	BAE SYSTEMS
69-37307-145	ENGINE & APU FIRE CONTROL MODULE ASSY, P8-1	BAE SYSTEMS
69-37307-147	ENGINE & APU FIRE CONTROL MODULE ASSY, P8-1	BAE SYSTEMS
69-37307-149	ENGINE & APU FIRE CONTROL MODULE ASSY, P8-1	BAE SYSTEMS
69-37307-150	ENGINE & APU FIRE CONTROL MODULE ASSY, P8-1	BAE SYSTEMS
69-37307-153	ENGINE & APU FIRE CONTROL MODULE ASSY, P8-1	BAE SYSTEMS
69-37307-155	ENGINE & APU FIRE CONTROL MODULE ASSY, P8-1	BAE SYSTEMS
69-37307-158	ENGINE & APU FIRE CONTROL MODULE ASSY, P8-1	BAE SYSTEMS
69-37307-159	ENGINE & APU FIRE CONTROL MODULE ASSY, P8-1	BAE SYSTEMS
69-37307-300	ENGINE & APU FIRE CONTROL MODULE ASSY, P8-1	BAE SYSTEMS
69-37307-301	ENGINE & APU FIRE CONTROL MODULE ASSY, P8-1	BAE SYSTEMS
69-37313-99	FLIGHT CONTROLS MODULE ASSY, P5-3	BOEING
69-37313-104	FLIGHT CONTROLS MODULE ASSY, P5-3	BOEING
69-37313-105	FLIGHT CONTROLS MODULE ASSY, P5-3	BOEING
69-37313-106	FLIGHT CONTROLS MODULE ASSY, P5-3	BOEING
69-37313-107	FLIGHT CONTROLS MODULE ASSY, P5-3	BOEING
69-37313-108	FLIGHT CONTROLS MODULE ASSY, P5-3	BOEING
69-37313-109	FLIGHT CONTROLS MODULE ASSY, P5-3	BOEING
69-37313-110	FLIGHT CONTROLS MODULE ASSY, P5-3	BOEING
69-37313-111	FLIGHT CONTROLS MODULE ASSY, P5-3	BOEING
69-37313-112	FLIGHT CONTROLS MODULE ASSY, P5-3	BOEING
69-37313-113	FLIGHT CONTROLS MODULE ASSY, P5-3	BOEING
69-37313-114	FLIGHT CONTROLS MODULE ASSY, P5-3	BOEING
69-37313-115	FLIGHT CONTROLS MODULE ASSY, P5-3	BOEING
69-37313-116	FLIGHT CONTROLS MODULE ASSY, P5-3	BOEING
69-37313-117	FLIGHT CONTROLS MODULE ASSY, P5-3	BOEING
69-37313-118	FLIGHT CONTROLS MODULE ASSY, P5-3	BOEING
69-37313-119	FLIGHT CONTROLS MODULE ASSY, P5-3	BOEING
69-37313-120	FLIGHT CONTROLS MODULE ASSY, P5-3	BOEING
69-37313-121	FLIGHT CONTROLS MODULE ASSY, P5-3	BOEING
69-37313-122	FLIGHT CONTROLS MODULE ASSY, P5-3	BOEING
69-37313-123	FLIGHT CONTROLS MODULE ASSY, P5-3	BOEING
69-37313-124	FLIGHT CONTROLS MODULE ASSY, P5-3	BOEING
69-37313-125	FLIGHT CONTROLS MODULE ASSY, P5-3	BOEING
69-37313-126	FLIGHT CONTROLS MODULE ASSY, P5-3	BOEING
69-37313-300	FLIGHT CONTROLS MODULE ASSY, P5-3	BOEING
69-37313-301	FLIGHT CONTROLS MODULE ASSY, P5-3	BOEING
69-37313-302	FLIGHT CONTROLS MODULE ASSY, P5-3	BOEING
69-37313-401	FLIGHT CONTROLS MODULE ASSY, P5-3	BOEING
69-37313-402	FLIGHT CONTROLS MODULE ASSY, P5-3	BOEING
69-37313-403	FLIGHT CONTROLS MODULE ASSY, P5-3	BOEING
69-37313-404	FLIGHT CONTROLS MODULE ASSY, P5-3	BOEING
69-37313-405	FLIGHT CONTROLS MODULE ASSY, P5-3	BOEING
69-37313-406	FLIGHT CONTROLS MODULE ASSY, P5-3	BOEING
69-37313-407	FLIGHT CONTROLS MODULE ASSY, P5-3	BOEING
69-37313-408	FLIGHT CONTROLS MODULE ASSY, P5-3	BOEING
69-37313-410	FLIGHT CONTROLS MODULE ASSY, P5-3	BOEING
69-37313-411	FLIGHT CONTROLS MODULE ASSY, P5-3	BOEING
69-37313-412	FLIGHT CONTROLS MODULE ASSY, P5-3	BOEING
69-37313-413	FLIGHT CONTROLS MODULE ASSY, P5-3	BOEING
69-37313-414	FLIGHT CONTROLS MODULE ASSY, P5-3	BOEING
69-37313-415	FLIGHT CONTROLS MODULE ASSY, P5-3	BOEING
69-37313-416	FLIGHT CONTROLS MODULE ASSY, P5-3	BOEING
69-37313-417	FLIGHT CONTROLS MODULE ASSY, P5-3	BOEING

PART NUMBER	DESCRIPTION	OEM
69-37335-2079	FUEL SYSTEM MODULE ASSEMBLY P5-2	BAE SYSTEMS
69-37335-2087	FUEL SYSTEM MODULE ASSEMBLY P5-2	BAE SYSTEMS
69-37335-2088	FUEL SYSTEM MODULE ASSEMBLY P5-2	BAE SYSTEMS
69-37335-2098	FUEL SYSTEM MODULE ASSEMBLY P5-2	BAE SYSTEMS
69-37335-2100	FUEL SYSTEM MODULE ASSEMBLY P5-2	BAE SYSTEMS
69-37335-2105	FUEL SYSTEM MODULE ASSEMBLY P5-2	BAE SYSTEMS
69-37335-2111	FUEL SYSTEM MODULE ASSEMBLY P5-2	BAE SYSTEMS
69-37335-2112	FUEL SYSTEM MODULE ASSEMBLY P5-2	BAE SYSTEMS
69-37335-2118	FUEL SYSTEM MODULE ASSEMBLY P5-2	BAE SYSTEMS
69-37335-2119	FUEL SYSTEM MODULE ASSEMBLY P5-2	BAE SYSTEMS
69-37335-2123	FUEL SYSTEM MODULE ASSEMBLY P5-2	BAE SYSTEMS
69-37335-2124	FUEL SYSTEM MODULE ASSEMBLY P5-2	BAE SYSTEMS
69-37335-2125	FUEL SYSTEM MODULE ASSEMBLY P5-2	BAE SYSTEMS
69-37335-2126	FUEL SYSTEM MODULE ASSEMBLY P5-2	BAE SYSTEMS
69-37335-2128	FUEL SYSTEM MODULE ASSEMBLY P5-2	BAE SYSTEMS
69-37335-2129	FUEL SYSTEM MODULE ASSEMBLY P5-2	BAE SYSTEMS
69-37335-2130	FUEL SYSTEM MODULE ASSEMBLY P5-2	BAE SYSTEMS
69-37335-2131	FUEL SYSTEM MODULE ASSEMBLY P5-2	BAE SYSTEMS
69-37335-2132	FUEL SYSTEM MODULE ASSEMBLY P5-2	BAE SYSTEMS
69-37335-2138	FUEL SYSTEM MODULE ASSEMBLY P5-2	BAE SYSTEMS
69-37335-2140	FUEL SYSTEM MODULE ASSEMBLY P5-2	BAE SYSTEMS
69-37346-123	WINDOW & COMBINED PITOT-STATIC HEAT MODULE ASSY P5-9	BAE SYSTEMS
69-37346-125	WINDOW & COMBINED PITOT-STATIC HEAT MODULE ASSY P5-9	BAE SYSTEMS
69-37346-135	WINDOW & COMBINED PITOT-STATIC HEAT MODULE ASSY P5-9	BAE SYSTEMS
69-37346-138	WINDOW & COMBINED PITOT-STATIC HEAT MODULE ASSY P5-9	BAE SYSTEMS
69-37346-140	WINDOW & COMBINED PITOT-STATIC HEAT MODULE ASSY P5-9	BAE SYSTEMS
69-37346-162	WINDOW & COMBINED PITOT-STATIC HEAT MODULE ASSY P5-9	BAE SYSTEMS
69-37346-163	WINDOW & COMBINED PITOT-STATIC HEAT MODULE ASSY P5-9	BAE SYSTEMS
69-37346-2123	WINDOW & COMBINED PITOT-STATIC HEAT MODULE ASSY P5-9	BAE SYSTEMS
69-37346-2125	WINDOW & COMBINED PITOT-STATIC HEAT MODULE ASSY P5-9	BAE SYSTEMS
69-37346-2135	WINDOW & COMBINED PITOT-STATIC HEAT MODULE ASSY P5-9	BAE SYSTEMS
69-37346-2138	WINDOW & COMBINED PITOT-STATIC HEAT MODULE ASSY P5-9	BAE SYSTEMS
69-37346-2140	WINDOW & COMBINED PITOT-STATIC HEAT MODULE ASSY P5-9	BAE SYSTEMS
69-37346-2162	WINDOW & COMBINED PITOT-STATIC HEAT MODULE ASSY P5-9	BAE SYSTEMS
69-37346-2163	WINDOW & COMBINED PITOT-STATIC HEAT MODULE ASSY P5-9	BAE SYSTEMS
69-37369-1	GROUND PROXIMITY WARNING MODULE ASSY P3-7	BAE SYSTEMS
69-37369-4	GROUND PROXIMITY WARNING MODULE ASSY P3-7	BAE SYSTEMS
69-37369-7	GROUND PROXIMITY WARNING MODULE ASSY P3-7	BAE SYSTEMS
69-37369-9	GROUND PROXIMITY WARNING MODULE ASSY P3-7	BAE SYSTEMS
69-37369-11	GROUND PROXIMITY WARNING MODULE ASSY P3-7	BAE SYSTEMS
69-37369-15	GROUND PROXIMITY WARNING MODULE ASSY P3-7	BAE SYSTEMS
69-37369-19	GROUND PROXIMITY WARNING MODULE ASSY P3-7	BAE SYSTEMS
69-37369-21	GROUND PROXIMITY WARNING MODULE ASSY P3-7	BAE SYSTEMS
69-37369-24	GROUND PROXIMITY WARNING MODULE ASSY P3-7	BAE SYSTEMS
69-37369-35	GROUND PROXIMITY WARNING MODULE ASSY P3-7	BAE SYSTEMS
69-37369-300	GROUND PROXIMITY WARNING MODULE ASSY P3-7	BAE SYSTEMS
69-37369-301	GROUND PROXIMITY WARNING MODULE ASSY P3-7	BAE SYSTEMS
69-37369-302	GROUND PROXIMITY WARNING MODULE ASSY P3-7	BAE SYSTEMS
69-37369-303	GROUND PROXIMITY WARNING MODULE ASSY P3-7	BAE SYSTEMS
69-37369-304	GROUND PROXIMITY WARNING MODULE ASSY P3-7	BAE SYSTEMS
69-37369-305	GROUND PROXIMITY WARNING MODULE ASSY P3-7	BAE SYSTEMS
69-38D	FLUORESCENT LAMP BALLASTS	DAY-RAY PRODUCTS
69-55179-47	INDICATOR LIGHT DIMMING MODULE ASSY, M469	BAE SYSTEMS
69-55179-47 MOD A	INDICATOR LIGHT DIMMING MODULE ASSY, M469	BAE SYSTEMS
69-55179-53	INDICATOR LIGHT DIMMING MODULE ASSY, M469	BAE SYSTEMS
69-55179-53 MOD A	INDICATOR LIGHT DIMMING MODULE ASSY, M469	BAE SYSTEMS
69-55179-55	INDICATOR LIGHT DIMMING MODULE ASSY, M469	BAE SYSTEMS
69-55179-58	INDICATOR LIGHT DIMMING MODULE ASSY, M469	BAE SYSTEMS
69-55179-58 MOD A	INDICATOR LIGHT DIMMING MODULE ASSY, M469	BAE SYSTEMS
69-55179-63	INDICATOR LIGHT DIMMING MODULE ASSY, M469	BAE SYSTEMS
69-55179-63 MOD A	INDICATOR LIGHT DIMMING MODULE ASSY, M469	BAE SYSTEMS
69-55179-64	INDICATOR LIGHT DIMMING MODULE ASSY, M469	BAE SYSTEMS
69-55179-64 MOD A	INDICATOR LIGHT DIMMING MODULE ASSY, M469	BAE SYSTEMS
69-55179-65	INDICATOR LIGHT DIMMING MODULE ASSY, M469	BAE SYSTEMS
69-55179-67	INDICATOR LIGHT DIMMING MODULE ASSY, M469	BAE SYSTEMS
69-60764-1	MASTER DIM PRINTED CIRCUIT ASSY	BAE SYSTEMS
69-60764-3	MASTER DIM PRINTED CIRCUIT ASSY	BAE SYSTEMS

PART NUMBER	DESCRIPTION	OEM
69-73079-6	APU OIL LEVEL INDICATOR MODULE ASSY	BAE SYSTEMS
69-73079-7	APU OIL LEVEL INDICATOR MODULE ASSY	BAE SYSTEMS
69-73614-24	POWER MANAGEMENT CONTROL MODULE ASSY	BOEING
69-73614-26	POWER MANAGEMENT CONTROL MODULE ASSY	BOEING
69-73614-27	POWER MANAGEMENT CONTROL MODULE ASSY	BOEING
69-73614-32	POWER MANAGEMENT CONTROL MODULE ASSY	BOEING
69-73614-35	POWER MANAGEMENT CONTROL MODULE ASSY	BOEING
69-73614-36	POWER MANAGEMENT CONTROL MODULE ASSY	BOEING
69-73614-37	POWER MANAGEMENT CONTROL MODULE ASSY	BOEING
69-73614-46	POWER MANAGEMENT CONTROL MODULE ASSY	BOEING
69-73614-47	POWER MANAGEMENT CONTROL MODULE ASSY	BOEING
69-73614-48	POWER MANAGEMENT CONTROL MODULE ASSY	BOEING
69-73614-52	POWER MANAGEMENT CONTROL MODULE ASSY	BAE SYSTEMS
69-73614-53	POWER MANAGEMENT CONTROL MODULE ASSY	BAE SYSTEMS
69-73614-54	POWER MANAGEMENT CONTROL MODULE ASSY	BAE SYSTEMS
69-73614-55	POWER MANAGEMENT CONTROL MODULE ASSY	BAE SYSTEMS
69-73614-56	POWER MANAGEMENT CONTROL MODULE ASSY	BAE SYSTEMS
69-73614-57	POWER MANAGEMENT CONTROL MODULE ASSY	BAE SYSTEMS
69-73614-58	POWER MANAGEMENT CONTROL MODULE ASSY	BAE SYSTEMS
69-73713-5	IRS MODE SELECTOR MODULE ASSEMBLY	BAE SYSTEMS
69-73713-8	IRS MODE SELECTOR MODULE ASSEMBLY	BAE SYSTEMS
69-73713-12	IRS MODE SELECTOR MODULE ASSEMBLY	BAE SYSTEMS
69-73713-15	IRS MODE SELECTOR MODULE ASSEMBLY	BAE SYSTEMS
69-73713-17	IRS MODE SELECTOR MODULE ASSEMBLY	BAE SYSTEMS
69-73713-20	IRS MODE SELECTOR MODULE ASSEMBLY	BAE SYSTEMS
69-73713-317	IRS MODE SELECTOR MODULE ASSEMBLY	BAE SYSTEMS
69-73713-320	IRS MODE SELECTOR MODULE ASSEMBLY	BAE SYSTEMS
69-75978-1	STALL WARNING TEST MODULE ASSY	BAE SYSTEMS
69-76435-5	FLOOD & PANEL LIGHTING MODULE ASSY, P8-50	BAE SYSTEMS
69-76435-305	FLOOD & PANEL LIGHTING MODULE ASSY, P8-50	BAE SYSTEMS
69-76436-1	STAB TRIM & CAB DOOR MODULE ASSY, P8-47	BAE SYSTEMS
69-76436-4	STAB TRIM & CAB DOOR MODULE ASSY, P8-47	BAE SYSTEMS
69-76436-7	STAB TRIM & CAB DOOR MODULE ASSY, P8-47	BAE SYSTEMS
69-76436-8	STAB TRIM & CAB DOOR MODULE ASSY, P8-47	BAE SYSTEMS
69-76436-9	STAB TRIM & CAB DOOR MODULE ASSY, P8-47	BAE SYSTEMS
69-76436-307	STAB TRIM & CAB DOOR MODULE ASSY, P8-47	BAE SYSTEMS
69-78547-2	FLIGHT RECORDER & MACH AIRSPEED TEST MOD ASSY	BOEING
7G110-3	GAGE PRESSURE SWITCH	CUSTOM CONTROL SEN
7G110-6	GAGE PRESSURE SWITCH	CUSTOM COMPONENT
701285	POWER SUPPLY	BFGOODRICH
702536	LIGHT & POWER SUPPLY ASSEMBLY	HOSKINS
70400-1	LOGIC CONTROL UNIT	MONOGRAM
70400-3	LOGIC CONTROL UNIT	MONOGRAM
7080M91G01	FAN & THRUST REVERSER ELECTRICAL CABLES	MIDDLE RIVER AIRCRAF
7080M91G02	FAN & THRUST REVERSER ELECTRICAL CABLES	MIDDLE RIVER AIRCRAF
7080M91G03	FAN & THRUST REVERSER ELECTRICAL CABLES	MIDDLE RIVER AIRCRAF
7080M91G04	FAN & THRUST REVERSER ELECTRICAL CABLES	MIDDLE RIVER AIRCRAF
7080M92G01	FAN & THRUST REVERSER ELECTRICAL CABLES	MIDDLE RIVER AIRCRAF
7080M92G02	FAN & THRUST REVERSER ELECTRICAL CABLES	MIDDLE RIVER AIRCRAF
7080M92G03	FAN & THRUST REVERSER ELECTRICAL CABLES	MIDDLE RIVER AIRCRAF
7080M92G04	FAN & THRUST REVERSER ELECTRICAL CABLES	MIDDLE RIVER AIRCRAF
7080M92G05	FAN & THRUST REVERSER ELECTRICAL CABLES	MIDDLE RIVER AIRCRAF
708-079-3	CABLE HARNESS	INTERTECHNIQUE
708-079-4	CABLE HARNESS	INTERTECHNIQUE
708-080-3	CABLE HARNESS	INTERTECHNIQUE
708-080-4	CABLE HARNESS	INTERTECHNIQUE
708-105-1	CABLE HARNESS	INTERTECHNIQUE
708-614-2	CABLE HARNESS	INTERTECHNIQUE
708-614-3	CABLE HARNESS	INTERTECHNIQUE
708-614-4	CABLE HARNESS	INTERTECHNIQUE
708-615	CABLE HARNESS	INTERTECHNIQUE
708-615-1	CABLE HARNESS	INTERTECHNIQUE
708-616-1	CABLE HARNESS	INTERTECHNIQUE
708-616-2	CABLE HARNESS	INTERTECHNIQUE
708-616-3	CABLE HARNESS	INTERTECHNIQUE
70900-1	LEVEL SENSOR	MONOGRAM
7101-01	MODEL 801RDS FIRE/OVERHEAT DETECTOR	MEGGITT

PART NUMBER	DESCRIPTION	OEM
7101-69	MODEL 801RDS FIRE/OVERHEAT DETECTOR	MEGGITT
7101-70	MODEL 801RDS FIRE/OVERHEAT DETECTOR	MEGGITT
7101-71	MODEL 801RDS FIRE/OVERHEAT DETECTOR	MEGGITT
7101-72	MODEL 801RDS FIRE/OVERHEAT DETECTOR	MEGGITT
7101-73	MODEL 801RDS FIRE/OVERHEAT DETECTOR	MEGGITT
7101-77	MODEL 801RDS FIRE/OVERHEAT DETECTOR	MEGGITT
7101-78	MODEL 801RDS FIRE/OVERHEAT DETECTOR	MEGGITT
7101-80	MODEL 801RDS FIRE/OVERHEAT DETECTOR	MEGGITT
7101-81	MODEL 801RDS FIRE/OVERHEAT DETECTOR	MEGGITT
7101-129	MODEL 801RDS FIRE/OVERHEAT DETECTOR	MEGGITT
7101-135	MODEL 801RDS FIRE/OVERHEAT DETECTOR	MEGGITT
7101-136	MODEL 801RDS FIRE/OVERHEAT DETECTOR	MEGGITT
7101-137	MODEL 801RDS FIRE/OVERHEAT DETECTOR	MEGGITT
7101-138	MODEL 801RDS FIRE/OVERHEAT DETECTOR	MEGGITT
7101-149	MODEL 801RDS FIRE/OVERHEAT DETECTOR	MEGGITT
7101-155	MODEL 801RDS FIRE/OVERHEAT DETECTOR	MEGGITT
7101-236	MODEL 801RDS FIRE/OVERHEAT DETECTOR	MEGGITT
7101-237	MODEL 801RDS FIRE/OVERHEAT DETECTOR	MEGGITT
7101-265	MODEL 801RDS FIRE/OVERHEAT DETECTOR	MEGGITT
710298-4	PRESSURE SELECTOR PANEL	HAMILTON SUNDSTRA
710298-5	PRESSURE SELECTOR PANEL	HAMILTON SUNDSTRA
710298-6	PRESSURE SELECTOR PANEL	HAMILTON SUNDSTRA
710298-7	PRESSURE SELECTOR PANEL	HAMILTON SUNDSTRA
710298-8	PRESSURE SELECTOR PANEL	HAMILTON SUNDSTRA
710298-9	PRESSURE SELECTOR PANEL	HAMILTON SUNDSTRA
710298-10	PRESSURE SELECTOR PANEL	HAMILTON SUNDSTRA
711002-3	PRESSURE CONTROL PANEL	HAMILTON SUNDST
711002-4	PRESSURE CONTROL PANEL	HAMILTON SUNDST
711002-5	PRESSURE CONTROL PANEL	HAMILTON SUNDST
711003-2	OUTFLOW VALVE	HAMILTON SUNDSTRA
711003-3	OUTFLOW VALVE	HAMILTON SUNDSTRA
711003-5	OUTFLOW VALVE	HAMILTON SUNDSTRA
7116M20G01	FAN & THRUST REVERSER ELECTRICAL CABLES	MIDDLE RIVER AIRCRAF
7116M20G02	FAN & THRUST REVERSER ELECTRICAL CABLES	MIDDLE RIVER AIRCRAF
7116M20G03	FAN & THRUST REVERSER ELECTRICAL CABLES	MIDDLE RIVER AIRCRAF
7116M20G04	FAN & THRUST REVERSER ELECTRICAL CABLES	MIDDLE RIVER AIRCRAF
7116M20G05	FAN & THRUST REVERSER ELECTRICAL CABLES	MIDDLE RIVER AIRCRAF
7116M20G06	FAN & THRUST REVERSER ELECTRICAL CABLES	MIDDLE RIVER AIRCRAF
7116M20G07	FAN & THRUST REVERSER ELECTRICAL CABLES	MIDDLE RIVER AIRCRAF
7116M21G01	FAN & THRUST REVERSER ELECTRICAL CABLES	MIDDLE RIVER AIRCRAF
7116M21G02	FAN & THRUST REVERSER ELECTRICAL CABLES	MIDDLE RIVER AIRCRAF
7116M21G03	FAN & THRUST REVERSER ELECTRICAL CABLES	MIDDLE RIVER AIRCRAF
7116M21G04	FAN & THRUST REVERSER ELECTRICAL CABLES	MIDDLE RIVER AIRCRAF
7116M21G05	FAN & THRUST REVERSER ELECTRICAL CABLES	MIDDLE RIVER AIRCRAF
7121-19971-01AA	PRESSURE CONTROLLER	NORD-MICRO
7121-19971-01AB	PRESSURE CONTROLLER	NORD-MICRO
7121-19971-01AC	PRESSURE CONTROLLER	NORD-MICRO
7121-19971-01BA	PRESSURE CONTROLLER	NORD-MICRO
7123-19973-01AA	PRESSURE SELECTOR PANEL	UTC AEROSPACE
7123-19973-02AB	PRESSURE SELECTOR PANEL	UTC AEROSPACE
7123-19973-02AC	PRESSURE SELECTOR PANEL	UTC AEROSPACE
7123-19973-03AB	PRESSURE SELECTOR PANEL PSL105-1	UTC AEROSPACE
7123-19973-03AC	PRESSURE SELECTOR PANEL PSL105-1	UTC AEROSPACE
714E-1	RADIO SET CONTROL	ROCKWELL COLLINS
714E-2	RADIO SET CONTROL	ROCKWELL COLLINS
714E-2A	RADIO SET CONTROL	ROCKWELL COLLINS
714E-2B	RADIO SET CONTROL	ROCKWELL COLLINS
714E-2C	RADIO SET CONTROL	ROCKWELL COLLINS
714E-3	RADIO SET CONTROL	ROCKWELL COLLINS
714E-3B	RADIO SET CONTROL	ROCKWELL COLLINS
714E-3C	RADIO SET CONTROL	ROCKWELL COLLINS
714E-3D	RADIO SET CONTROL	ROCKWELL COLLINS
714E-3F	RADIO SET CONTROL	ROCKWELL COLLINS
714E-3G	RADIO SET CONTROL	ROCKWELL COLLINS
714E-3H	RADIO SET CONTROL	ROCKWELL COLLINS
72011210	COFFEE MAKER DA12 SERIES	BE AEROSPACE
72011402B	COFFEE MAKER DA14 SERIES	BE AEROSPACE

PART NUMBER	DESCRIPTION	OEM
72011403B	COFFEE MAKER DA14 SERIES	BE AEROSPACE
72011404B	COFFEE MAKER DA14 SERIES	BE AEROSPACE
72011412	COFFEE MAKER DA14 SERIES	BE AEROSPACE
72011413	COFFEE MAKER DA14 SERIES	BE AEROSPACE
72011414	COFFEE MAKER DA14 SERIES	BE AEROSPACE
72011500	COFFEE MAKER DA14 SERIES	BE AEROSPACE
72011510	COFFEE MAKER DA14 SERIES	BE AEROSPACE
72012400	COFFEE MAKER DA24 SERIES	BE AEROSPACE
72012410	COFFEE MAKER DA24 SERIES	BE AEROSPACE
72012420	COFFEE MAKER DA24 SERIES	BE AEROSPACE
72015727	COFFEE MAKER DA5 SERIES	BE AEROSPACE
72015728	COFFEE MAKER DA5 SERIES	BE AEROSPACE
72067000	HIGH SPEED OVEN DF700/DF775	BE AEROSPACE
72067001	HIGH SPEED OVEN DF700/DF775	BE AEROSPACE
72067002	HIGH SPEED OVEN DF700/DF775	BE AEROSPACE
72067003	HIGH SPEED OVEN DF700/DF775	BE AEROSPACE
72067004	HIGH SPEED OVEN DF700/DF775	BE AEROSPACE
72067005	HIGH SPEED OVEN DF700/DF775	BE AEROSPACE
72067006	HIGH SPEED OVEN DF700/DF775	BE AEROSPACE
72067100	HIGH SPEED OVEN DF700/DF775	BE AEROSPACE
72067101	HIGH SPEED OVEN DF700/DF775	BE AEROSPACE
72067102	HIGH SPEED OVEN DF700/DF775	BE AEROSPACE
72067750	HIGH SPEED OVEN DF700/DF775	BE AEROSPACE
72067751	HIGH SPEED OVEN DF700/DF775	BE AEROSPACE
72067752	HIGH SPEED OVEN DF700/DF775	BE AEROSPACE
72067850	HIGH SPEED OVEN DF700/DF775	BE AEROSPACE
72068000	HIGH SPEED OVEN DF800/DF801	BE AEROSPACE
72068001	HIGH SPEED OVEN DF800/DF801	BE AEROSPACE
72068002	HIGH SPEED OVEN DF800/DF801	BE AEROSPACE
72068050	HIGH SPEED OVEN DF800/DF801	BE AEROSPACE
72068053	HIGH SPEED OVEN DF800/DF801	BE AEROSPACE
72068100	HIGH SPEED OVEN DF800/DF801	BE AEROSPACE
72068101	HIGH SPEED OVEN DF800/DF801	BE AEROSPACE
72068102	HIGH SPEED OVEN DF800/DF801	BE AEROSPACE
72068150	HIGH SPEED OVEN DF800/DF801	BE AEROSPACE
72068153	HIGH SPEED OVEN DF800/DF801	BE AEROSPACE
72071000	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
720710-00-04-06	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
720710-00-07-02	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
720710-00-08-02	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
720710-00-11-02	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
720710-00-12-02	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
720710-00-18-02	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
720710-00-22-02	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
720710-00-24-02	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
720710-00-27-02	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
720710-00-30-02	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
720710-00-37-03	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
720710-00-39-03	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
720710-00-40-02	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
720710-00-42-00	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
720710-00-42-02	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
720710-00-42-03	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
720710-00-42-06	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
720710-00-42-08	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
720710-00-63-03	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
72071001	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
720710-01-42-00	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
720710-01-42-02	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
720710-01-42-03	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
720710-01-42-06	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
720710-01-42-08	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
72071006	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
720710-06-47-02	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
720710-06-48-03	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
72071007	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
720710-07-44-02	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE

PART NUMBER	DESCRIPTION	OEM
720710-07-44-03	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
720710-07-46-00	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
720710-07-48-03	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
720710-07-59-08	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
720710-07-61-02	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
720710-07-62-02	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
720710-09-59-08	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
720710-09-62-02	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
72071100	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
720711-00-15-02	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
720711-00-16-02	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
720711-00-18-02	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
720711-00-24-02	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
720711-00-30-02	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
720711-00-42-00	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
720711-00-42-02	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
720711-00-42-03	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
72071101	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
72071106	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
720711-06-45-02	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
720711-06-48-03	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
72071107	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
720711-07-46-00	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
720711-07-48-03	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
72071750	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
720717-50-30-02	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
720717-50-42-08	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
720717-51-61-00	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
720717-51-61-02	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
72071850	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
720718-51-61-02	STEAM OVEN DS1000/DS1075 SERIES	BE AEROSPACE
72072000	STEAM OVEN DS2000 SERIES	BE AEROSPACE
720720-00-00-02	STEAM OVEN DS2000 SERIES	BE AEROSPACE
72072002	STEAM OVEN DS2000 SERIES	BE AEROSPACE
720720-02-00-00	STEAM OVEN DS2000 SERIES	BE AEROSPACE
720720-02-00-02	STEAM OVEN DS2000 SERIES	BE AEROSPACE
720720-02-00-03	STEAM OVEN DS2000 SERIES	BE AEROSPACE
72072004	STEAM OVEN DS2000 SERIES	BE AEROSPACE
720720-04-00-02	STEAM OVEN DS2000 SERIES	BE AEROSPACE
72072100	STEAM OVEN DS2000 SERIES	BE AEROSPACE
720721-00-00-02	STEAM OVEN DS2000 SERIES	BE AEROSPACE
72072102	STEAM OVEN DS2000 SERIES	BE AEROSPACE
720721-02-00-00	STEAM OVEN DS2000 SERIES	BE AEROSPACE
720721-02-00-02	STEAM OVEN DS2000 SERIES	BE AEROSPACE
720721-02-00-03	STEAM OVEN DS2000 SERIES	BE AEROSPACE
72072104	STEAM OVEN DS2000 SERIES	BE AEROSPACE
720721-04-00-02	STEAM OVEN DS2000 SERIES	BE AEROSPACE
721-1-000-1B	COFFEE MAKER DA5 SERIES	BE AEROSPACE
72184002B	WATER HEATER DR40 SERIES	BE AEROSPACE
72184003B	WATER HEATER DR40 SERIES	BE AEROSPACE
72184004	WATER HEATER DR40 SERIES	BE AEROSPACE
72184006	WATER HEATER DR40 SERIES	BE AEROSPACE
72184007B	WATER HEATER DR40 SERIES	BE AEROSPACE
72184008B	WATER HEATER DR40 SERIES	BE AEROSPACE
72184011B	WATER HEATER DR40 SERIES	BE AEROSPACE
72184012B	WATER HEATER DR40 SERIES	BE AEROSPACE
72184013B	WATER HEATER DR40 SERIES	BE AEROSPACE
72184015B	WATER HEATER DR40 SERIES	BE AEROSPACE
72184017B	WATER HEATER DR40 SERIES	BE AEROSPACE
72184018	WATER HEATER DR40 SERIES	BE AEROSPACE
72184019	WATER HEATER DR40 SERIES	BE AEROSPACE
72184025	WATER HEATER DR40 SERIES	BE AEROSPACE
72184100	WATER HEATER DR4100 SERIES	BE AEROSPACE
72184101	WATER HEATER DR4100 SERIES	BE AEROSPACE
72184106	WATER HEATER DR4100 SERIES	BE AEROSPACE
72184108	WATER HEATER DR4100 SERIES	BE AEROSPACE
72184109	WATER HEATER DR4100 SERIES	BE AEROSPACE

PART NUMBER	DESCRIPTION	OEM
72184110	WATER HEATER DR4100 SERIES	BE AEROSPACE
72184113	WATER HEATER DR4100 SERIES	BE AEROSPACE
72184117	WATER HEATER DR4100 SERIES	BE AEROSPACE
722-100-2	HARNESS	ZODIAC
722-100-3	HARNESS	ZODIAC
722-100-4	HARNESS	ZODIAC
732-11240-01	MODULAR ASSY, RESERVOIR PRESSURIZATION	SHIMADZU CORP
732-11240-02	MODULAR ASSY, RESERVOIR PRESSURIZATION	SHIMADZU CORP
732-11240-03	MODULAR ASSY, RESERVOIR PRESSURIZATION	SHIMADZU CORP
732-11240-04	MODULAR ASSY, RESERVOIR PRESSURIZATION	SHIMADZU CORP
732-11240-05	MODULAR ASSY, RESERVOIR PRESSURIZATION	SHIMADZU CORP
74-110-1	TRANSMITTER, OIL QUANTITY	MEGGITT AVIONICS
74-110-3	TRANSMITTER, OIL QUANTITY	VIBRO-METER
74-110-4	TRANSMITTER, OIL QUANTITY	VIBRO-METER
74-110-10	OIL QUANTITY TRANSMITTER	ROHR, INC.
747674	THERMOCOUPLE BOX AND CABLE	PRATT & WHITNEY
75-0434-1	CAUTION AND ADVISORY ANNUNCIATOR PANEL	HONEYWELL
75-0434-3	CAUTION AND ADVISORY ANNUNCIATOR PANEL	HONEYWELL
75-0434-5	CAUTION AND ADVISORY ANNUNCIATOR PANEL	HONEYWELL
75-0434-7	CAUTION AND ADVISORY ANNUNCIATOR PANEL	HONEYWELL
7522-1	VHF RADIO TUNING PANEL	AVTECH
2053395	VHF RADIO TUNING PANELS	AVTECH
2053396	VHF RADIO TUNING PANEL	AVTECH
2053397	VHF RADIO TUNING PANEL	AVTECH
2053398	VHF RADIO TUNING PANELS	AVTECH
2053399	VHF RADIO TUNING PANEL	AVTECH
2053403	VHF RADIO TUNING PANELS	AVTECH
2053404	VHF RADIO TUNING PANELS	AVTECH
754775-1	PRESSURE SELECTOR PANEL	HAMILTON SUNDSTRA
754775-2	PRESSURE SELECTOR PANEL	HAMILTON SUNDSTRA
754775-3	PRESSURE SELECTOR PANEL	HAMILTON SUNDSTRA
754775-4	PRESSURE SELECTOR PANEL	HAMILTON SUNDSTRA
754775-5	PRESSURE SELECTOR PANEL	HAMILTON SUNDSTRA
761A0000-03	RAM AIR INLET ACTUATOR (RAIA)	LIEBHERR
761A0000-04	RAM AIR INLET ACTUATOR (RAIA)	LIEBHERR
761B0000-01	RAM AIR INLET ACTUATOR (RAIA)	LIEBHERR
762A0000-03	RAM AIR OUTLET ACTUATOR (RAOA)	LIEBHERR
762A0000-04	RAM AIR OUTLET ACTUATOR (RAOA)	LIEBHERR
763A0000-02	TEMPERATURE SENSOR	LIEBHERR
763A0000-03	TEMPERATURE SENSOR	LIEBHERR
766-323-1	TANK UNIT	ZODIAC INTERTECHNIQ
766-324-2	TANK UNIT	ZODIAC INTERTECHNIQ
766-325-1	TANK UNIT	ZODIAC INTERTECHNIQ
766-326-1	TANK UNIT	ZODIAC INTERTECHNIQ
766-327-2	TANK UNIT	ZODIAC INTERTECHNIQ
766-328-1	TANK UNIT	ZODIAC INTERTECHNIQ
766-329-1	TANK UNIT	ZODIAC INTERTECHNIQ
766-330-1	TANK UNIT	ZODIAC INTERTECHNIQ
766-331-1	TANK UNIT	ZODIAC INTERTECHNIQ
768-380	TANK UNIT	ZODIAC INTERTECHNIQ
771275-1	PRESSURE SELECTOR PANEL	HAMILTON SUNDSTRA
771275-2	PRESSURE SELECTOR PANEL	HAMILTON SUNDSTRA
771275-3	PRESSURE SELECTOR PANEL	HAMILTON SUNDSTRA
771275-4	PRESSURE SELECTOR PANEL	HAMILTON SUNDSTRA
771365	THERMOCOUPLE BOX AND CABLE	PRATT & WHITNEY
772-5005-001	FLIGHT DIRECTOR INDICATOR	ROCKWELL COLLINS
772-5005-002	FLIGHT DIRECTOR INDICATOR	ROCKWELL COLLINS
772-5005-003	FLIGHT DIRECTOR INDICATOR	ROCKWELL COLLINS
772-5005-004	FLIGHT DIRECTOR INDICATOR	ROCKWELL COLLINS
772-5005-005	FLIGHT DIRECTOR INDICATOR	ROCKWELL COLLINS
772-5005-006	FLIGHT DIRECTOR INDICATOR	ROCKWELL COLLINS
772-5005-007	FLIGHT DIRECTOR INDICATOR	ROCKWELL COLLINS
772-5005-009	FLIGHT DIRECTOR INDICATOR	ROCKWELL COLLINS
772-5005-011	FLIGHT DIRECTOR INDICATOR	ROCKWELL COLLINS
772-5005-012	FLIGHT DIRECTOR INDICATOR	ROCKWELL COLLINS
772-5005-013	FLIGHT DIRECTOR INDICATOR	ROCKWELL COLLINS
772-5025-001	HORIZONTAL SITUATION INDICATOR	ROCKWELL COLLINS

PART NUMBER	DESCRIPTION	OEM
772-5025-002	HORIZONTAL SITUATION INDICATOR	ROCKWELL COLLINS
772-5025-004	HORIZONTAL SITUATION INDICATOR	ROCKWELL COLLINS
772-5025-006	HORIZONTAL SITUATION INDICATOR	ROCKWELL COLLINS
772-5025-008	HORIZONTAL SITUATION INDICATOR	ROCKWELL COLLINS
772-5025-009	HORIZONTAL SITUATION INDICATOR	ROCKWELL COLLINS
772-5025-010	HORIZONTAL SITUATION INDICATOR	ROCKWELL COLLINS
772-5025-011	HORIZONTAL SITUATION INDICATOR	ROCKWELL COLLINS
772-5025-012	HORIZONTAL SITUATION INDICATOR	ROCKWELL COLLINS
772-5025-014	HORIZONTAL SITUATION INDICATOR	ROCKWELL COLLINS
772-5370-001	COURSE INDICATOR	ROCKWELL COLLINS
772-5370-002	COURSE INDICATOR	ROCKWELL COLLINS
772-5370-003	COURSE INDICATOR	ROCKWELL COLLINS
772-5370-005	COURSE INDICATOR	ROCKWELL COLLINS
773A0000-01	TEMPERATURE SENSOR	LIEBHERR AEROSPACE
773795-1	PRESSURE SELECTOR PANEL	HAMILTON SUNDSTRA
773795-2	PRESSURE SELECTOR PANEL	HAMILTON SUNDSTRA
773855-3	FAN AIR MODULATING VALVE	UTC AEROSPACE
773855-4	FAN AIR MODULATING VALVE	UTC AEROSPACE
773855-5	FAN AIR MODULATING VALVE	UTC AEROSPACE
773855-6	FAN AIR MODULATING VALVE	UTC AEROSPACE
773855-7	FAN AIR MODULATING VALVE	UTC AEROSPACE
773855-8	FAN AIR MODULATING VALVE	UTC AEROSPACE
774812	THERMOCOUPLE BOX & CABLE	PRATT & WHITNEY
777-1029-001	RADIO SET CONTROL	ROCKWELL COLLINS
777-1029-002	RADIO SET CONTROL	ROCKWELL COLLINS
777-1029-003	RADIO SET CONTROL	ROCKWELL COLLINS
777-1029-004	RADIO SET CONTROL	ROCKWELL COLLINS
777-1029-005	RADIO SET CONTROL	ROCKWELL COLLINS
777-1029-006	RADIO SET CONTROL	ROCKWELL COLLINS
777-1029-007	RADIO SET CONTROL	ROCKWELL COLLINS
777-1397-001	HORIZONTAL SITUATION INDICATOR	ROCKWELL COLLINS
777-1397-002	HORIZONTAL SITUATION INDICATOR	ROCKWELL COLLINS
777-1397-003	HORIZONTAL SITUATION INDICATOR	ROCKWELL COLLINS
777-1493-001	ADF CONTROL UNIT	ROCKWELL COLLINS
777-1493-002	ADF CONTROL UNIT	ROCKWELL COLLINS
777-1493-003	ADF CONTROL UNIT	ROCKWELL COLLINS
777-1493-004	ADF CONTROL UNIT	ROCKWELL COLLINS
777-1493-005	ADF CONTROL UNIT	ROCKWELL COLLINS
777-1493-006	ADF CONTROL UNIT	ROCKWELL COLLINS
777-1493-007	ADF CONTROL UNIT	ROCKWELL COLLINS
777-1493-008	ADF CONTROL UNIT	ROCKWELL COLLINS
777-1493-009	ADF CONTROL UNIT	ROCKWELL COLLINS
777-1493-010	ADF CONTROL UNIT	ROCKWELL COLLINS
787-6366-001	ADF CONTROL UNIT	ROCKWELL COLLINS
787-6366-002	ADF CONTROL UNIT	ROCKWELL COLLINS
787-6366-003	ADF CONTROL UNIT	ROCKWELL COLLINS
787-6366-004	ADF CONTROL UNIT	ROCKWELL COLLINS
787-6366-005	ADF CONTROL UNIT	ROCKWELL COLLINS
787-6366-006	ADF CONTROL UNIT	ROCKWELL COLLINS
787-6366-007	ADF CONTROL UNIT	ROCKWELL COLLINS
787-6366-008	ADF CONTROL UNIT	ROCKWELL COLLINS
787-6366-009	ADF CONTROL UNIT	ROCKWELL COLLINS
787-6366-010	ADF CONTROL UNIT	ROCKWELL COLLINS
787-6366-011	ADF CONTROL UNIT	ROCKWELL COLLINS
787-6366-012	ADF CONTROL UNIT	ROCKWELL COLLINS
787-6366-013	ADF CONTROL UNIT	ROCKWELL COLLINS
787-6366-014	ADF CONTROL UNIT	ROCKWELL COLLINS
787-6366-015	ADF CONTROL UNIT	ROCKWELL COLLINS
787-6366-016	ADF CONTROL UNIT	ROCKWELL COLLINS
787-6366-017	ADF CONTROL UNIT	ROCKWELL COLLINS
787-6366-018	ADF CONTROL UNIT	ROCKWELL COLLINS
787-6377-001	RADIO SET CONTROL	ROCKWELL COLLINS
787-6377-002	RADIO SET CONTROL	ROCKWELL COLLINS
787-6378-001	RADIO SET CONTROL	ROCKWELL COLLINS
787-6378-002	RADIO SET CONTROL	ROCKWELL COLLINS
787-6557-001	RADIO SET CONTROL	ROCKWELL COLLINS
789466	THERMOCOUPLE BOX AND CABLE	PRATT & WHITNEY

PART NUMBER	DESCRIPTION	OEM
790055-1	PRESSURE SELECTOR PANEL	HAMILTON SUNDSTRA
7915043-1	SUPPLY AIR PRESSURE TRANSMITTER	AMETEK
792-6275-001	ADF CONTROL UNIT	ROCKWELL COLLINS
792-6275-002	ADF CONTROL UNIT	ROCKWELL COLLINS
792-6275-003	ADF CONTROL UNIT	ROCKWELL COLLINS
792-6275-004	ADF CONTROL UNIT	ROCKWELL COLLINS
792-6275-005	ADF CONTROL UNIT	ROCKWELL COLLINS
792-6275-006	ADF CONTROL UNIT	ROCKWELL COLLINS
792-6275-007	ADF CONTROL UNIT	ROCKWELL COLLINS
792-6275-008	ADF CONTROL UNIT	ROCKWELL COLLINS
792-6348-001	AUTOPILOT CONTROLLER	ROCKWELL COLLINS
792-6348-002	AUTOPILOT CONTROLLER	ROCKWELL COLLINS
792-6348-003	AUTOPILOT CONTROLLER	ROCKWELL COLLINS
792-6348-004	AUTOPILOT CONTROLLER	ROCKWELL COLLINS
792-6348-005	AUTOPILOT CONTROLLER	ROCKWELL COLLINS
792-6348-015	AUTOPILOT CONTROLLER	ROCKWELL COLLINS
792-6348-101	AUTOPILOT CONTROLLER	ROCKWELL COLLINS
792-6348-102	AUTOPILOT CONTROLLER	ROCKWELL COLLINS
792-6348-103	AUTOPILOT CONTROLLER	ROCKWELL COLLINS
792-6348-104	AUTOPILOT CONTROLLER	ROCKWELL COLLINS
792-6348-105	AUTOPILOT CONTROLLER	ROCKWELL COLLINS
792-6357-001	ATTITUDE DIRECTOR INDICATOR	ROCKWELL INT'L
792-6357-002	ATTITUDE DIRECTOR INDICATOR	ROCKWELL INT'L
792-6357-003	ATTITUDE DIRECTOR INDICATOR	ROCKWELL INT'L
792-6357-005	ATTITUDE DIRECTOR INDICATOR	ROCKWELL INT'L
792-6357-006	ATTITUDE DIRECTOR INDICATOR	ROCKWELL INT'L
792-6357-007	ATTITUDE DIRECTOR INDICATOR	ROCKWELL INT'L
792-6357-008	ATTITUDE DIRECTOR INDICATOR	ROCKWELL INT'L
792-6357-009	ATTITUDE DIRECTOR INDICATOR	ROCKWELL INT'L
792-6357-011	ATTITUDE DIRECTOR INDICATOR	ROCKWELL INT'L
792755-3	PRESSURE CONTROLLER	UTC AEROSPACE
792755-4	PRESSURE CONTROLLER	UTC AEROSPACE
792755-5	PRESSURE CONTROLLER	UTC AEROSPACE
792755-6	PRESSURE CONTROLLER	UTC AEROSPACE
792755-7	PRESSURE CONTROLLER	UTC AEROSPACE
792755-8	PRESSURE CONTROLLER	UTC AEROSPACE
792755-11	PRESSURE CONTROLLER	UTC AEROSPACE
792755-12	PRESSURE CONTROLLER	UTC AEROSPACE
792755-13	PRESSURE CONTROLLER	UTC AEROSPACE
792755-14	PRESSURE CONTROLLER	UTC AEROSPACE
792755-15	PRESSURE CONTROLLER	UTC AEROSPACE
792755-16	PRESSURE CONTROLLER	UTC AEROSPACE
7934123-510	MAIN AND AUXILIARY FUEL TANK CONDUIT ASSY	BOEING
7934123-511	MAIN AND AUXILIARY FUEL TANK CONDUIT ASSY	BOEING
7934123-512	MAIN AND AUXILIARY FUEL TANK CONDUIT ASSY	BOEING
7934123-513	MAIN AND AUXILIARY FUEL TANK CONDUIT ASSY	BOEING
7934123-514	MAIN AND AUXILIARY FUEL TANK CONDUIT ASSY	BOEING
7934123-515	MAIN AND AUXILIARY FUEL TANK CONDUIT ASSY	BOEING
7934123-516	MAIN AND AUXILIARY FUEL TANK CONDUIT ASSY	BOEING
7934123-517	MAIN AND AUXILIARY FUEL TANK CONDUIT ASSY	BOEING
7934123-518	MAIN AND AUXILIARY FUEL TANK CONDUIT ASSY	BOEING
7934123-519	MAIN AND AUXILIARY FUEL TANK CONDUIT ASSY	BOEING
7934123-520	MAIN AND AUXILIARY FUEL TANK CONDUIT ASSY	BOEING
7934123-521	MAIN AND AUXILIARY FUEL TANK CONDUIT ASSY	BOEING
7934123-522	MAIN AND AUXILIARY FUEL TANK CONDUIT ASSY	BOEING
7934123-523	MAIN AND AUXILIARY FUEL TANK CONDUIT ASSY	BOEING
7934123-524	MAIN AND AUXILIARY FUEL TANK CONDUIT ASSY	BOEING
7934123-525	MAIN AND AUXILIARY FUEL TANK CONDUIT ASSY	BOEING
7934123-526	MAIN AND AUXILIARY FUEL TANK CONDUIT ASSY	BOEING
7934123-527	MAIN AND AUXILIARY FUEL TANK CONDUIT ASSY	BOEING
7934123-528	MAIN AND AUXILIARY FUEL TANK CONDUIT ASSY	BOEING
7934123-529	MAIN AND AUXILIARY FUEL TANK CONDUIT ASSY	BOEING
7934123-530	MAIN AND AUXILIARY FUEL TANK CONDUIT ASSY	BOEING
7934123-531	MAIN AND AUXILIARY FUEL TANK CONDUIT ASSY	BOEING
7934123-532	MAIN AND AUXILIARY FUEL TANK CONDUIT ASSY	BOEING
7934123-533	MAIN AND AUXILIARY FUEL TANK CONDUIT ASSY	BOEING
7934123-534	MAIN AND AUXILIARY FUEL TANK CONDUIT ASSY	BOEING

PART NUMBER	DESCRIPTION	OEM
7934163-515	MAIN AND AUXILIARY FUEL TANK CONDUIT ASSY	BOEING
7934163-517	MAIN AND AUXILIARY FUEL TANK CONDUIT ASSY	BOEING
7934163-519	MAIN AND AUXILIARY FUEL TANK CONDUIT ASSY	BOEING
7934163-521	MAIN AND AUXILIARY FUEL TANK CONDUIT ASSY	BOEING
7934163-523	MAIN AND AUXILIARY FUEL TANK CONDUIT ASSY	BOEING
7934163-525	MAIN AND AUXILIARY FUEL TANK CONDUIT ASSY	BOEING
7934163-527	MAIN AND AUXILIARY FUEL TANK CONDUIT ASSY	BOEING
7934163-529	MAIN AND AUXILIARY FUEL TANK CONDUIT ASSY	BOEING
7934163-531	MAIN AND AUXILIARY FUEL TANK CONDUIT ASSY	BOEING
7934163-533	MAIN AND AUXILIARY FUEL TANK CONDUIT ASSY	BOEING
7934163-535	MAIN AND AUXILIARY FUEL TANK CONDUIT ASSY	BOEING
7934163-537	MAIN AND AUXILIARY FUEL TANK CONDUIT ASSY	BOEING
7934163-539	MAIN AND AUXILIARY FUEL TANK CONDUIT ASSY	BOEING
7934163-541	MAIN AND AUXILIARY FUEL TANK CONDUIT ASSY	BOEING
7934163-543	MAIN AND AUXILIARY FUEL TANK CONDUIT ASSY	BOEING
7934163-545	MAIN AND AUXILIARY FUEL TANK CONDUIT ASSY	BOEING
7934163-547	MAIN AND AUXILIARY FUEL TANK CONDUIT ASSY	BOEING
7934163-549	MAIN AND AUXILIARY FUEL TANK CONDUIT ASSY	BOEING
793477	THERMOCOUPLE BOX AND CABLE	PRATT & WHITNEY
793515	THERMOCOUPLE BOX AND CABLE	PRATT & WHITNEY
794-531-2	TANK UNIT	ZODIAC INTERTECHNIQ
794-532-1	TANK UNIT	ZODIAC INTERTECHNIQ
794-533-1	TANK UNIT	ZODIAC INTERTECHNIQ
794-534-1	TANK UNIT	ZODIAC INTERTECHNIQ
794-535-1	TANK UNIT	ZODIAC INTERTECHNIQ
794-536-2	TANK UNIT	ZODIAC INTERTECHNIQ
794-537-2	TANK UNIT	ZODIAC INTERTECHNIQ
794-538-1	TANK UNIT	ZODIAC INTERTECHNIQ
794-540-1	TANK UNIT	ZODIAC INTERTECHNIQ
794-541-2	TANK UNIT	ZODIAC INTERTECHNIQ
794-542-1	TANK UNIT	ZODIAC INTERTECHNIQ
794-543-1	TANK UNIT	ZODIAC INTERTECHNIQ
794-544-1	TANK UNIT	ZODIAC INTERTECHNIQ
794-818	TANK UNIT	ZODIAC INTERTECHNIQ
794-819	TANK UNIT	ZODIAC INTERTECHNIQ
795233	THERMOCOUPLE BOX AND CABLE	PRATT & WHITNEY
7958522-507	ENGINE OIL FILTER DIFFERENTIAL PRESSURE SWITCH	CUSTOM CONTROL SEN
796-354-1	ATTITUDE DETECTOR	INTERTECHNIQUE
796-391	CABLE HARNESS	INTERTECHNIQUE
796-391-1	CABLE HARNESS	INTERTECHNIQUE
796-428	ADAPTORS	ZODIAC
796428-1	ADAPTORS	ZODIAC
796-429-1	ADAPTORS	ZODIAC
796429-2	ADAPTORS	ZODIAC
796-430	ADAPTORS	ZODIAC
796430-1	ADAPTORS	ZODIAC
796-697-1	HARNESS	ZODIAC
796-697-2	HARNESS	ZODIAC
796-697-3	HARNESS	ZODIAC
796-698-1	HARNESS	ZODIAC
796-698-2	HARNESS	ZODIAC
796-698-3	HARNESS	ZODIAC
796-699-1	HARNESS	ZODIAC
796-699-2	HARNESS	ZODIAC
796-699-3	HARNESS	ZODIAC
796-700-1	HARNESS	ZODIAC
796-778-1	ADAPTORS	ZODIAC
796-779-1	ADAPTORS	ZODIAC
796-815C1-01	PRESELECTOR ASSEMBLY	GE AVIATION
796-815-C1-01	PRESELECTOR ASSEMBLY	GE AVIATION
796-815-01-02	PRESELECTOR ASSEMBLY	GE AVIATION
796815-02-03	PRESELECTOR	GE AVIATION
796-871-1	HARNESS	ZODIAC
796-871-2	HARNESS	ZODIAC
796-871-3	HARNESS	ZODIAC
796-947-1	HARNESS	ZODIAC
796-947-2	HARNESS	ZODIAC

PART NUMBER	DESCRIPTION	OEM
796-947-3	HARNESS	ZODIAC
796-948-1	HARNESS	ZODIAC
796-948-2	HARNESS	ZODIAC
796-948-3	HARNESS	ZODIAC
796-949-1	HARNESS	ZODIAC
796-949-2	HARNESS	ZODIAC
796-949-3	HARNESS	ZODIAC
796-965	HARNESS	ZODIAC
796-966	PRESELECTOR	ZODIAC
796-976	HARNESS	ZODIAC
796-977	HARNESS	ZODIAC
796-977-1	HARNESS	ZODIAC
796-977-2	HARNESS	ZODIAC
796-978	HARNESS	ZODIAC
797480-1	PRESSURE SELECTOR PANEL	HAMILTON SUNDSTRA
797480-2	PRESSURE SELECTOR PANEL	HAMILTON SUNDSTRA
797480-3	PRESSURE SELECTOR PANEL	HAMILTON SUNDSTRA
797480-4	PRESSURE SELECTOR PANEL	HAMILTON SUNDSTRA
797480-5	PRESSURE SELECTOR PANEL	HAMILTON SUNDSTRA
797480-6	PRESSURE SELECTOR PANEL	HAMILTON SUNDSTRA
798-017	HARNESS	ZODIAC
798-017-1	HARNESS	ZODIAC
798-017-2	HARNESS	ZODIAC
798-017-3	HARNESS	ZODIAC
798-021-01-02	PRESELECTOR ASSEMBLY	GE AVIATION
798021-02-03	PRESELECTOR	GE AVIATION
798-078	HARNESS	ZODIAC
798-078-1	HARNESS	ZODIAC
798-078-2	HARNESS	ZODIAC
798287	THERMOCOUPLE BOX AND CABLE	PRATT & WHITNEY
799607	THERMOCOUPLE BOX AND CABLE	PRATT & WHITNEY
799628	THERMOCOUPLE BOX AND CABLE	PRATT & WHITNEY
799817	THERMOCOUPLE BOX AND CABLE	PRATT & WHITNEY
8DJ175LWK2	ENGINE EXHAUST GAS TEMPERATURE INDICATOR	AMETEK AEROSPACE
8DJ175LWK2-T	ENGINE EXHAUST GAS TEMPERATURE INDICATOR	AMETEK AEROSPACE
8DJ175LWM2	ENGINE EXHAUST GAS TEMPERATURE INDICATOR	AMETEK AEROSPACE
8DJ175LWS2	ENGINE EXHAUST GAS TEMPERATURE INDICATOR	AMETEK AEROSPACE
8DJ175LWT2	ENGINE EXHAUST GAS TEMPERATURE INDICATOR	AMETEK AEROSPACE
8DJ175LXB2	ENGINE EXHAUST GAS TEMPERATURE INDICATOR	AMETEK AEROSPACE
8DJ175LXF2	ENGINE EXHAUST GAS TEMPERATURE INDICATOR	AMETEK AEROSPACE
8DJ175LXP2	ENGINE EXHAUST GAS TEMPERATURE INDICATOR	AMETEK AEROSPACE
8DJ176LWG2	ENGINE CORE SPEED INDICATOR	AMETEK AEROSPACE
8DJ176LWV2	ENGINE CORE SPEED INDICATOR	AMETEK AEROSPACE
8DJ176LZA3	ENGINE CORE SPEED INDICATOR	AMETEK AEROSPACE
8DJ176LZF2	ENGINE CORE SPEED INDICATOR	AMETEK AEROSPACE
8DJ176LZS2	ENGINE CORE SPEED INDICATOR	AMETEK AEROSPACE
8DJ176WAR2	ENGINE CORE SPEED INDICATOR	AMETEK AEROSPACE
8ES005304-SERIES	ENERGY BOX	HELLA KG HUECK CO
8ES005421-09	POWER SUPPLY UNIT	UTC AEROSPACE
8ES005421-19	POWER SUPPLY UNIT	UTC AEROSPACE
8G441-1	GAGE PRESSURE SWITCH	CUSTOM COMPONENT SWITCHES
8SC0055	INTERTURBINE TEMP INDICATOR ASSY	AMETEK
8SC0325	INTERTURBINE TEMP INDICATOR ASSY	AMETEK
8TJ209HAB1	OIL LEVEL/TEMPERATURE SENSOR	AMETEK
80000000-11	STABILIZER TRIM LIMIT SWITCH	MOOG
8000281Y00	RUNWAY TURN-OFF LIGHT	ZODIAC AEROSPACE
8000306Y00	RUNWAY TURN-OFF LIGHT	ZODIAC AEROSPACE
8001-05	OVEN	SELL
8001-05-0000	OVEN	SELL
8001-05-0000A	OVEN	SELL
8001-06-0000	OVEN	SELL
8001-06-0000A	OVEN	SELL
8001-06-0000B	OVEN	SELL
8001-16-0000	OVEN	SELL
8001-16-0000A	OVEN	SELL
8001-16-0000B	OVEN	SELL
8054-19-0000	OVEN ASSY	BUDERUS SELL

PART NUMBER	DESCRIPTION	OEM
8054-69-0000	OVEN ASSY	BUDERUS SELL
8-061-02	PROXIMITY ELECTRONICS UNIT	ELDEC CORPORATION
8-061-03	PROXIMITY ELECTRONICS UNIT	ELDEC CORPORATION
8-061-04	PROXIMITY ELECTRONICS UNIT	ELDEC CORPORATION
8-061-05	PROXIMITY ELECTRONICS UNIT	ELDEC CORPORATION
8-061-12	PROXIMITY ELECTRONICS UNIT	ELDEC CORPORATION
8-061-12A	PROXIMITY ELECTRONICS UNIT	ELDEC CORPORATION
8-061-14	PROXIMITY ELECTRONICS UNIT	ELDEC CORPORATION
8-061-15	PROXIMITY ELECTRONICS UNIT	ELDEC CORPORATION
8-061-24	PROXIMITY ELECTRONICS UNIT	ELDEC CORPORATION
8-061-25	PROXIMITY ELECTRONICS UNIT	ELDEC CORPORATION
806636	THERMOCOUPLE BOX AND CABLE	PRATT & WHITNEY
806637	THERMOCOUPLE BOX AND CABLE	PRATT & WHITNEY
808957	OVEN CONTROL MODULE 700 SERIES	BE AEROSPACE
808959	OVEN CONTROL MODULE 700 SERIES	BE AEROSPACE
808962	OVEN CONTROL MODULE 700 SERIES	BE AEROSPACE
808982	OVEN CONTROL MODULE 700 SERIES	BE AEROSPACE
81000-15001	LOGO LIGHT ASSEMBLY	KOITO
81000-15002	LOGO LIGHT ASSEMBLY	KOITO
81000-15003	LOGO LIGHT ASSEMBLY	KOITO
81000-15004	LOGO LIGHT ASSEMBLY	KOITO
81000-15005	LOGO LIGHT ASSEMBLY	KOITO
81000-15006	LOGO LIGHT ASSEMBLY	KOITO
81000-37601	LOGO LIGHT ASSEMBLY	KOITO
81000-37602	LOGO LIGHT ASSEMBLY	KOITO
8101-01-0000	OVEN	SELL
8101-01-0000C	OVEN	SELL
8101-02-0000	OVEN	SELL
8101-04-0000	OVEN	SELL
8101-07-0000	OVEN	SELL
8101-08-0000C	OVEN	SELL
8101-09-0000	OVEN	SELL
8101-11-0000	OVEN	SELL
8101-11-0000A	OVEN	SELL
8101-11-0000B	OVEN	SELL
8101-11-0000C	OVEN	SELL
8101-12-0000	OVEN	SELL
8101-12-0000A	OVEN	SELL
8101-12-0000B	OVEN	SELL
8101-12-0000C	OVEN	SELL
8101-13-0000	OVEN	SELL
8101-14-0000	OVEN	SELL
8101-14-0000A	OVEN	SELL
8101-14-0000B	OVEN	SELL
8101-15-0000	OVEN	SELL
8101-17-0000	OVEN	SELL
8101-17-0000A	OVEN	SELL
8101-17-0000B	OVEN	SELL
8101-18-0000	OVEN	SELL
8101-18-0000A	OVEN	SELL
8101-18-0000B	OVEN	SELL
8101-18-0000C	OVEN	SELL
8101-19-0000	OVEN	SELL
8101-19-0000A	OVEN	SELL
8101-19-0000B	OVEN	SELL
8101-21-0000B	OVEN	SELL
8101-21-0000C	OVEN	SELL
8101-22-0000B	OVEN	SELL
8101-26-0000B	OVEN	SELL
8101-26-0000C	OVEN	SELL
8101-27-0000	OVEN	SELL
8101-27-0000C	OVEN	SELL
8101-28-0000B	OVEN	SELL
8101-330-0000	OVEN	SELL
8101-61-0000B	OVEN	SELL
8101-61-0000C	OVEN	SELL
8101-66-0000B	OVEN	SELL
8101-66-0000C	OVEN	SELL

PART NUMBER	DESCRIPTION	OEM
8101-71-0000B	OVEN	SELL
8101-71-0000C	OVEN	SELL
8101-76-0000B	OVEN	SELL
8101-76-0000C	OVEN	SELL
8103-01-0000	OVEN	SELL
8103-02-0000	OVEN	SELL
8103-06-0000	OVEN	SELL
8103-07-0000	OVEN	SELL
814067	THERMOCOUPLE BOX AND CABLE	PRATT & WHITNEY
814392-1-001	PRESSURE SELECTOR PANEL	UTC AEROSPACE
814392-2-002	PRESSURE SELECTOR PANEL	UTC AEROSPACE
814392-2-003	PRESSURE SELECTOR PANEL	UTC AEROSPACE
814392-3-001	PRESSURE SELECTOR PANEL	UTC AEROSPACE
814392-4-002	PRESSURE SELECTOR PANEL	UTC AEROSPACE
814392-4-003	PRESSURE SELECTOR PANEL	UTC AEROSPACE
816101-2	TEMPERATURE CONTROLLER	HAMILTON SUNDSTRA
816101-4	TEMPERATURE CONTROLLER	HAMILTON SUNDSTRA
8184-1	ELECTRONIC BALLAST	AVTECHTYEE
8184-1 MOD A	ELECTRONIC BALLAST	AVTECHTYEE
8201-01-0000	OVEN	BUDERUS SELL
8201-02-0000	OVEN	BUDERUS SELL
8201-03-0000	OVEN	BUDERUS SELL
8201-04-0000	OVEN	BUDERUS SELL
8201-07-0000	OVEN	BUDERUS SELL
8201-11-0000	OVEN	BRITAX SELL
8201-11-0000A	OVEN	BRITAX SELL
8201-11-0000D	OVEN	BRITAX SELL
8201-11-0000-01	OVEN	SELL
8201-11-0000-04	OVEN	SELL
8201-11-0000-11	OVEN	SELL
8201-11-0000-12	OVEN	SELL
8201-11-0000-15	OVEN	SELL
8201-11-0000-33	OVEN	SELL
8201-12-0000	OVEN	BRITAX SELL
8201-12-0000D	OVEN	BRITAX SELL
8201-13-0000	OVEN	BRITAX SELL
8201-14-0000	OVEN	BRITAX SELL
8201-17-0000	OVEN	BRITAX SELL
8201-51-0000	OVEN	BUDERUS SELL
8201-52-0000	OVEN	BUDERUS SELL
8201-53-0000	OVEN	BUDERUS SELL
8201-54-0000	OVEN	BUDERUS SELL
8201-61-0000	OVEN	BRITAX SELL
8201-61-0000-01	OVEN	SELL
8201-61-0000-15	OVEN	SELL
8201-61-0000-33	OVEN	SELL
8201-63-0000	OVEN	BRITAX SELL
8201-64-0000	OVEN	BRITAX SELL
8201-67-0000	OVEN	BRITAX SELL
8203-11-0000	OVEN	SELL
8203-11-0000A	OVEN	SELL
8203-11-0000D	OVEN	SELL
8203-11-0000-01	OVEN	SELL
8203-11-0000-12	OVEN	SELL
8203-11-0000-16	OVEN	SELL
8203-12-0000	OVEN	SELL
8203-12-0000C	OVEN	SELL
8203-12-0000D	OVEN	SELL
8203-17-0000	OVEN	SELL
8203-61-0000	OVEN	SELL
8203-62-0000	OVEN	SELL
8203-63-0000C	OVEN	SELL
8203-67-0000	OVEN	SELL
824PTY	800 SERIES SMOKE DETECTOR	GENTEX
824392-1-002	PRESSURE SELECTOR PANEL PSL105-1	UTC AEROSPACE
824392-1-003	PRESSURE SELECTOR PANEL PSL105-1	UTC AEROSPACE
824392-2-002	PRESSURE SELECTOR PANEL PSL105-1	UTC AEROSPACE

PART NUMBER	DESCRIPTION	OEM
824392-2-003	PRESSURE SELECTOR PANEL PSL105-1	UTC AEROSPACE
83000-05601	WINDOW HEAT CONTROL	KOITO
83000-05602	WINDOW HEAT CONTROL	KOITO
83000-05603	WINDOW HEAT CONTROL UNIT	KOITO
83000-05604	WINDOW HEAT CONTROL UNIT	KOITO
83000-05605	WINDOW HEAT CONTROL UNIT	KOITO
83427	COFFEE / LAVATORY PUMP	MICROPUMP
851AH	PITOT TUBE	ROSEMOUNT
861CAB	ANGLE OF ATTACK SENSOR	ROSEMOUNT
861CAE	ANGLE OF ATTACK SENSOR	ROSEMOUNT
861CAE1	ANGLE OF ATTACK SENSOR	ROSEMOUNT
861CAS3	ANGLE OF ATTACK SENSOR	ROSEMOUNT
87001-24	MONITOR SPEAKER	OLIN AEROSPACE
871BN3-2	ICE DETECTOR	UTC AEROSPACE
871BN3-4	ICE DETECTOR	UTC AEROSPACE
871BN3-6	ICE DETECTOR	UTC AEROSPACE
87232323V00	DUCT TEMP SENSOR	THALES
87232323V01	DUCT TEMP SENSOR	THALES
87500-1130	CLOCK, MECHANICAL AIRCRAFT	AEROSONIC
87500-1132	CLOCK, MECHANICAL AIRCRAFT	AEROSONIC
87500-1133	CLOCK, MECHANICAL AIRCRAFT	AEROSONIC
87500-1134	CLOCK, MECHANICAL AIRCRAFT	AEROSONIC
87500-1135	CLOCK, MECHANICAL AIRCRAFT	AEROSONIC
87500-1136	CLOCK, MECHANICAL AIRCRAFT	AEROSONIC
87500-1137	CLOCK, MECHANICAL AIRCRAFT	AEROSONIC
87500-1138	CLOCK, MECHANICAL AIRCRAFT	AEROSONIC
87500-1139	CLOCK, MECHANICAL AIRCRAFT	AEROSONIC
87500-1140	CLOCK, MECHANICAL AIRCRAFT	AEROSONIC
87500-1141	CLOCK, MECHANICAL AIRCRAFT	AEROSONIC
87500-1142	CLOCK, MECHANICAL AIRCRAFT	AEROSONIC
87500-1143	CLOCK, MECHANICAL AIRCRAFT	AEROSONIC
87500-1144	CLOCK, MECHANICAL AIRCRAFT	AEROSONIC
87500-1145	CLOCK, MECHANICAL AIRCRAFT	AEROSONIC
87500-1146	CLOCK, MECHANICAL AIRCRAFT	AEROSONIC
87500-2131	CLOCK, MECHANICAL AIRCRAFT	AEROSONIC
8870-01	FIRE/OVERHEAT DETECTOR MODEL 801 TRSS	MEGGITT
8870-02	FIRE/OVERHEAT DETECTOR MODEL 801 TRSS	MEGGITT
8870-03	FIRE/OVERHEAT DETECTOR MODEL 801 TRSS	MEGGITT
8870-04	FIRE/OVERHEAT DETECTOR MODEL 801 TRSS	MEGGITT
8870-11	FIRE/OVERHEAT DETECTOR MODEL 801 TRSS	MEGGITT
8870-12	FIRE/OVERHEAT DETECTOR MODEL 801 TRSS	MEGGITT
8870-13	FIRE/OVERHEAT DETECTOR MODEL 801 TRSS	MEGGITT
8870-14	FIRE/OVERHEAT DETECTOR MODEL 801 TRSS	MEGGITT
8921082G1	LAVATORY WATER HEATER	BF GOODRICH
8921082G2	LAVATORY WATER HEATER	BF GOODRICH
8921082G5	LAVATORY WATER HEATER	BF GOODRICH
8921082G6	LAVATORY WATER HEATER	BF GOODRICH
8921340G1	LAVATORY WATER HEATER	BF GOODRICH
892809-0400	FIRE DETECTOR, CONTROL UNIT	KIDDE AEROSPACE
892809-0400-01	FIRE DETECTOR, CONTROL UNIT	KIDDE AEROSPACE
892809-0400-02	FIRE DETECTOR, CONTROL UNIT	KIDDE AEROSPACE
892809-0400-03	FIRE DETECTOR, CONTROL UNIT	KIDDE AEROSPACE
8930-XXX-XXXXXX	MODEL 602 SMOKE DETECTOR	MEGGITT
8930-111B	MODEL 602 SMOKE DETECTOR	MEGGITT
8930-111B60L010	MODEL 602 SMOKE DETECTOR	MEGGITT
8930-112AB	MODEL 602 SMOKE DETECTOR	MEGGITT
8930-112B	MODEL 602 SMOKE DETECTOR	MEGGITT
8930-112B00H114	MODEL 602 SMOKE DETECTOR	MEGGITT
8930-112B69H412	MODEL 602 SMOKE DETECTOR	MEGGITT
8930-122B	MODEL 602 SMOKE DETECTOR	MEGGITT
8930-123AB	MODEL 602 SMOKE DETECTOR	MEGGITT
8930-123B	MODEL 602 SMOKE DETECTOR	MEGGITT
8930-123-91H014	MODEL 602 SMOKE DETECTOR	MEGGITT
8930-132B	MODEL 602 SMOKE DETECTOR	MEGGITT
8930-212B	MODEL 602 SMOKE DETECTOR	MEGGITT
8930-222B	MODEL 602 SMOKE DETECTOR	MEGGITT
8930-223B	MODEL 602 SMOKE DETECTOR	MEGGITT

PART NUMBER	DESCRIPTION	OEM
8930-223B90H014	MODEL 602 SMOKE DETECTOR	MEGGITT
899-0850-002	RMP 850 RADIO MANAGEMENT PANEL	THALES
899-0850-003	RMP 850 RADIO MANAGEMENT PANEL	THALES
899-0850-004	RMP 850 RADIO MANAGEMENT PANEL	THALES
899315	CONTROL MODULE, ENGINE FIRE & OVERHEAT & APU FIRE	KIDDE AEROSPACE
899315-01	CONTROL MODULE, ENGINE FIRE & OVERHEAT & APU FIRE	KIDDE AEROSPACE
899315-02	CONTROL MODULE, ENGINE FIRE & OVERHEAT & APU FIRE	KIDDE AEROSPACE
899315-03	CONTROL MODULE, ENGINE FIRE & OVERHEAT & APU FIRE	KIDDE AEROSPACE
899315-04	CONTROL MODULE, ENGINE FIRE & OVERHEAT & APU FIRE	KIDDE AEROSPACE
899315-05	CONTROL MODULE, ENGINE FIRE & OVERHEAT & APU FIRE	KIDDE AEROSPACE
899315-06	CONTROL MODULE, ENGINE FIRE & OVERHEAT & APU FIRE	KIDDE AEROSPACE
899315-07	CONTROL MODULE, ENGINE FIRE & OVERHEAT & APU FIRE	KIDDE AEROSPACE
899315-08	CONTROL MODULE, ENGINE FIRE & OVERHEAT & APU FIRE	KIDDE AEROSPACE
899315-09	CONTROL MODULE, ENGINE FIRE & OVERHEAT & APU FIRE	KIDDE AEROSPACE
9BG408324-00	LIGHT ASSEMBLY, HOUSING ASSEMBLY	GOODRICH
9005-42	BATTERY POWER SUPPLY, EMERGENCY EXIT LIGHTS	IDD AEROSPACE CORP
9008D09-1	POWER RELAY	HAMILTON SUNDST
9008D09-2	POWER RELAY	HAMILTON SUNDST
9008D09-3	POWER RELAY	HAMILTON SUNDST
9010-1-1 MOD A	ELECTRONIC CLOCK	AVTECHTYEE
2596877	ELECTRONIC CLOCK	AVTECHTYEE
2596878	ELECTRONIC CLOCK	AVTECHTYEE
902015-01	FIRE/OVERHEAT DETECTOR ASSEMBLY	MEGGITT
902016-01	FIRE/OVERHEAT DETECTOR ASSEMBLY	MEGGITT
902017-01	FIRE/OVERHEAT DETECTOR ASSEMBLY	MEGGITT
902018-01	FIRE/OVERHEAT DETECTOR ASSEMBLY	MEGGITT
902862	FIRE/OVERHEAT DETECTOR ASSEMBLY	MEGGITT
902864	FIRE/OVERHEAT DETECTOR ASSEMBLY	MEGGITT
903-1341	MICROPHONE, ELECTRET NOISE CANCELING	ELECTRO-VOICE
903-1342	MICROPHONE, ELECTRET NOISE CANCELING	ELECTRO-VOICE
9-115-10	FUEL FLOW ELECTRONICS PKG	CRANE
9-115-11	FUEL FLOW ELECTRONICS PKG	CRANE
9-115-14	FUEL FLOW ELECTRONICS PKG	CRANE
9-115-18	FUEL FLOW ELECTRONICS PKG	CRANE
9-115-19	FUEL FLOW ELECTRONICS PKG	CRANE
9124-8073	RELAY	LEACH CORPORATION
9124-8074	RELAY	LEACH CORPORATION
9131-8506	RELAY	LEACH CORPORATION
915F213-2	BUS PROTECTION PANEL	UTC AEROSPACE
915F213-3	BUS PROTECTION PANEL	UTC AEROSPACE
915F213-4	BUS PROTECTION PANEL	UTC AEROSPACE
915F369-3	ELECTRICAL LOAD CONTROL UNIT	HAMILTON SUNDSTRA
915F369-5	ELECTRICAL LOAD CONTROL UNIT	HAMILTON SUNDSTRA
9207-8333	RELAY	LEACH CORPORATION
9207-8333-1	RELAY	LEACH CORPORATION
9207-8968	RELAY	LEACH CORPORATION
9207-10101	RELAY	LEACH CORPORATION
9207-10166	RELAY	LEACH CORPORATION
9207-10296	RELAY	LEACH CORPORATION
9227-10127	RELAY	LEACH CORPORATION
9274-8681	RELAY	LEACH CORPORATION
941D335-2	CIRCUIT BREAKER	UTC AEROSPACE
941D335-4	CIRCUIT BREAKER	UTC AEROSPACE
941D339-1	CURRENT TRANSFORMER PACKAGE	WESTINGHOUSE
941D340-1	CURRENT TRANSFORMER PACKAGE	WESTINGHOUSE
947F945-1	GENERATOR CONTROL UNIT	HAMILTON SUNDSTRA
947F945-2	GENERATOR CONTROL UNIT	HAMILTON SUNDSTRA
947F945-3	GENERATOR CONTROL UNIT	HAMILTON SUNDSTRA
947F946-1	BUS CONTROL PANEL	UTC AEROSPACE
947F946-2	BUS CONTROL PANEL	UTC AEROSPACE
947F946-3	BUS CONTROL PANEL	UTC AEROSPACE
948F458-1	GENERATOR CONTROL UNIT (GCU)	UTC AEROSPACE
948F458-2	GENERATOR CONTROL UNIT (GCU)	UTC AEROSPACE
948F458-3	GENERATOR CONTROL UNIT (GCU)	UTC AEROSPACE
948F458-4	GENERATOR CONTROL UNIT (GCU)	UTC AEROSPACE
948F458-5	GENERATOR CONTROL UNIT (GCU)	UTC AEROSPACE
9599-607-12118	HEIGHT INDICATOR FOR RADIO ALTIMETERS	THALES

PART NUMBER	DESCRIPTION	OEM
9599-607-12167	HEIGHT INDICATOR FOR RADIO ALTIMETERS	THALES
9599-607-12174	HEIGHT INDICATOR FOR RADIO ALTIMETERS	THALES
9599-607-15103	RADIO ALTITUDE INDICATOR	THALES
9599-607-15104	RADIO ALTITUDE INDICATOR	THALES
965-0449-001	STALL WARNING COMPUTER	HONEYWELL
965-0449-002	STALL WARNING COMPUTER	HONEYWELL
965-0449-011	STALL WARNING COMPUTER	HONEYWELL
965-0449-030	STALL WARNING COMPUTER	HONEYWELL
975-0018-001	THERMAL SWITCH	HONEYWELL
975-0018-005	THERMAL SWITCH	HONEYWELL
975-0018-006	THERMAL SWITCH	HONEYWELL
975-0018-007	THERMAL SWITCH	HONEYWELL
9810	MECHANICALLY TIMED FAUCET ASSEMBLY	ADAMS RITE
9810-3	MECHANICALLY TIMED FAUCET ASSEMBLY	ADAMS RITE
9810-5	MECHANICALLY TIMED FAUCET ASSEMBLY	ADAMS RITE
9810-7	MECHANICALLY TIMED FAUCET ASSEMBLY	ADAMS RITE
9810-9	MECHANICALLY TIMED FAUCET ASSEMBLY	ADAMS RITE
9810-11	MECHANICALLY TIMED FAUCET ASSEMBLY	ADAMS RITE
9810-13	MECHANICALLY TIMED FAUCET ASSEMBLY	ADAMS RITE
9810-21	MECHANICALLY TIMED FAUCET ASSEMBLY	ADAMS RITE
9810-23	MECHANICALLY TIMED FAUCET ASSEMBLY	ADAMS RITE
9810-25	MECHANICALLY TIMED FAUCET ASSEMBLY	ADAMS RITE
9810-27	MECHANICALLY TIMED FAUCET ASSEMBLY	ADAMS RITE
9810-29	MECHANICALLY TIMED FAUCET ASSEMBLY	ADAMS RITE
9810-31	MECHANICALLY TIMED FAUCET ASSEMBLY	ADAMS RITE
9810-101	MECHANICALLY TIMED FAUCET ASSEMBLY	ADAMS RITE
9810-103	MECHANICALLY TIMED FAUCET ASSEMBLY	ADAMS RITE
9819	MECHANICALLY TIMED FAUCET ASSEMBLY	ADAMS RITE
9819-3	MECHANICALLY TIMED FAUCET ASSEMBLY	ADAMS RITE
9819-101	MECHANICALLY TIMED FAUCET ASSEMBLY	ADAMS RITE
9824	MECHANICALLY TIMED FAUCET ASSEMBLY	ADAMS RITE
9824-3	MECHANICALLY TIMED FAUCET ASSEMBLY	ADAMS RITE
9824-5	MECHANICALLY TIMED FAUCET ASSEMBLY	ADAMS RITE
9819-93-02	TRAILING EDGE FLAP POSITION INDICATOR	CLIFTON PRECISION
9819-93-03	TRAILING EDGE FLAP POSITION INDICATOR	CLIFTON PRECISION
9819-93-05	TRAILING EDGE FLAP POSITION INDICATOR	CLIFTON PRECISION
9819-93-06	TRAILING EDGE FLAP POSITION INDICATOR	CLIFTON PRECISION
9819-93-09	TRAILING EDGE FLAP POSITION INDICATOR	CLIFTON PRECISION